

Introduction

Thank you for purchasing the Solaris microphone from M-Audio. Please take a few moments to read the following guide in order to get the maximum results from your microphone.

Important: Please fill out and mail your warranty card for the Solaris immediately so that we may provide you with support for your microphone (you may also register online at www.m-audio.com/register).

Features

- > Large all brass capsule
- > Class A FET Electronics
- > Includes shock mount and hard case
- > 3 Polar patterns: cardioid, omni and figure 8
- > 10dB switchable attenuation pad
- > Bass Cut pad, 6dB per octave
- > 1.1" evaporated gold diaphragm

Unpacking

The container for your microphone was carefully constructed for protection during shipping. Please save this packaging for storage or traveling with your Solaris microphone. If your box does not include the following items, please contact your dealer immediately:

- 1 M-Audio Solaris microphone
- 1 hard case
- 1 shock mount

Care of Your Microphone

Here are a few tips for care of your Solaris microphone:

- > Never subject the Solaris to physical shock.
- > Always use the included shock mount when securing to a stand.
- > Always wipe the Solaris exterior down with a soft dry cloth and return the Solaris to its case after each use to prevent damage from dust and shock.
- > In the event that your Solaris needs more extensive cleaning, lightly dampen a soft cloth with water or mild household soap and clean the metal exterior of the Solaris, wiping it completely dry when finished. Never spray a cleaning agent on the microphone itself, as the moisture can damage the unit.
- > Avoid subjecting the Solaris to any kind of moisture. In vocal applications, moisture from breath condensation / saliva build-up

can be prevented by use of a windscreen.

- > Never disassemble the Solaris microphone. There are no user-serviceable parts inside.
- > Always use top-quality cables in order to avoid shorts that may damage the microphone's electronics.
- > Avoid temperature extremes above 95°F and below 50°F. When moving the microphone between outdoor and indoor environments, allow the microphone to acclimate to room temperature before connection and use, in order to avoid condensation on the diaphragm.

Connections and Phantom Power

The M-Audio Solaris microphone outputs a balanced, low impedance signal. It requires the additional signal boost acquired via connection to mic-level inputs of a preamp or mixer channel.

As with all condenser microphones, your Solaris condenser requires power in order to operate. You will need to connect the Solaris via XLR connection to a preamp or mixer channel strip that supplies +48V phantom power (phantom power shares the same XLR cable as the audio from the microphone). In order to avoid loud pops that can damage components like speakers and microphones, always perform the following steps (in the order listed) when connecting the mic and/or cable:

1. Turn the gain on your preamp and/or mixer all the way down
2. Make sure that phantom power is disengaged
3. Connect the microphone via a high-quality XLR cable
4. Engage phantom power
5. Turn up the gain on your preamp and/or mixer

Before disconnecting the mic and/or cable:

1. Turn the gain on your preamp and/or mixer all the way down
2. Disengage phantom power
3. Disconnect the microphone via a high-quality XLR cable

Applications

The Solaris's clean-sounding technology is combined with an all-brass capsule to produce a smooth bottom and vintage tone that's perfect for capturing and enhancing great vocals. The Solaris is also great for most other instruments and applications—including amplified guitar or bass.

Solaris Specification Data

Type: **Large diaphragm condenser, double-sided**
Polar Patterns: **cardioid, omni-directional, figure-eight**
Frequency Response: **20Hz – 20kHz**
Sensitivity: **16 mV/Pa (-36dBV)**
Max. SPL for 0.5% THD: **130dB**
Equivalent Noise Level: **14dB A weighted**
Attenuation Pad: **-10dB, switchable**
Bass Cut Pad: **6dB/octave, below 125Hz, switchable**
Output Impedance: **200 Ω**
Recommended Load Impedance: **> 1,000 Ω**
Preamp Topology: **Class A FET, with output transformer**
Power Requirement: **48V phantom power**
Connector: **3-pin male XLR**
Dimensions: **Lollipop style, 76 mm (3") max. top grille, 210 mm (8.25") long**
Weight: **650 g (23 oz)**
Package: **Solaris microphone and SM-4 shock mount in aluminum carrycase**

Solaris Warranty Terms

M-Audio warrants that this product is free of defects in materials and workmanship under normal use for a period of Six (6) months, so long as the product is: owned by the original purchaser; the original purchaser has proof of purchase from an authorized M-Audio dealer; and the purchaser has registered his/her ownership of the product by sending in the completed warranty card. This warranty explicitly excludes included accessories which may become defective as a result of normal wear and tear. In the event that M-Audio receives written notice of defects in materials or workmanship from such an original purchaser, M-Audio will either replace the product, repair the product, or refund the purchase price at its option. In the event any repair is required, shipment to and from M-Audio and a nominal handling charge shall be borne by the purchaser. In the event that repair is required, a Return Authorization number must be obtained from M-Audio. After this number is obtained, the unit should be shipped back to M-Audio in a protective package with a description of the problem and the Return Authorization clearly written on the package.

In the event that M-Audio determines that the product requires repair because of user misuse or regular wear, it will assess a fair repair or replacement fee. The customer will have the option to pay this fee and have the unit repaired and returned, or not pay this fee and have the unit returned unrepared. The remedy for breach of this limited warranty shall not include any other damages. M-Audio will not be liable for consequential, special, indirect, or similar damages or claims including loss of profit or any other commercial damage, even if its agents have been advised of the possibility of such damages, and in no event will M-Audio's liability for any damages to the purchaser or any other person exceed the price paid for the product, regardless of any form of the claim. M-Audio specifically disclaims all other warranties, expressed or implied. Specifically, M-Audio makes no warranty that the product is fit for any particular purpose. This warranty shall be construed, interpreted, and governed by the laws of the state of California. If any provision of this warranty is found void, invalid or unenforceable, it will not affect the validity of the balance of the warranty, which shall remain valid and enforceable according to its terms. In the event any remedy hereunder is determined to have failed of its essential purpose, all limitations of liability and exclusion of damages set forth herein shall remain in full force and effect.

M-AUDIO[®]

USER GUIDE



Solaris

professional
condenser microphone

care & usage