


**SAMSUNG**

# MICROWAVE OVEN

## Owner's Instructions and Cooking Guide

**GE89M / GE89MST**






|  |    |
|--|----|
| Quick Look-up Guide .....                              | 2  |
| Oven.....  | 2  |
| Control Panel .....                                    | 3  |
| Accessories.....                                       | 3  |
| Using this Instruction Booklet.....                    | 4  |
| Safety Precautions .....                               | 4  |
| Installing Your Microwave Oven .....                   | 5  |
| Setting the Time .....                                 | 6  |
| What to Do if You are in Doubt or Have a Problem ..... | 6  |
| Cooking / Reheating.....                               | 7  |
| Power Levels.....                                      | 7  |
| Stopping the Cooking.....                              | 8  |
| Adjusting the Cooking Time .....                       | 8  |
| Using the Steam Cleaning .....                         | 8  |
| Using the Auto Reheat Feature .....                    | 9  |
| Auto Reheat Settings .....                             | 9  |
| Using the Auto Power Defrost Feature .....             | 10 |
| Auto Power Defrost Settings.....                       | 10 |
| Using the Auto Crusty Cook Function.....               | 11 |
| Using the Manual Crusty Cook Function .....            | 12 |
| Choosing the Heating Element Position .....            | 13 |
| Choosing the Accessories .....                         | 13 |
| Grilling .....   | 13 |
| Combining Microwave and the Grill .....                | 14 |
| Switching the Beeper Off .....                         | 14 |
| Using the Child Lock Feature.....                      | 14 |
| Cookware Guide .....                                   | 15 |
| Cooking Guide .....                                    | 16 |
| Cleaning Your Microwave Oven .....                     | 22 |
| Storing and Repairing Your Microwave Oven.....         | 23 |
| Technical Specifications.....                          | 23 |

## Quick Look-up Guide

### If you want to cook some food






1. Place the food in the oven.  
Select the power level by pressing the  button one or more times.
2. Set the cooking time by Pressing the ( - ) and ( + ) buttons as required.
3. Press the  button.  
**Result:** Cooking starts. The oven beeps four times when cooking is over.



### If you want to auto power defrost some food



1. Place the frozen food in the oven.  
Select the type of food that you are cooking by pressing the **Power Defrost** () button one or more times.
2. Select the food weight by pressing the ( - ) and ( + ) buttons.
3. Press the  button.





### If you want to add extra 30 seconds



- Leave the food in the oven.  
Press **+30s** one or more times for each extra 30 seconds that you wish to add.


### If you want to grill some food




1. Press the  button.
2. Set the cooking time by Pressing the ( - ) and ( + ) buttons.
3. Press the  button.



## Oven



## Control Panel




- |  |                          |
|--|--------------------------|
| 1. DISPLAY   | 7. STOP/CANCEL BUTTON    |
| 2. AUTO POWER DEFROST<br>BUTTON  | 8. CLOCK SETTING         |
| 3. AUTO CRUSTY COOK<br>SELECTION                                       | 9. AUTO REHEAT SELECTION |
| 4. GRILL MODE SELECTION  | 10. STEAM CLEAN BUTTON   |
| 5. MICROWAVE/ POWER LEVEL<br>MODE SELECTION                            | 11. COMBI MODE SELECTION |
| 6. UP (+) / DOWN (-) BUTTON<br>(Cook time, Weight and serving<br>size) | 12. CHILD LOCK SELECTION |
|  | 13. START BUTTON         |


## Accessories

Depending on the model that you have purchased, you are supplied with several accessories that can be used in a variety of ways.


EN




1. **Coupler**, already placed over the motor shaft in the base of the oven.  
**Purpose** : The coupler rotates the turntable.




2. **Roller ring**, to be placed in the centre of the oven.  
**Purpose** : The roller ring supports the turntable.




3. **Turntable**, to be placed on the roller ring with the centre fitting to the coupler.  
**Purpose** : The turntable serves as the main cooking surface; it can be easily removed for cleaning.



4. **Metal rack**, to be placed on the turntable.  
**Purpose** : The metal rack can be used in grill and combination cooking.



5. **Crusty plate**, see page 11 to 12.  
**Purpose** : The crusty plate when using auto crusty cook function or manual crusty cook function.



6. **Clean Water Bowl**, see page 8.  
**Purpose** : The water bowl can be used to clean.



**DO NOT** operate the microwave oven without the roller ring and turntable.

## Using this Instruction Booklet

You have just purchased a SAMSUNG microwave oven. Your Owner's Instructions contain much valuable information on cooking with your microwave oven:

- Safety precautions
- Suitable accessories and cookware
- Useful cooking tips

Inside the cover you will find a quick look-up guide explaining four basic cooking operations:

- Cooking food
- Auto Power Defrosting of food
- Grilling food
- Adding extra cooking time

At the front of the booklet you will find illustrations of the oven, and more importantly the control panel, so that you can find the buttons more easily.

The step-by-step procedures use two different symbols.



Important



Note

### PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

- Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.
- Do not place any object between the oven door and front face or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use first with a damp cloth and then with a soft dry cloth.
- Do not operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer. It is particularly important that the oven door closes properly and that there is no damage to the:
  - Door (bent)
  - Door hinges (broken or loose)
  - door seals and sealing surfaces
- The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

## Safety Precautions

### IMPORTANT SAFETY INSTRUCTIONS.

#### READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

Before cooking food or liquids in your microwave oven, please check that the following safety precautions are taken.

- Only use utensils that are suitable for use in microwave ovens; **DO NOT** use any metallic containers, Dinnerware with gold or silver trimmings, Skewers, forks, etc.  
Remove wire twist ties from paper or plastic bags.

**Reason:** Electric arcing or sparking may occur and may damage the oven.

- When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition;  
Do not use your microwave oven to dry papers or clothes.
- Small amounts of food require shorter cooking or heating time.  
If normal times are allowed they may overheat and burn.
- If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames;
- Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container; To prevent this situation  
**ALWAYS** allow a standing time of at least 20 seconds after the oven has been switched off so that the temperature can equalize.  
Stir during heating, if necessary, and **ALWAYS** stir after heating.  
In the event of scalding, follow these **FIRST AID** instructions:
  - \* Immerse the scalded area in cold water for at least 10 minutes.
  - \* Cover with a clean, dry dressing.
  - \* Do not apply any creams, oils or lotions.
- **NEVER** fill the container to the top and choose a container that is wider at the top than at the bottom to prevent the liquid from boiling over. Bottles with narrow necks may also explode if overheated.  
**NEVER** heat a baby's bottle with the teat on, as the bottle may explode if overheated.
- The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns;
- Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended;  
Also do not heat airtight or vacuum-sealed bottles, jars, containers, nuts in shells, tomatoes etc.
- The oven should be cleaned regularly and any food deposits removed;
- Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation;
- **DO NOT** cover the ventilation slots with cloths or paper. They may catch fire as hot air is evacuated from the oven.  
The oven may overheat and automatically switch itself off. It will remain inoperable until it has cooled sufficiently.
- **ALWAYS** use oven gloves when removing a dish from the oven to avoid unintentional burn.

## Safety Precautions (continued)

- **DO NOT** touch heating elements or interior oven walls until the oven be cooled down.
  - Do not immerse the power cable or plug in water and keep the power cable away from heated surfaces.  
Do not operate this appliance if it has a damaged power cable or plug.
  - Stand at arms length from the oven when opening the door.
- Reason:** The hot air or steam released may cause scalding.
- You may notice a Clicking sound during operation (especially when the oven is defrosting).

**Reason:** This sound is normal when the electrical power output is changing.

- **DO NOT** operate the microwave oven when it is empty. The power will be cut off automatically for safety. You can operate normally after letting it stand for over 30 minutes.  
It is best to leave a glass of water inside the oven at all times. The water will absorb the microwaves energy if the oven accidentally started.
- The microwave oven shall not be placed in a cabinet.

### IMPORTANT

- Young children should **NEVER** be allowed to use or play with the microwave oven. Nor should they be left unattended near the microwave oven when it is in use. Items of interest to children should not be stored or hidden just above the oven.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
- **DO NOT** use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass. (If provided)

### WARNING:

If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

### WARNING:

It is hazardous for anyone other than a competent person to carry out any service or repair operation which involves the removal of a cover which gives protection against exposure to microwave energy.

### WARNING:

Liquids and other foods must not be heated in sealed containers since they are liable to explode.

### WARNING:

Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.

### WARNING:

When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated.



### WARNING:

Accessible parts may become hot during use. Young children should be kept away.

- For safety reasons do not clean the appliance with a steam jet or high pressure cleaner.

## Installing Your Microwave Oven

*Place the oven on a flat level surface 85cm above the floor. The surface should be strong enough to safely bear the weight of the oven.*



1. When you install your oven, make sure there is adequate ventilation for your oven by leaving at least 10 cm (4 inches) of space behind and, on the sides of the oven and 20 cm (8 inches) of space above.
2. Remove all packing materials inside the oven. Install the roller ring and turntable. Check that the turntable rotates freely.
3. This microwave oven has to be positioned so that plug is accessible.



If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent. For your personal safety, plug the cable into a 3-pin, 230 Volt, 50Hz, AC earthed socket. If the power cable of this appliance is damaged, it must be replaced by a special cable.




Do not install the microwave oven in hot or damp surroundings like next to a traditional oven or radiator. The power supply specifications of the oven must be respected and any extension cable used must be of the same standard as the power cable supplied with the oven. Wipe the interior and the door seal with a damp cloth before using your microwave oven for the first time.

## Setting the Time

Your microwave oven has an inbuilt clock. The time can be displayed in either the 24-hour or 12-hour notation. You must set the clock:

- When you first install your microwave oven
  - After a power failure
- ✕ Do not forget to reset the clock when you switch to and from summer and winter time.



1. To display the time in the...


Then press the  button...


24-hour notation  
12-hour notation

Once  
Twice




2. Press the ( - ) and ( + ) buttons to set the hour.



3. Press the  button.





4. Press the ( - ) and ( + ) buttons to set the minute.



5. Press the  button.

## What to Do if You are in Doubt or Have a Problem

If you have any of the problems listed below try the solutions given.

- ◆ This is normal.
    - Condensation inside the oven
    - Air flow around the door and outer casing
    - Light reflection around the door and outer casing
    - Steam escaping from around the door or vents
  - ◆ The oven does not start when you press the  button.
    - Is the door completely closed?
  - ◆ The food is not cooked at all
    - Have you set the timer correctly and/or pressed the  button?
    - Is the door closed?
    - Have you overloaded the electric circuit and caused a fuse to blow or a breaker to be triggered?
  - ◆ The food is either overcooked or undercooked
    - Was the appropriate cooking length set for the type of food?
    - Was an appropriate power level chosen?
  - ◆ Sparking and cracking occur inside the oven (arcing)
    - Have you used a dish with metal trimmings?
    - Have you left a fork or other metal utensil inside the oven?
    - Is aluminium foil too close to the inside walls?
  - ◆ The oven causes interference with radios or televisions
    - Slight interference may be observed on televisions or radios when the oven is operating. This is normal. To solve this problem, install the oven away from televisions, radios and aerials.
    - If interference is detected by the oven's microprocessor, the display may be reset. To solve this problem, disconnect the power plug and reconnect it. Reset the time.
- ✕ If the above guidelines do not enable you to solve the problem, contact your local dealer or SAMSUNG after-sales service.

## Cooking / Reheating

The following procedure explains how to cook or reheat food.

**ALWAYS** check your cooking settings before leaving the oven unattended.

First, place the food in the centre of the turntable. Then, close the door



1. Press the button.

**Result:** The 850W (maximum cooking power) indications are displayed:  
Select the appropriate power level by pressing the button again until the corresponding wattage is displayed. Refer to the power level table.



2. Set the cooking time by Pressing the ( - ) and ( + ) buttons as required.



3. Press the button.

**Result:** The oven light comes on and the turntable starts rotating.

- 1) Cooking starts and when it has finished the oven beeps four times.
- 2) The end reminder signal will beep 3 times(once every minute).
- 3) The current time is displayed again.



**Never** switch the microwave oven on when it is empty.



If you wish to heat a dish for a short period of time at maximum power(850W), simply press the **+30s** button once for each 30 seconds of cooking time. The oven starts immediately.

## Power Levels

You can choose among the power levels below.

| Power Level     | Output |        |
|-----------------|--------|--------|
|                 | MWO    | GRILL  |
| HIGH            | 850 W  |        |
| MEDIUM HIGH     | 600 W  |        |
| MEDIUM          | 450 W  |        |
| MEDIUM LOW      | 300 W  |        |
| DEFROST         | 180 W  |        |
| LOW / KEEP WARM | 100 W  |        |
| GRILL           | -      | 1100 W |
| COMBI I         | 600 W  | 1100 W |
| COMBI II        | 450 W  | 1100 W |
| COMBI III       | 300 W  | 1100 W |




If you select higher power level, the cooking time must be decreased.



If you select lower power level, the cooking time must be increased.

## Stopping the Cooking


You can stop cooking at any time to check the food.



1. To stop temporarily;  
Open the door.  
**Result :** Cooking stops. To resume cooking, close the door and press  $\diamond$  again.




2. To stop completely;  
Press the  $\odot$  button  
**Result :** The cooking stops. If you wish to cancel the cooking settings, press the **Cancel** ( $\odot$ ) button again.

 You can also cancel any setting before starting by simply pressing **Cancel** ( $\odot$ ).

## Adjusting the Cooking Time



You can increase the cooking time by pressing the +30s button once for each 30 seconds to be added.




Press the **+30s** button once for each 30 seconds to be added.


## Using the Steam Cleaning

The steam provided by steam clean system will soak the cavity surface. After using steam clean function, you can easily clean the cavity of oven.


-  use this function only after the oven has completely cooled. (Room temperature)
-  Use normal water only, and no distilled water.



1. Open the Door.



2. Fill with water following guide line (water level) outside the water bowl.  
(The line is about 50ml.)




3. Insert water bowl into upper water bowl holder on the right wall of cooking chamber.


4. Close the door.



5. Press the **Steam clean** ( $\text{☾}^+$ ) button.  
It can be seen **MISTY** during steam cleaning, but it is not a defect **BUT STEAM SHIELDS THE light INSIDE.**



6. Open the Door.



7. Please clean cavity of oven with dried dishtowel. Remove the turntable and only under rack with kitchen paper.


### Warning!


- Water Bowl only can be use during **"Steam Clean"** mode.
- When cooking non-liquid items, remove water bowl because it will damage and cause fire to the microwave oven.


## Using the Auto Reheat Feature

The Auto Reheat feature has four pre-programmed cooking time. You do not need to set either the cooking times or the power level. You can adjust the number of servings by pressing the (–) and (+) buttons.

First, place the food in the centre of the turntable and close the door.




1. Select the type of food that you are cooking by pressing the **Auto Reheat** () button once or more times.



2. Select the size of the serving by pressing the (–) and (+) buttons. (Refer to the table on the side.)







3. Press the  button.  
**Result:** Cooking starts. When it has finished.  
1) The oven beeps four times.  
2) The end reminder signal will beep 3 times (once every minute).  
3) The current time is displayed again.



Use only recipients that are microwave-safe.

## Auto Reheat Settings


The following table presents the various Auto Reheat Programmes, quantities, standing times and appropriate recommendations.

| Code/Food   | Portion                                | Standing Time | Recommendations  |
|---|--|---------------|--|
| 1. <br><b>Ready Meal</b><br>(Chilled)                                      | 300-350 g<br>400-450 g                 | 3 min.        | Put on a ceramic plate and cover with microwave cling film. This programme is suitable for meals consisting of 3 components (e.g. meat with sauce, vegetables and a side dish like potatoes, rice or pasta).                                 |
| 2. <br><b>Soup/Sauce</b><br>(Chilled)                                      | 200-250 g<br>300-350 g<br>400-450 g    | 3 min.        | Pour the soup/sauce into a deep ceramic soup plate or bowl. Cover during heating and standing time. Stir before and after standing time.   |
| 3. <br><b>Pasta Gratin</b><br>(frozen)                                     | 200 g<br>400 g                         | 3 min.        | Put the frozen pasta gratin into a suitable sized glass pyrex dish. Put the dish on the rack.<br>This programme is suitable for frozen pasta geatin such as lasagne, cannelloni or macaroni.   |
| 4. <br><b>Drinks</b><br>Coffee, milk,<br>tea, water (room-<br>temperature) | 150 ml<br>(1 cup)<br>250 ml<br>(1 mug) | 1-2 min.      | Pour into a ceramic cup (150 ml) or mug (250 ml) and place in the centre of turntable.<br>Reheat uncovered.<br>Stir carefully before and after standing time.<br>Be careful while taking the cups out (see safety instructions for liquids). |


## Using the Auto Power Defrost Feature

The Auto power Defrost feature enables you to defrost meat, poultry, fish and Bread Cake. The defrost time and power level are set automatically.


You simply select the programme and the weight.

 Use only dishes that are microwave-safe.


First, place the frozen food in the centre of the turntable and close the door.





1. Select the type of food that you are cooking by pressing the **Power Defrost** (Power) button one or more times. (Refer to the table on the side)




2. Select the food weight by pressing the (–) and (+) buttons. It is possible to set up to a maximum of 1500g



3. Press the  button.  
**Result:**





- ◆ Defrosting begins.
- ◆ The oven beeps half way through defrosting to remind you to turn the food over.
- ◆ Press  button again to finish defrosting.


 You can also defrost food manually. To do so, select the microwave cooking/reheating function with a power level of 180W. Refer to the section entitled “Cooking/Reheating” on page 7 for further details.

## Auto Power Defrost Settings

The following table presents the various Auto Power Defrost programmes, quantities, standing times and appropriate recommendations.

Remove all kinds of package material before defrosting. Place meat, poultry, fish and Bread Cake on a ceramic plate.

| Code/<br>Food  | Portion      | Standing<br>Time | Recommendations   |
|--|--------------|------------------|---|
| 1. <br><b>Meat</b>            | 200 - 1500 g | 20-60 min.       | Shield the edges with aluminium foil. Turn the meat over when the oven beeps. This programme is suitable for beef, lamb, pork, steaks, chops and minced meat.   |
| 2. <br><b>Poultry</b>         | 200 - 1500 g | 20-60 min.       | Shield the leg and wing tips with aluminium foil. Turn the poultry over when the oven beeps. This programme is suitable for whole chicken and chicken portions.   |
| 3. <br><b>Fish</b>            | 200 - 1500 g | 20-50 min.       | Shield the tail of the whole fish with aluminium foil. Turn the fish over when the oven beeps. This programme is suitable for whole fishes and fish fillets.  |
| 4. <br><b>Bread/<br/>Cake</b> | 125 - 625 g  | 5-20 min.        | Put bread on a piece of kitchen paper and turn over, as soon as the oven beeps. Place cake on a ceramic plate and if possible, turn over, as soon as the oven beeps. (Oven keeps operating and is stopped, when you open the door. This programme is suitable for all kinds of bread, sliced or whole, as well as for bread rolls and baguettes. Arrange bread rolls in a circle. This programme is suitable for all kinds of yeast cake, biscuit, cheese cake and puff pastry. It is not, suitable for short/crust pastry, fruit and cream cakes as well as for cake with chocolate topping. |


 Select the Manual Defrosting function with a power level of 180 W if you want to defrost food manually. For further details on manual defrosting and defrosting time, refer to the page 19.

## Using the Auto Crusty Cook Function


With the Auto Crusty Cook feature, the cooking time is set automatically.

You can adjust the number of servings by pressing the (–) and (+) buttons.


First, place the crusty plate in the centre of the turntable and close the door.



- Place the crusty plate directly on the turntable and preheat it with highest Microwave-Grill-Combination. By pressing the **Combi** (🔥🌀) button and set the preheat time (3 to 5 minutes) by pressing the (–) and (+) buttons.



- Press the button.  
 Always use oven gloves to take out the crusty plate, as will become very hot.



- Open the oven door.  
Place the food on the crusty plate.  
Close the door.  
 Place the crusty plate on the metal rack (or turntable) in the microwave.



- Select the type of food that you are cooking by pressing the **Crusty Cook** (🍷) button once or more times.



- Select the size of the serving by pressing the (–) and (+) buttons.  
(Refer to the table on the side)



- Press the button.  
Result : Cooking starts. When it has finished:
  - The oven beeps four times.
  - The end reminder signal will beep 3 times (once every minute)
  - The current time is displayed again.



### How to clean the Crusty Plate

Clean the crusty plate with warm water and detergent and rinse off with clean water.



Do not use a scrubbing brush or a hard sponge otherwise the top layer will be damaged.



### Please Note

The crusty plate is not dishwasher-safe.

The following table presents the various Auto Programmes of the Crisp function, quantities, standing times and appropriate recommendations. These Programmes are running with a combination of microwaves and grill.


Before using the Crisp function, we recommend to preheat the crusty plate on the turntable for 3 to 5 minutes, using a combination of 600W and grill. Use oven gloves while taking out!

| Code / Food (-18°C)              | Serving Size                  | Preheating Time | Standing Time | Recommendations  |
|----------------------------------|-------------------------------|-----------------|---------------|--|
| 1. <b>Frozen Pizza</b>           | 200 g<br>300 g<br>400 g       | 5 min.          | -             | Preheat the crusty plate using 600W + grill.<br>Put pizza on crusty plate. Put crusty plate on rack.   |
| 2. <b>Frozen Baguettes</b>       | 150 g (1pc)<br>250 g (2pcs)   | 4 min.          | 2-3           | Preheat the crusty plate using 450W + grill.<br>Put one baguette off-center on crusty plate, put 2 baguettes side by side on the crusty plate. This programme is suitable for baguettes with topping, (e.g. vegetables, ham and cheese) as well as pizza snacks. |
| 3. <b>Frozen Quiche / Pie</b>    | 150 g (1pc)<br>300 g (1-2pcs) | 3 min.          | 1-2           | Preheat the crusty plate using 600W + grill.<br>Put frozen quiche/ pie on crusty plate.<br>Put crusty plate on rack.   |
| 4. <b>Frozen Chicken Nuggets</b> | 125 g<br>250 g                | 4 min.          | -             | Preheat the crusty plate using 600W + grill.<br>Brush crusty plate with one tbsp. oil. Distribute chicken nuggets evenly on crusty plate. Turn over when the oven beeps. Push start button to continue cooking.  |

## Using the Manual Crusty Cook Function


This crusty plate allows you to brown food not only on the top with the grill, but also the bottom of the food turns crispy and brown due to the high temperature of the crusty plate. Several items which you can prepare on the crusty plate can be found in the chart (see next page).

The crusty plate can also be used for bacon, eggs, sausages, etc.




- Place the crusty plate directly on the turntable and preheat it with highest Microwave-Grill-Combination [600W+Grill( )] by following the times and instructions in the chart.

- ☝ Always use oven gloves to take out the crusty plate, as will become very hot.
- 2. Brush the plate with oil if you are cooking food, such as bacon and eggs, in order to brown the food nicely.
- \* Please note that the crusty plate has a teflon layer which is not scratch-resistant. Do not use any sharp objects like a knife to cut on the crusty plate.
- \* Use plastic accessories to avoid scratches on the surface of the crusty plate or remove the food from the plate before cutting.



- Place the food on the crusty plate.
  - ☝ Do not place any objects on the crusty plate that are not heat-resistant; e.g. plastic bowls.
  - ☝ Never place the crusty plate in the oven without turntable.



- Place the crusty plate on the metal rack(or turntable) in the microwave.

- Select the appropriate cooking time and power. Refer to the table on the next page.



### How to clean the Crusty Plate

Clean the crusty plate with warm water and detergent and rinse off with clean water.



Do not use a scrubbing brush or a hard sponge otherwise the top layer will be damaged.



### Please Note

The crusty plate is not dishwasher-safe.

We recommend to preheat the crusty plate directly on the turntable.

Preheat the crusty plate with 600 W + Grill( )function and follow the times and instructions in the table.


| Food                         | Portion                         | Preheating Time | Power       | Cooking Time        | Recommendations   |
|------------------------------|---------------------------------|-----------------|-------------|---------------------|---|
| <b>Bacon</b>                 | 4 Slices (80g)                  | 3 min           | 600W+ Grill | 3½-4 min            | Preheat crusty plate. Put slices side by side on crusty plate. Put crusty plate on the rack.  |
| <b>Grilled Tomatoes</b>      | 200 g (2pcs)                    | 3 min           | 450W+ Grill | 4½-5 min            | Preheat crusty plate. Cut tomatoes in halves. Put some cheese on top. Arrange in a circle on crusty plate. Put crusty plate on the rack.                    |
| <b>Burger (frozen)</b>       | 2 pieces (125g)                 | 3 min           | 600W+ Grill | 7-7½ min            | Preheat crusty plate. Put frozen burger in a circle on crusty plate. Put crusty plate on the rack. Turn over after 4- 5 min.                                |
| <b>Baked Potatoes</b>        | 250 g<br>500 g                  | 3 min           | 600W+ Grill | 5-6 min<br>8-9 min  | Preheat crusty plate. Cut potatoes in halves. Put them on the crusty plate with the cut side to the bottom. Arrange in a circle. Put the plate on the rack. |
| <b>Fish Fingers (frozen)</b> | 150 g (5 pcs)<br>300 g (10 pcs) | 4 min           | 600W+ Grill | 7-8 min<br>9-10 min | Preheat crusty plate. Brush plate with 1 tbsp. oil. Put fish fingers in a circle on the plate. Turn over after 4 min (5 pcs) or after 6 min (10 pcs).       |
| <b>Pizza (chilled)</b>       | 300-350 g                       | 4 min           | 450W+ Grill | 6½-7½ min           | Preheat crusty plate. Put the chilled pizza on the plate. Put crusty plate on rack.   |

## Choosing the Heating Element Position

The heating element is used when grilling. There is only one position listed. We need to tell consumers when it should be placed in the vertical position.

- **Horizontal position for grilling or combined microwave + grill cooking**

☞ Only change the position of the heating element when it is cold and do not apply excessive force when placing it in the vertical position.




**To set the heating element to the...**

Horizontal position (grill or combined microwave + grill)

**Then...**


- ◆ Pull the heating element towards you
- ◆ Push it upwards until it is parallel with the roof of the oven



When cleaning the upper part inside the cavity, it will be convenient to turn heater downward by 45° and clean it.

## Choosing the Accessories

Use microwave-safe recipients; do not use plastic containers, dishes, paper cups, towels, etc.



If you wish to select the combined cooking mode (grill and microwave), use only dishes that are microwave-safe and oven-proof. Metallic cookware or utensils may damage your oven.

☒ For further details on suitable cookware and utensils, refer to the Cookware Guide on page 15.

## Grilling

The grill enables you to heat and brown food quickly, without using microwaves. To this aim, a grill rack is supplied with your microwave oven.


EN



1. Preheat the grill to the required temperature, by pressing the **Grill**(U) button and set the preheat time by pressing the (–) and (+) buttons.



2. Press the ◊ button.



3. Open the door and place the food on the rack. Close the door.



4. Press the U button.  
**Result:** The following indications are displayed:



5. Set the Grilling time by pressing the (–) and (+) buttons. The maximum grilling time is 60 minutes.



6. Press the ◊ button.  
**Result:** Grilling cooking start. When it has finished
  - 1) The oven beeps four times.
  - 2) The end reminder signal will beep 3 times (once every minute).
  - 3) The current time is displayed again.


☒ Do not worry if the heater turns off and on while grilling. This system is designed to prevent overheating of the oven.

☞ Always use oven gloves when touching the dishes in the oven, as they will be very hot. Check that the heating element is in the horizontal position.


## Combining Microwave and the Grill

**You can also combine microwave cooking with the grill, to cook quickly and brown at the same time.**

- ALWAYS use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.
- ALWAYS use oven gloves when touching the recipients in the oven, as they will be very hot.



1. Make sure that the heating element is in the horizontal position; refer to page 13 for further details.



2. Open the oven door. Place the food on the rack and the rack on the turntable. Close the door.




3. Press the **Combi** (微波) button.  
Result : The following indications are displayed:  
微波 (microwave and grill mode)  
600W (out power)

- Select the appropriate power level by pressing the **Combi** (微波) button again until the corresponding power level is displayed.

You cannot set the temperature of the grill.



4. Set the cooking time by pressing the (–) and (+) buttons as required.  
The maximum cooking time is 60 minutes.




5. Press the  $\diamond$  button.  
Result : Combination cooking starts. When it has finished
  - 1) The oven beeps four times.
  - 2) The end reminder signal will beep 3 times (once every minute).
  - 3) The current time is displayed again.

- The maximum microwave power for the combined microwave and grill mode is 600W.

## Switching the Beeper Off

**You can switch the beeper off whenever you want.**



1. Press the  $\odot$  and  $\diamond$  buttons at the same time.

Result :

- The following indication is displayed.

OFF

- The oven does not beep each time you press a button.

2. To switch the beeper back on, press the  $\odot$  and  $\diamond$  buttons again at the same time.

Result :

- The following indication is displayed.

07

- The oven operates with the beeper on again.

## Using the Child Lock Feature

**Your microwave oven is fitted with a special Child Lock programme, which enables the oven to be “locked” so that children or anyone unfamiliar with it cannot operate it accidentally.**

**The oven can be locked at any time.**



1. Press the **Child Lock**( $\square$ ) button for one second.

Result :

- The oven is locked (no functions can be selected).

- The display shows “L”.

L



2. To unlock the oven, press the **Child Lock**( $\square$ ) button for one second.

Result : The oven can be used normally.

## Cookware Guide

To cook food in the microwave oven, the microwaves must be able to penetrate the food, without being reflected or absorbed by the dish used.

Care must therefore be taken when choosing the cookware. If the cookware is marked microwave-safe, you do not need to worry.

The following table lists various types of cookware and indicates whether and how they should be used in a microwave oven.

| Cookware                                     | Microwave-Safe | Comments  |
|--|----------------|---|
| <b>Aluminium foil</b>                        | ✓ X            | Can be used in small quantities to protect areas against overcooking. Arcing can occur if the foil is too close to the oven wall or if too much foil is used. |
| <b>Browning plate</b>                        | ✓              | Do not preheat for more than eight minutes.   |
| <b>China and earthenware</b>                 | ✓              | Porcelain, pottery, glazed earthenware and bone china are usually suitable, unless decorated with a metal trim.   |
| <b>Disposable polyester cardboard dishes</b> | ✓              | Some frozen foods are packaged in these dishes.   |
| <b>Fast-food packaging</b>                   |                |   |
| • Polystyrene cups containers                | ✓              | Can be used to warm food. Overheating may cause the polystyrene to melt.  |
| • Paper bags or newspaper                    | X              | May catch fire.   |
| • Recycled paper or metal trims              | X              | May cause arcing.   |
| <b>Glassware</b>                             |                |   |
| • Oven-to-table ware                         | ✓              | Can be used, unless decorated with a metal trim.  |
| • Fine glassware                             | ✓              | Can be used to warm foods or liquids. Delicate glass may break or crack if heated suddenly.   |
| • Glass jars                                 | ✓              | Must remove the lid. Suitable for warming only.   |
| <b>Metal</b>                                 |                |   |
| • Dishes                                     | X              | May cause arcing or fire.   |
| • Freezer bag twist ties                     | X              |   |

|   |     |  |  |
|---|-----|--|--|
| <b>Paper</b>                              |     |  |  |
| • Plates, cups, napkins and Kitchen paper | ✓   |  | For short cooking times and warming. Also to absorb excess moisture.   |
| • Recycled paper                          | X   |  | May cause arcing.  |
| <b>Plastic</b>                            |     |  |  |
| • Containers                              | ✓   |  | Particularly if heat-resistant thermoplastic. Some other plastics may warp or discolour at high temperatures. Do not use Melamine plastic. |
| • Cling film                              | ✓   |  | Can be used to retain moisture. Should not touch the food. Take care when removing the film as hot steam will escape.                      |
| • Freezer bags                            | ✓ X |  | Only if boilable or oven-proof. Should not be airtight. Prick with a fork, if necessary.   |
| <b>Wax or grease-proof paper</b>          | ✓   |  | Can be used to retain moisture and prevent spattering.   |

✓ :Recommended

✓X:Use Caution

X :Unsafe

# Cooking Guide

## MICROWAVES

Microwave energy actually penetrates food, attracted and absorbed by its water, fat and sugar content.

The microwaves cause the molecules in the food to move rapidly. The rapid movement of these molecules creates friction and the resulting heat cooks the food.

### COOKING

#### Cookware for microwave cooking:

Cookware must allow microwave energy to pass through it for maximum efficiency. Microwaves are reflected by metal, such as stainless steel, aluminium and copper, but they can penetrate through ceramic, glass, porcelain and plastic as well as paper and wood. So food must never be cooked in metal containers.

#### Food suitable for microwave cooking:

Many kinds of food are suitable for microwave cooking, including fresh or frozen vegetables, fruit, pasta, rice, grains, beans, fish, and meat. Sauces, custard, soups, steamed puddings, preserves, and chutneys can also be cooked in a microwave oven. Generally speaking, microwave cooking is ideal for any food that would normally be prepared on a hob. Melting butter or chocolate, for example (see the chapter with tips, techniques and hints).

#### Covering during cooking

To cover the food during cooking is very important, as the evaporated water rises as steam and contributes to cooking process. Food can be covered in different ways: e.g. with a ceramic plate, plastic cover or microwave suitable cling film.

#### Standing times

After cooking is over, standing time for the food is important to allow the temperature to even out within the food.

#### Cooking Guide for frozen vegetables

Use a suitable glass pyrex bowl with lid. Cook covered for the minimum time - see table. Continue cooking to get the result you prefer. Stir twice during cooking and once after cooking. Add salt, herbs or butter after cooking. Cover during standing time.

| Food        | Portion | Power | Time (min.) | Standing Time(min.) | Instructions                         |
|-------------|---------|-------|-------------|---------------------|--------------------------------------|
| Spinach     | 150g    | 600W  | 4½-5½       | 2-3                 | Add 15 ml (1 tablespoon) cold water. |
| Broccoli    | 300g    | 600W  | 9-10        | 2-3                 | Add 30 ml (2 tbsp.) cold water.      |
| Peas        | 300g    | 600W  | 7½-8½       | 2-3                 | Add 15 ml (1 tbsp.) cold water.      |
| Green Beans | 300g    | 600W  | 8-9         | 2-3                 | Add 30 ml (2 tbsp.) cold water.      |

| Food                                 | Portion | Power | Time (min.) | Standing Time(min.) | Instructions                    |
|--------------------------------------|---------|-------|-------------|---------------------|---------------------------------|
| Mixed Vegetables (carrots/peas/corn) | 300g    | 600W  | 7½-8½       | 2-3                 | Add 15 ml (1 tbsp.) cold water. |
| Mixed Vegetables (Chinese style)     | 300g    | 600W  | 8-9         | 2-3                 | Add 15 ml (1 tbsp.) cold water. |

#### Cooking Guide for rice and pasta

**Rice:** Use a large glass pyrex bowl with lid - rice doubles in volume during cooking. Cook covered. After the cooking time is over, stir before standing time and add salt or add herbs and butter. Remark: the rice may not have absorbed all water after the cooking time is finished.

**Pasta:** Use a large glass pyrex bowl. Add boiling water, a pinch of salt and stir well. Cook uncovered. Stir occasionally during and after cooking. Cover during standing time and drain thoroughly afterwards.

| Food                          | Portion | Power | Time (min.) | Standing Time(min.) | Instructions           |
|-------------------------------|---------|-------|-------------|---------------------|------------------------|
| White Rice (parboiled)        | 250g    | 850W  | 16-17       | 5                   | Add 500 ml cold water. |
| Brown Rice (parboiled)        | 250g    | 850W  | 21-22       | 5                   | Add 500 ml cold water. |
| Mixed Rice (rice + wild rice) | 250g    | 850W  | 17-18       | 5                   | Add 500 ml cold water. |
| Mixed Corn (rice + grain)     | 250g    | 850W  | 18-19       | 5                   | Add 400 ml cold water. |
| Pasta                         | 250g    | 850W  | 11-12       | 5                   | Add 1000 ml hot water. |

## Cooking Guide(continued)

### Cooking Guide for fresh vegetables

Use a suitable glass pyrex bowl with lid. Add 30-45 ml cold water (2-3 tbsp.) for every 250 g unless another water quantity is recommended - see table. Cook covered for the minimum time - see table. Continue cooking to get the result you prefer. Stir once during and once after cooking. Add salt, herbs or butter after cooking. Cover during a standing time of 3 minutes.

Hint: Cut the fresh vegetables into even sized pieces. The smaller they are cut, the quicker they will cook.

All fresh vegetables should be cooked using full microwave power (850 W).

| Food             | Portion      | Time (min.)  | Standing Time (min.) | Instructions  |
|------------------|--------------|--------------|----------------------|---|
| Broccoli         | 250g<br>500g | 4-4½<br>8-8½ | 3                    | Prepare even sized florets. Arrange the stems to the centre.  |
| Brussels Sprouts | 250g         | 5½-6½        | 3                    | Add 60-75 ml (5-6 tbsp.) water.   |
| Carrots          | 250g         | 4½-5         | 3                    | Cut carrots into even sized slices.   |
| Cauliflower      | 250g<br>500g | 5-5½<br>8½-9 | 3                    | Prepare even sized florets. Cut big florets into halves. Arrange stems to the centre.   |
| Courgettes       | 250g         | 3½-4         | 3                    | Cut courgettes into slices. Add 30 ml (2 tbsp.) water or a knob of butter. Cook until just tender.  |
| Egg Plants       | 250g         | 3½-4         | 3                    | Cut egg plants into small slices and sprinkle with 1 tablespoon lemon juice.  |
| Leeks            | 250g         | 4½-5         | 3                    | Cut leeks into thick slices.  |
| Mushrooms        | 125g<br>250g | 1½-2<br>3-3½ | 3                    | Prepare small whole or sliced mushrooms. Do not add any water. Sprinkle with lemon juice. Spice with salt and pepper. Drain before serving. |
| Onions           | 250g         | 5½-6         | 3                    | Cut onions into slices or halves. Add only 15 ml (1 tbsp.) water.   |
| Pepper           | 250g         | 4½-5         | 3                    | Cut pepper into small slices.   |
| Potatoes         | 250g<br>500g | 4-5<br>7½-8½ | 3                    | Weigh the peeled potatoes and cut them into similar sized halves or quarters.   |
| Turnip Cabbage   | 250g         | 5-5½         | 3                    | Cut turnip cabbage into small cubes.  |

### REHEATING

Your microwave oven will reheat food in a fraction of the time that conventional ovens hobs normally take.

Use the power levels and reheating times in the following chart as a guide. The times in the chart consider liquids with a room temperature of about +18 to +20°C or a chilled food with a temperature of about +5 to +7°C.

#### Arranging and covering

Avoid reheating large items such as joint of meat - they tend to overcook and dry out before the centre is piping hot. Reheating small pieces will be more successful.

#### Power levels and stirring

- Some foods can be reheated using 850 W power while others should be reheated using 600 W, 450 W or even 300 W.

Check the tables for guidance. In general, it is better to reheat food using a lower power level, if the food is delicate, in large quantities, or if it is likely to heat up very quickly (mince pies, for example).

Stir well or turn food over during reheating for best results. When possible, stir again before serving.

Take particular care when heating liquids and baby foods. To prevent eruptive boiling of liquids and possible scalding, stir before, during and after heating. Keep them in the microwave oven during standing time. We recommend putting a plastic spoon or glass stick into the liquids. Avoid overheating (and therefore spoiling) the food.

It is preferable to underestimate cooking time and add extra heating time, if necessary.

- Heating and standing times**

When reheating food for the first time, it is helpful to make a note of the time taken for future reference.

Always make sure that the reheated food is piping hot throughout.

Allow food to stand for a short time after reheating - to let the temperature even out.

The recommended standing time after reheating is 2-4 minutes, unless another time is recommended in the chart.

Take particular care when heating liquids and baby food. See also the chapter with the safety precautions.

### REHEATING LIQUIDS

- Always allow a standing time of at least 20 seconds after the oven has been switched off to allow the temperature to even out. Stir during heating, if necessary, and ALWAYS stir after heating. To prevent eruptive boiling and possible scalding, you should put a spoon or glass stick into the beverages and stir before, during and after heating.

## Cooking Guide(continued)

EN

### REHEATING BABY FOOD

#### BABY FOOD:

Empty into a deep ceramic plate. Cover with plastic lid. Stir well after reheating! Let stand for 2-3 minutes before serving. Stir again and check the temperature. Recommended serving temperature: between 30-40°C.

#### BABY MILK:

Pour milk into a sterilised glass bottle. Reheat uncovered. Never heat a baby's bottle with teat on, as the bottle may explode if overheated. Shake well before standing time and again before serving ! Always carefully check the temperature of baby milk or food before giving it to the baby. Recommended serving temperature: about 37°C.

#### REMARK:

Baby food particularly needs to be checked carefully before serving to prevent burns.

Use the power levels and times in the next table as a guide lines for reheating.

#### Reheating Baby Food and Milk

Use the power levels and times in this table as guide lines for reheating.

| Food                                 | Portion        | Power | Time                         | Standing Time (min.) | Instructions  |
|--------------------------------------|----------------|-------|------------------------------|----------------------|---|
| Baby food (vegetables + meat)        | 190g           | 600W  | 30sec.                       | 2-3                  | Empty into ceramic deep plate. Cook covered. Stir after cooking time. Stand for 2-3 minutes. Before serving, stir well and check the temperature carefully.   |
| Baby porridge (grain + milk + fruit) | 190g           | 600W  | 20sec.                       | 2-3                  | Empty into ceramic deep plate. Cook covered. Stir after cooking time. Stand for 2-3 minutes. Before serving, stir well and check the temperature carefully.   |
| Baby milk                            | 100ml<br>200ml | 300W  | 30-40sec.<br>50 sec to 1min. | 2-3                  | Stir or shake well and pour into a sterilised glass bottle. Place into the centre of turn-table. Cook uncovered. Shake well and stand for at least 3 minutes. Before serving, shake well and check the temperature carefully. |

### Reheating Liquids and Food

Use the power levels and times in this table as a guide lines for reheating.

| Food  | Portion                        | Power | Time (min.)    | Standing Time (min.) | Instructions  |
|---|--------------------------------|-------|----------------|----------------------|---|
| Drinks<br>Coffee, milk, tea, water (room-temperature) | 150ml (1 cup)<br>250ml (1 mug) | 850W  | 1-1 ½<br>1½ -2 | 1-2                  | Pour into a ceramic cup (150 ml) or mug (250 ml) and place in the centre of turntable. Reheat uncovered. Stir carefully before and after standing time. Be careful while taking the cups out (see safety instructions for liquids). |
| Soup (chilled)  | 250g                           | 850W  | 3-3½           | 2-3                  | Pour into a deep ceramic plate. Cover with plastic lid. Stir well after reheating. Stir again before serving.   |
| Stew (chilled)  | 350g                           | 600W  | 5 ½ -6 ½       | 2-3                  | Put stew in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving.   |
| Pasta with sauce (chilled)                            | 350g                           | 600W  | 4 ½ -5 ½       | 3                    | Put pasta (e.g. spaghetti or egg noodles) on a flat ceramic plate. Cover with microwave cling film. Stir before serving.  |
| Filled pasta with sauce (chilled)                     | 350g                           | 600W  | 5-6            | 3                    | Put filled pasta (e.g. ravioli, tortellini) in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving.  |
| Plated Meal (chilled)                                 | 350g                           | 600W  | 5 ½ -6 ½       | 3                    | Plate a meal of 2-3 chilled components on a ceramic dish. Cover with microwave cling-film.  |

## Cooking Guide(continued)

### MANUAL DEFROSTING

Microwaves are an excellent way of defrosting frozen food. Microwaves gently defrost frozen food in a short period of time. This can be of great advantage, if unexpected guests suddenly show up.

Frozen poultry must be thoroughly thawed before cooking. Remove any metal ties and take it out of any wrapping to allow thawed liquid to drain away.

Put the frozen food on a dish without cover. Turn over half way, drain off any liquid and remove any giblets as soon as possible.

Check the food occasionally to make sure that it does not feel warm. If smaller and thinner parts of the frozen food start to warm up, they can be shield by wrapping very small strips of aluminium foil around them during defrosting.

Should poultry start to warm up on the outer surface, stop thawing and allow it to stand for 20 minutes before continuing.

Leave the fish, meat and poultry to stand in order to complete defrosting. The standing time for complete defrosting will vary depending on the quantity defrosted. Please refer to the table below.

Hint: Flat food defrosts better than thick and smaller quantities need less time than bigger ones. Remember this hint while freezing and defrosting food.

For defrosting of frozen food with a temperature of about -18 to -20 °C, use the following table as a guide.

All frozen food should be defrosted using defrosting power level (180 W).

| Food                            | Portion         | Time (min.)     | Standing Time (min.) | Instructions   |
|---------------------------------|-----------------|-----------------|----------------------|--|
| Meat                            |                 |                 |                      |  |
| Minced beef                     | 250g            | 6½ -7½          | 5-25                 | Place the meat on a flat ceramic plate. Shield thinner edges with aluminium foil. Turn over after half of defrosting time!   |
| Pork steaks                     | 500g<br>250g    | 13-14<br>7½ -8½ |                      |  |
| Poultry                         |                 |                 |                      |  |
| Chicken pieces                  | 500g<br>(2 pcs) | 14½-15½         | 15-40                | First, put chicken pieces first skin-side down, whole chicken first breast-side-down on a flat ceramic plate. Shield the thinner parts like wings and ends with aluminium foil. Turn over after half of defrosting time! |
| Whole chicken                   | 900g            | 28-30           |                      |  |
| Fish                            |                 |                 |                      |  |
| Fish fillets                    | 200g<br>(2 pcs) | 6-7             | 5-15                 | Put frozen fish in the middle of a flat ceramic plate. Arrange the thinner parts under the thicker parts. Shield narrow ends with aluminium foil. Turn over after half of defrosting time!                               |
|                                 | 400g<br>(4 pcs) | 12-13           |                      |  |
| Fruits                          |                 |                 |                      |  |
| Berries                         | 250g            | 6-7             | 5 - 10               | Distribute fruits on a flat, round glass dish (with a large diameter).   |
| Bread                           |                 |                 |                      |  |
| Bread rolls (each about 50 g)   | 2 pcs           | ½-1             | 5 - 20               | Arrange rolls in a circle or bread horizontally on kitchen paper in the middle of turntable. Turn over after half of defrosting time!  |
|                                 | 4 pcs           | 2-2½            |                      |  |
| Toast/ Sandwich                 | 250g            | 4½-5            |                      |  |
| German bread (wheat+ rye flour) | 500g            | 8-10            |                      |  |

## Cooking Guide(continued)

EN

### GRILL

The grill-heating element is located underneath the ceiling of the cavity. It operates while the door is closed and the turntable is rotating. The turntable's rotation makes the food brown more evenly. Preheating the grill for 4 minutes will make the food brown more quickly.

#### Cookware for grilling:

Should be flameproof and may include metal. Do not use any type of plastic cookware, as it can melt.

#### Food suitable for grilling:

Chops, sausages, steaks, hamburgers, bacon and gammon rashers, thin fish portions, sandwiches and all kinds of toast with toppings.

#### IMPORTANT REMARK:

Whenever the grill only mode is used, make sure that the grill-heating element is under the ceiling in the horizontal position and not on the back-wall in the vertical position. Please remember that food must be placed on the high rack, unless another instruction is recommended.

### MICROWAVE + GRILL

This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed and the turntable is rotating. Due to the rotation of the turntable, the food browns evenly. Three combination modes are available with this model: 600 W + Grill, 450 W + Grill and 300 W + Grill.

#### Cookware for cooking with microwave + grill

Please use cookware that microwaves can pass through. Cookware should be flameproof. Do not use metal cookware with combination mode. Do not use any type of plastic cookware, as it can melt.

#### Food suitable for microwave + grill cooking:

Food suitable for combination mode cooking include all kinds of cooked food which need reheating and browning (e.g. baked pasta), as well as foods which require a short cooking time to brown the top of the food. Also, this mode can be used for thick food portions that benefit from a browned and crispy top (e.g. chicken pieces, turning them over half way through cooking). Please refer to the grill table for further details.

#### IMPORTANT REMARK:

Whenever the combination mode (microwave + grill) is used, make sure that the grill heating element is under the ceiling in the horizontal position and not on the back-wall in the vertical position. The food should be placed on the high rack, unless another instruction is recommended. Otherwise it has to be placed directly on the turntable. Please refer to the instructions in the following chart.

The food must be turned over, if it is to be browned on both sides.

#### Grill Guide for frozen food

Use the power levels and times in this table as guide lines for grilling.

| Fresh Food  | Portion          | Power         | 1. Side Time (min)          | 2. Side Time (min.)      | Instructions  |
|---|------------------|---------------|-----------------------------|--------------------------|---|
| Bread Rolls (each about 50 g)                         | 2 pcs<br>4 pcs   | MW+ Grill     | 300W+ Grill<br>1-1½<br>2-2½ | Grill only<br>1-2<br>1-2 | Arrange rolls in a circle on rack. Grill the second side of the rolls up to the crisp you prefer. Stand for 2-5 minutes.                      |
| Baguettes + topping (tomatos, cheese, ham, mushrooms) | 250-300 g (2pcs) | 450 W + Grill | 8-9                         | --                       | Put 2 frozen baguettes side by side on the rack. After grilling stand for 2-3 minutes.  |
| Gratin (vegetables potatoes)                          | 400 g            | 450 W + Grill | 13-14                       | --                       | Put frozen gratin into a small, round glass pyrex dish. Put the dish on the rack. After cooking stand for 2-3 minutes.                        |
| Pasta (Cannelloni, Macaroni, Lasagne)                 | 400 g            | 600 W + Grill | 14-15                       | --                       | Put frozen pasta into a small flat rectangular glass pyrex dish. Put the dish directly on the turntable. After cooking stand for 2-3 minutes. |
| Chicken Nuggets                                       | 250 g            | 450 W + Grill | 5-5½                        | 3-3½                     | Put chicken nuggets on the rack.  |
| Oven Chips  | 250 g            | 450 W + Grill | 9-11                        | 4-5                      | Put oven chips evenly on baking paper on the rack.  |

## Cooking Guide(continued)

### Grill Guide for fresh food

Preheat the grill with the grill-function for 4 minutes.

Use the power levels and times in this table as guide lines for grilling.

| Fresh Food                                   | Portion                      | Power         | 1. Side Time (min) | 2. Side Time (min.) | Instructions   |
|--|------------------------------|---------------|--------------------|---------------------|--|
| Toast Slices                                 | 4 pcs (each 25g)             | Grill only    | 4-5                | 4½-5½               | Put the toast slices side by side on the rack.   |
| Bread Rolls (already baked)                  | 2-4 pieces                   | Grill only    | 2-3                | 2-3                 | Put bread rolls first with the bottom side up in a circle directly on the turntable.   |
| Grilled Tomatoes                             | 200 g (2pcs)<br>400 g (4pcs) | 300 W + Grill | 3½-4½<br>6-7       | --                  | Cut tomatoes into halves. Put some cheese on top. Arrange in a circle in a flat glass pyrex dish. Place it on the rack.  |
| Toast Hawaii (pineapple, ham, cheese slices) | 2 pcs (300 g)                | 450 W + Grill | 3½-4               | --                  | Toast the bread slices first. Put the toast with topping on the rack. Put 2 toasts opposite directly on the rack. Stand for 2-3 minutes.                                     |
| Baked Potatoes                               | 250 g<br>500 g               | 600 W + Grill | 4½-5½<br>8-9       | --                  | Cut potatoes into halves. Put them in a circle on the rack with the cut side to the grill.   |
| Chicken Pieces                               | 450 - 500 g (2 pcs)          | 300 W + Grill | 8-9                | 9-10                | Prepare chicken pieces with oil and spices. Put them in a circle with the bones to the middle. Put one chicken piece not into the centre of the rack. Stand for 2-3 minutes. |
| Lamb Chops (medium)                          | 400 g (4pcs)                 | Grill only    | 11-13              | 8-9                 | Brush the lamb chops with oil and spices. Lay them in a circle on the rack. After grilling stand for 2-3 minutes.  |

| Fresh Food   | Portion                                       | Power         | 1. Side Time (min) | 2. Side Time (min.) | Instructions  |
|--------------|---|---------------|--------------------|---------------------|---|
| Pork Steaks  | 250 g (2pcs)                                  | MW +Grill     | 300W+ Grill<br>7-8 | Grill only<br>6-7   | Brush the pork steaks with oil and spices. Lay them in a circle on the rack. After grilling stand for 2-3 minutes.  |
| Baked Apples | 1 apple (about 200g)<br>2 apples (about 400g) | 300 W + Grill | 4-4½<br>6-7        | --                  | Core the apples and fill them with raisins and jam. Put some almond slices on top. Put apples on a flat glass pyrex dish. Place the dish directly on the turntable. |

EN

## Cooking Guide(continued)

### SPECIAL HINTS

#### MELTING BUTTER

Put 50 g butter into a small deep glass dish. Cover with plastic lid. Heat for 30-40 seconds using 850 W, until butter is melted.

#### MELTING CHOCOLATE

Put 100 g chocolate into a small deep glass dish. Heat for 3-5 minutes, using 450 W until chocolate is melted. Stir once or twice during melting. Use oven gloves while taking out!

#### MELTING CRYSTALLIZED HONEY

Put 20 g crystallized honey into a small deep glass dish. Heat for 20-30 seconds using 300 W, until honey is melted.

#### MELTING GELATINE

Lay dry gelatine sheets (10 g) for 5 minutes into cold water. Put drained gelatine into a small glass pyrex bowl. Heat for 1 minute using 300 W. Stir after melting.

#### COOKING GLAZE/ICING (FOR CAKE AND GATEAUX)

Mix instant glaze (approximately 14 g) with 40 g sugar and 250 ml cold water. Cook uncovered in a glass pyrex bowl for 3 ½ to 4 ½ minutes using 850 W, until glaze/icing is transparent. Stir twice during cooking.

#### COOKING JAM

Put 600 g fruits (for example mixed berries) in a suitable sized glass pyrex bowl with lid. Add 300 g preserving sugar and stir well. Cook covered for 10-12 minutes using 850 W. Stir several times during cooking. Empty directly into small jam glasses with twist-off lids. Stand on lid for 5 minutes.

#### COOKING PUDDING

Mix pudding powder with sugar and milk (500 ml) by following the manufacturers instructions and stir well. Use a suitable sized glass pyrex bowl with lid. Cook covered for 6 ½ to 7 ½ minutes using 850 W. Stir several times well during cooking.

#### BROWNING ALMOND SLICES

Spread 30 g sliced almonds evenly on a medium sized ceramic plate. Stir several times during browning for 3 ½ to 4 ½ minutes using 600 W. Let it stand for 2-3 minutes in the oven. Use oven gloves while taking out!

## Cleaning Your Microwave Oven

*The following parts of your microwave oven should be cleaned regularly to prevent grease and food particles from building up:*

- *Inside and outside surfaces*
- *Door and door seals*
- *Turntable and Roller rings*


- ☞ ALWAYS ensure that the door seals are clean and the door closes properly.
- ☞ Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the of the appliance and possibly result in a hazardous situation.

1. Clean the outside surfaces with a soft cloth and warm, soapy water. Rinse and dry.
2. Remove any splashes or stains on the inside surfaces or on the roller ring with a soapy cloth. Rinse and dry.
3. To loosen hardened food particles and remove smells, place a cup of diluted lemon juice on the turntable and heat for ten minutes at maximum power.
4. Wash the dishwasher-safe plate whenever necessary.

- ☒ **DO NOT** spill water in the vents. **NEVER** use any abrasive products or chemical solvents. Take particular care when cleaning the door seals to ensure that no particles:

- Accumulate
- Prevent the door from closing correctly

- ☒ **Clean the** microwave oven cavity right after each use with a mild detergent solution, but let the microwave oven cool down before cleaning in order to avoid injury.



When cleaning the upper part inside the cavity, it will be convenient to turn heater downward by 45° and clean it.

## Storing and Repairing Your Microwave Oven

A few simple precautions should be taken when storing or having your microwave oven serviced.

The oven must not be used if the door or door seals are damaged:

- Broken hinge
- Deteriorated seals
- Distorted or bent oven casing

Only a qualified microwave service technician should perform repair


- **NEVER** remove the outer casing from the oven. If the oven is faulty and needs servicing or you are in doubt about its condition:
  - Unplug it from the wall socket
  - Contact the nearest after-sales service centre
- If you wish to store your oven away temporarily, choose a dry, dust-free place.
 

**Reason:** Dust and damp may adversely affect the working parts in the oven.
- This microwave oven is not intended for commercial use.

## Technical Specifications

SAMSUNG strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.

|                               |                        |
|-------------------------------|------------------------|
| <b>Model</b>                  | <b>GE89M / GE89MST</b> |
| <b>Power source</b>           | 230V ~ 50 Hz           |
| <b>Power consumption</b>      |                        |
| Microwave                     | 1300 W                 |
| Grill                         | 1100 W                 |
| Combined mode                 | 2400 W                 |
| <b>Output power</b>           | 100 W/850 W (IEC-705)  |
| <b>Operating frequency</b>    | 2450 MHz               |
| <b>Magnetron</b>              | OM75P(31)              |
| <b>Cooling method</b>         | Cooling fan motor      |
| <b>Dimensions (W x H x D)</b> |                        |
| Outside                       | 489 x 275 x 390 mm     |
| Oven cavity                   | 330 x 211 x 329 mm     |
| <b>Volume</b>                 | 23 liter               |
| <b>Weight</b>                 |                        |
| Net                           | 15 kg approx           |



**Bulgaria**  
Изхвърляйте правилно този продукт (отпадно електрическо и електронно оборудване)

Това обозначение на продукта или съответните го материални означава, че той не бива да бъде изхвърлян заедно с другите битови отпадъци след края на ползването му. За да се поддържа възможно уредбата на околната среда или човешки живот от безконтролно изхвърлянето на отпадъци, моля, отделните такова продукти от другите видове отпадъци и ги рециклирайте, демонстрирайки отговорно отношение към извършването на устойчива икономическа употреба на материални ресурси.

При употреба за битови нужди трябва да се свържете с продавача на дребно, от когото сте закупили продукта или с местните власти за подробности относно това къде и как можете да предадете продукта за безплатно рециклиране.

При употреба за стопански нужди трябва да се свържете с доставчика си и да проверите реда и условията в договора за закупуване. Този продукт не трябва да се смесва с други отпадъци на работното място.

**Greece**



Σωστή Διάθεση αυτού του Προϊόντος (Απορρίμματα Ηλεκτρικού & Ηλεκτρονικού Εξοπλισμού)

Το σήματα που εμφανίζονται πάνω στο προϊόν ή στο εγχώριο που το συνοδεύουν, υποδηλώνουν ότι δεν θα πρέπει να ρίπτεται μαζί με το υπόλοιπο οικιακό απόρριμμα μετά το τέλος του κύκλου ζωής του. Προκειμένου να αποφευχθούν ανεπιθύμητες βλάβες στην περιβάλλοντα ή την υγεία (επίσης της ανεξέλεγκτης διάθεσης απορριμμάτων, στις παρακαλούμε να το διαχωρίσετε από άλλους τύπους απορριμμάτων και να το ανακυκλώσετε, ώστε να βοηθήσετε στην βιώσιμη επανοχρησιμοποίηση των υλικών πόρων.

Οι οικιακοί χρήστες θα πρέπει να έλθουν σε επικοινωνία είτε με τον πωλητή από όπου αγοράσαν αυτό το προϊόν, είτε με κάποιον τύπου υπηρεσίας, προκειμένου να πληροφορηθούν τις λεπτομέρειες σχετικά με τον τόπο και τον τρόπο με τον οποίο μπορούν να δωσουν αυτό το προϊόν για ασφαλή προς το περιβάλλον ανακύκλωση.

Οι επαγγελματίες/χρήστες θα πρέπει να έλθουν σε επαφή με τον προμηθευτή τους και να δώσουν τους όρους και τις προϋποθέσεις του συμβόλαιου πώλησης. Το προϊόν αυτό δεν θα πρέπει να αναμειγνύεται με άλλα ανακυκλώσιμα απορρίμματα προς διάθεση.

**English**



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

**Romania**



Evacuarea corectă a acestui produs (reziduurii provenind din aparatură electrică și electronică)

Marcajele de pe acest produs sau menționate în instrucțiunile sale de folosire indică faptul că produsul nu trebuie aruncat împreună cu alte reziduuri din gospodărie atunci când nu mai este în stare de funcționare. Pentru a preveni posibile efecte dăunătoare asupra mediului înconjurător sau a sănătății oamenilor datorate evaziunii necorespunzătoare a reziduurilor, vă rugăm să separați acest produs de alte tipuri de reziduuri și să-l reciclați în mod responsabil pentru a promova reînnoirea resurselor materiale.

Utilizatorii casnici sunt rugați să ia legătura fie cu distribuitorul de la care au achiziționat acest produs, fie cu autoritățile locale, pentru a primi informații cu privire la locul și modul în care pot deponiza acest produs în vederea reciclării sale ecologice.

Utilizatorii instituționali sunt rugați să ia legătura cu furnizorul și să verifice condițiile stipulate în contractul de vânzare. Acest produs nu trebuie amestecat cu alte reziduuri de natură comercială.



**ELECTRONICS**

**If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.**

**QUESTIONS OR COMMENTS?**

| <b>COUNTRY</b> | <b>CALL</b>            | <b>OR VISIT US ONLINE AT</b>                               |
|----------------|------------------------|--|
| UK             | 0845-SAMSUNG(726-7864) | <a href="http://www.samsung.com">www.samsung.com</a>       |
| EIRE           | 0818 717 100           | <a href="http://www.samsung.com/ie">www.samsung.com/ie</a> |
| SOUTH AFRICA   | 0860-SAMSUNG(726-7864) | <a href="http://www.samsung.com">www.samsung.com</a>       |
| INDIA          | 3030 8282, 1800 110011 | <a href="http://www.samsung.com">www.samsung.com</a>       |
| GREECE         |                        | <a href="http://www.samsung.com/gr">www.samsung.com/gr</a> |