STEP 2 – BACK OF THE HEAD

- Change to the next longest comb attachment 9mm or 12mm and cut the back of the head (fig.2).

STEP 3 – SIDE OF THE HEAD

- Change to one of the shorter combs 3mm or 6mm, trim sideburns, i.e. the hair directly in front of the ears.
- Then change to one of the longer combs, 9mm or 12mm, and continue to cut to the top of the head (fig.3).
- Attach the comb №7 and cut the right temporal part of head.
- Attach the comb №8 and cut the left temporal part of head. (fig.3)

STEP 4 – SIDE OF THE HEAD

- Using comb attachment 9mm or 12mm, cut top of head from back to front against the direction in which the hair normally grows (fig.4). In same cases, this may require the reverse, or cutting from front to back.
- Comb attachment 3mm or 6mm are used to achieve a close crew cut or short cut.
- For longer hair on top, use the comb provided and lift hair on the top of the head. Cut over the comb, with the hair lifted or hold the hair between the fingers to lift it and cut it to desired length (fig.5,6). Always work from the back of the head. You can cut the hair shorter gradually by reducing the space between the comb/fingers, and the head. Comb out trimmed hair and check for uneven strands.



SPECIFICATION

Power supply	230 V, 50 Hz
Power	15 W
Net/Gross Weight	0.59 kg / 1.36 kg
Gift box dimension (L x W x H)	251 mm x 75 mm x 255 mm

СМАЗКА ЛЕЗВИЙ

- Для обеспечения надежной работы машинки ее лезвия должны регулярно смазываться.
- Не рекомендуется применять для смазки масла для волос, жиры и масла, разбавленные керосином или другими растворителями. Испарение растворителя может привести к сгущению масла и затруднению движения лезвий.

РЕГУЛЯТОР ДЛИНЫ СРЕЗАЕМЫХ ВОЛОС

- Регулятор длины срезаемых волос удобно расположен около Вашего большого правого пальца, что позволяет легко регулировать длину срезаемых волос.
- Регулятор длины срезаемых волос позволяет Вам постепенно изменять длину срезаемых волос без использования дополнительных насадок.
- При нахождении регулятора длины срезаемых волос в верхнем положении волосы срезаются очень коротко. При медленном перемещении вниз величина срезаемых волос уменьшается.
- Длина срезаемых волос при самом нижнем положении регулятора соответствует применению дополнительного гребня №1 (3 мм).
- Регулятор длины срезаемых волос также позволяет увеличить срок службы лезвий, так как каждая их перестановка приводит к уменьшению времени их эксплуатации.
- При стрижке волос возможно застревание волос между зубьями лезвий, освободиться от которых также можно с помощью данного регулятора, не снимая при этом самих лезвий.
- Для освобождения застрявших волос быстро переведите регулятор из нижнего положения в верхнее несколько раз. Применение данной операции после каждого использования машинки позволит Вам избавиться от остатка волос.
- Если машинка перестает срезать волосы и затрудняется операция освобождения от волос, следует заменить затупившиеся лезвия.

ПОДГОТОВКА К РАБОТЕ

- Перед началом стрижки проверьте машинку, убедитесь, что между зубьями лезвий нет масла. Включите машинку и посмотрите на ход лезвий, они должны беспрепятственно передвигаться. Применяйте данную

ОПИСАНИЕ

1. Защитная крышка для режущих лезвий
2. Лезвия
3. Регулятор длины срезаемых волос
4. Корпус
5. Переключатель Вкл./Выкл.
6. Петелька для подвешивания
7. Защита шнура от перекручивания
8. 6 съемных гребней (3 мм, 6 мм, 9 мм, 12 мм, для левого и правого висков)
9. Парикмахерские расчески
10. Ножницы
11. Масленка для машинки
12. Щеточка для чистки лезвий
13. Щеточка для состриженных волос
14. Зажимы для волос
15. Кейс для хранения

МЕРЫ БЕЗОПАСНОСТИ

При обращении с прибором, особенно в присутствии детей, следует соблюдать следующие меры предосторожности:

DESCRIPTION

1. Blade guard
2. Blades
3. Blade adjustment level
4. Housing
5. On/Off switch
6. Hanging loop
7. Cord swivel protection
8. 6 detachable combs (3 mm, 6 mm, 9 mm, 12 mm, left and right tapes)
9. Barber combs
10. Scissors
11. Oil
12. Cleaning brush
13. Neck brush
14. Styling clips
15. Storage case

IMPORTANT SAFEGUARDS

When using electrical appliance, especially when children are present, basic safety precautions should always be followed, including the following:

- Home use only. Do not use for industrial purpose.

- Do not use hair oil, grease, oil mixed with kerosene or any solvent. As the solvent will evaporate and leave the thick oil which may slow down the blades motion.

BLADE LEVEL

- The level is conveniently located near your thumb (if you are right-hander) so it can easily be adjusted while the clipper is in your hand.
- The level adds versatility to your clipper by allowing you gradually change the closeness of your cut without an attachment comb.
- When the level is in the uppermost position, the blades will give you the closest cut and leave the hair very short. Pushing the level downward gradually increases the cutting length.
- In its lowest position, the level will leave the hair approximately the same length as a №1 comb.
- The level will also extend the use of your blades since a different cutting edge is used in each setting.
- In addition, if extremely heavy hair cutting has jammed the blades, it will help you remove hair that has become wedged between the two blades without removing the blades.
- While the clipper is running rapidly move the level from "close cut" to "longer cut" a couple of times. Doing this each time after you have finished using your clipper will help to keep the blades clear of cut hair.
- If your clipper stops cutting and this does not help, your cutting blades are dulled. Replace them with new blades.



INSTRUCTIONS FOR HAIR CUTTING

- Before starting the hair cut inspect the clipper, making sure that it is free of oil between the cutting blade teeth and switch the unit on to distribute the oil and to make sure it is running smoothly. Wipe off any excess oil. This should be done after each use. While using the unit, unbwist the cord from time to time to avoid tangling.
- Seat the person so their head is approximately at your eye level. This allows ease of visibility while cutting and a relaxed control of the unit.
- Before cutting always first comb the hair so it is tangle free and as it is naturally worn.
- Place a towel around the neck and shoulders of the person having the haircut.

REMINDERS

- Cut the hair in a relaxed and slow manner. Use short strokes only to work gradually over the entire head.
- Always take off a little at a time, you can always trim off additional hair later.

- To reduce the risk of death or injury by electric shock unplug this appliance before cleaning.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not immerse the appliance in water or other liquids.
- Do not use attachments not recommended by the manufacturer.
- Use this appliance only for its intended use as described in this manual.
- Never operate the appliance if it has a damaged cord or plug, if it is not working properly.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening of this appliance.
- Do not place appliance on any surface while it is operating.
- Do not use this appliance outdoor with a damaged or broken comb nor with teeth missing from the blades as injury may occur.

NOTE: KEEP BLADES OILED.

BLADE ALIGNMENT

- Your clippers were carefully examined to ensure that the blades were oiled and aligned before leaving our factory.
- To realign the blades, simply match the upper and end of top blade teeth should be approximately 1.2 mm back from bottom blade. Compare your clipper blades with the sketch.
- If blade alignments is incorrect, add a few drops of oil to the blades, switch on clipper for a few moments, switch off and unplug. Loosen screws slightly and adjust. Tighten screws after blade is aligned.

OIL

- To maintain your clipper in peak condition, the blades should be oiled every few haircuts.

КОРОТКАЯ СТРИЖКА ВОЛОС И «ПЛОЩАДКА»

- Используйте самый длинный гребень и ведите машинку при этом снизу от затылочной части до макушки. Держите гребень параллельно поверхности головы, медленно ведя машинку через волосы (рис. 8).
- Волосы сверху выстригаются до макушки в направлении, противоположном их росту. Затем переходите к стрижке волос с боков.
- Для стрижки под прическу «площадка» не требуются гребни, а только плоская расческа. Стрижка волос начинается сверху.
- Для стрижки и подравнивания волос на затылочной части головы используйте насадку для короткой стрижки волос. Примешите волосы, обратив внимание на неровные места. Перейдите затем к стрижке висков и затылка, как описано выше.



ОЧИСТКА И ХРАНЕНИЕ

- Очистите лезвия и машинку от обрезков волос прилагаемой щёточкой.
- Протрите корпус сухой мягкой тканью.
- Смажьте лезвия, как это описано выше.
- Храните машинку следует в сухом месте.
- Допускается подвешивать её за петлю.
- Лезвия обязательно должны быть смазаны.

ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ

Электропитание	230 Вольт, 50 Герц
Мощность	15 Ватт
Вес нетто/брутто	0,59 кг / 1,36 кг
Размеры коробки (Д х Ш х В)	251 мм х 75 мм х 255 мм

ШАГ 1 - ЗАТЫЛОК И ШЕЯ

- Установите гребень 3 мм или 6 мм.
- Возьмите машинку таким образом, чтобы лезвия смотрели вверх и начинайте стрижку от основания шеи к центру головы (рис.1).
- Затем поудобнее возьмите машинку с установленным дополнительным гребнем так, чтобы зубцы гребня были направлены вверх. Постепенно и медленно водите машинкой снизу вверх, от корней к концам волос (рис. 1).
- Во время работы постепенно поднимайте машинку вверх вдоль затылка. Продолжайте обработку шеи и затылка в направлении снизу вверх до верхних кончиков ушей.

ШАГ 2 - ЗАДНЯЯ ЧАСТЬ ГОЛОВЫ

- Установите гребень 9 мм или 12 мм для обработки более длинных волос и начинайте обработку всей задней части головы (рис. 2).

ШАГ 3 - ОБРАБОТКА ВИСКОВ

- Снова установите один из гребней 3 мм или 6 мм, в зависимости от длины волос, и обработайте височную часть головы.
- Затем, установив гребень 9 мм или 12 мм, Вы можете продвигаться выше (рис. 3).
- Установите гребень №5, обработайте левую височную часть головы.
- Затем, установив гребень №6, обработайте правую височную часть головы (рис. 3).

ШАГ 4 - ОБРАБОТКА ВЕРХНЕЙ ЧАСТИ ГОЛОВЫ

- Установив гребень 3 мм или 6 мм, начинайте стрижку верхней части головы. При этом машинку следует продвигать от тяжелым направлением против естественного роста волос к лбу и затылку.
- Для стрижки длинных волос верхней части головы, используйте гребень в сочетании с подъемом волос. Для этого расчесывайте волосы против их роста, используя гребень (рис. 5 и 6). Такой обрезок, а проделав машинкой. Для этих же целей используйте расческу (рис. 5 и 6). Такой обрезок, начинайте длину прядь, Вы можете сэкономить длину волос, прилегая по своему вкусу. Всегда предварительно расчесывайте длинные волосы перед стрижкой во избежание неравномерности.
- Если подравнивание волос Вы не предусмотрели заранее, для подравнивания волос вокруг ушей и около висков установите регулятор длины срезаемых волос в нижнее положение.
- Перемещая машинку сбоку назад и вперед, обработайте волосы в направлении роста волос. Затем закончите стрижку, используя гребень с самыми короткими волосами. Вы также можете подравнять длинные волосы с помощью ножниц.

ШАГ 5 - ПОДРАВНИВАНИЕ ВОЛОС

- Для подравнивания волос Вы не предусмотрели насадки. Для подравнивания волос вокруг ушей и около висков установите регулятор длины срезаемых волос в нижнее положение.
- Перемещая машинку сбоку назад и вперед, обработайте волосы в направлении роста волос. Затем закончите стрижку, используя гребень с самыми короткими волосами. Вы также можете подравнять длинные волосы с помощью ножниц и расчески.

Vitek

HAIR CLIPPER SET
Instruction manual
НАБОР ДЛЯ СТРИЖКИ ВОЛОС
Руководство по эксплуатации
VT-1465

USING AND CARING FOR YOUR CLIPPER

- Wipe the cutter with a dry soft cloth.
- Oil the blades as mentioned above.
- Keep the appliance in a dry room.
- You may hang the cutter by provided loop.
- The blades must be oiled for storage period.

CLEANING AND STORAGE

- Remove cut hair from the clipper with the brush endosed.
- Starting with the longest attachment comb (12mm), cut from the back of the head to the crown, hold the attachment comb flat against the head and slowly move the clipper through the hair, as shown (fig.8).
- Cut the hair against the direction in which it grows from the front to the crown and then level the cuts with the sides.
- To give a "flat top" look, the hair on top of the head must be cut over the top of a flat comb rather than by using the attachments combs. Use closer cutting attachments combs to taper the hair down to the neckline as desired. Comb hair and check for uneven areas and outlining sideburns and neckline as described previously.



SHORT TAPERED STYLES – "FLAT TOP" AND SHART CUTS

- Cutting hair requires practice so it is always better to leave the hair longer for the first few haircuts until you become used to the length to which each comb attachment cuts the hair.
- Comb hair to remove tangles and straighten it so the hair lies in its natural direction.
- Trying to cut hair when it is wet or damp will result in uneven cutting.
- Before cutting hair, make sure that the hair is dry, not wet. With the hair dry, it is much easier to control the length of hair being cut.
- Wear cutting with this hair clipper it is better to leave the hair longer and slowly move the clipper through the hair, as shown (fig.8).
- Cut the hair against the direction in which it grows from the front to the crown and then level the cuts with the sides.
- To give a "flat top" look, the hair on top of the head must be cut over top of a flat comb rather than by using the attachments combs. Use closer cutting attachments combs to taper the hair down to the neckline as desired. Comb hair and check for uneven areas and outlining sideburns and neckline as described previously.
- Remove cut hair from the clipper with the brush endosed.
- Wipe the cutter with a dry soft cloth.
- Oil the blades as mentioned above.
- Keep the appliance in a dry room.
- You may hang the cutter by provided loop.
- The blades must be oiled for storage period.

ATTACHMENT COMB

- Attachment comb №1 leaves 3 mm (1/8 inch) hair length.
- Attachment comb №2 leaves 6 mm (1/4 inch) hair length.
- Attachment comb №3 leaves 9 mm (3/8 inch) hair length.
- Attachment comb №4 leaves 12 mm (1/2 inch) hair length.
- Attachment comb №6 for left tape.
- Attachment comb №7 for right tape.
- Each comb attachment is marked accordingly on its outside middle surface.
- comb firmly seats against the clipper blade.
- To attach a comb, hold it with its teeth upward and slide it into and along the clipper blade until the front of the comb firmly seats against the clipper blade.
- When you use the clipper for the first time, cut only small portions of hair until you are accustomed to the cutting length with a certain comb attachment.
- For even cutting, allow the comb attachment/cutter to cut its way through the hair. Do not force it through quickly. Also remember to comb the hair frequently to remove trimmed hair and check for uneven strands.

STEP 1 – NAPE OF THE NECK

- Attach comb attachment 3mm or 6mm.
- Hold the clipper cutting edge pointed up and begin the haircut, starting at the centre of the head at the base of the neck (fig.1).
- Hold the clipper comfortably in your hand and hold lightly against the head with the comb teeth resting upward, gradually and slowly lift the clipper, working upwards and outwards, through the hair, trimming just a little at a time.
- As you cut, gradually lift the hair clipper head towards you. Continue to cut the back area from the bottom of the neck upwards to the top of the ears.

- Перед началом стрижки проверьте машинку, убедитесь, что между зубьями лезвий нет масла. Включите машинку и посмотрите на ход лезвий, они должны беспрепятственно передвигаться. Применяйте данную смазку только в малом количестве. Избыток ее испачкает волосы и затруднит операцию стрижки.
- Установите регулятор длины срезаемых волос в нижнее положение.
- Расположите гребень №1 (3 мм) на корпусе машинки.
- Включите машинку и начинайте стрижку от затылка, постепенно перемещая машинку вверх.
- Для обработки висков используйте гребни №5 и №6.
- Для обработки бакенбард используйте гребень №7.
- Для обработки верхней части головы используйте гребень №4.

ИСПОЛЬЗОВАНИЕ ДОПОЛНИТЕЛЬНЫХ ГРЕБНЕЙ

- Дополнительный гребень №1 – для стрижки волос длиной около 3 мм.
- Дополнительный гребень №2 – для стрижки волос длиной около 6 мм.
- Дополнительный гребень №3 – для стрижки волос длиной около 9 мм.
- Дополнительный гребень №4 – для стрижки волос длиной около 12 мм.
- Дополнительный гребень №5 – для стрижки висков.
- Дополнительный гребень №6 – для стрижки правого виска.
- Расположите гребень №7 – для стрижки бакенбард.
- Съемные гребни для стрижки неравномерно растущих волос. Чтобы привыкнуть к длине срезаемых волос, чтобы избежать спутывания волос, чтобы установить нужную длину стрижки, чтобы стрижка была равномерной, мы рекомендуем Вам сначала попробовать стрижку с гребнем №1 (3 мм).

- Используйте только в бытовых целях. Прибор не предназначен для промышленного использования.
- Избегайте попадания волос на вентиляционные отверстия.
- Не погружайте машинку при мытье в воду. Не оставляйте машинку в ванной или раковину.
- Не оставляйте прибор в воду или другие жидкости.
- Не опускайте прибор в воду или другие жидкости.
- Не оставляйте работающий прибор без присмотра.
- Не используйте аксессуары, не рекомендованные производителем.
- Не применяйте электрические насадки, не предусмотренных изготовителем.
- Держите прибор вдали от нагревательных приборов.
- Не оставляйте работающий прибор без присмотра.
- Не используйте прибор с поврежденным шнуром или вилкой, а также при возникновении сбоев в его работе.
- Не допускайте попадания посторонних предметов в вентиляционные отверстия.
- Не пользуйтесь машинкой при поврежденной электровилке или шнуре, а также при возникновении сбоев в его работе.
- Не допускайте попадания посторонних предметов в вентиляционные отверстия.
- Не оставляйте работающий прибор без присмотра