ENGLISH

HAIR CLIPPER

IMPORTANT INFORMATION
Before using your haircutting set read these instructions attentively.

- When using power adapter make sure that the voltage of the local power supply corresponds to the voltage indicated on the adapter.
- Turn off the device when not in operation or when you do not use it.
- Periodically check the power adapter cord. If the device or the power adapter is damaged, do not use the appliance and service cord.
- Do not use the clipper if guide combs or blades are damaged.
- For the clipper to work properly, the blades must be clean, oiled and have no cut hair on them. After each usage clean the set using the brush supplied.
- Keep the appliance away from the reach of children.
- Do not immerse the appliance in water or let it fall into water.
- Do not use the appliance in the bathroom.
- Do not use the appliance for other purposes.
- Do not touch the appliance if your hands are wet.
- Do not use the appliance if you have cut or injured skin.
- Do not use the appliance if the power cord or plug is damaged.
- Do not use the appliance if it has fallen into water or other liquid.
- Do not use accessories or attachments not recommended by the manufacturer.
- Do not use the appliance if it has been dropped or if it has fallen into water or other liquid.
- Do not use the appliance if it has been damaged in any way.
- Do not use the appliance if the power cord or plug is damaged

MANUAL INSTRUCTION

Vitek

x-DRIVE
VT-1364 SR

www.vitek-aus.com

CR MANUAL INSTRUCTION
BG DIE BETRIEBSANWEISUNG
UA ІНСТРУКЦІЯ ЕКСПЛУАТАЦІЇ
RO NOTICE D'UTILISATION
RU ISTRUZIONI D' USO
EN INSTRUCCIONES DE USO
HU ИНСТРУКЦИЯ ЭКСПЛУАТАЦИИ
HR HASZNÁLATI UTMUTATÓ
SCO UPUTSTVO ZA UPOTREBU
CZ INSTRUKCJA OBSŁUGI
SK NÁVOD K POUŽITÍ
SI INSTRUKCIJA S EKSPLUATACIJI
RS INSTRUKCIJA ZA EKSPLOATACIJU
PL ПОСІБНИК ЕКСПЛУАТАЦІЇ

MAGYAR

HAJNYÍRÓGÉP

FONTOS INFORMÁCIÓ

A hajnyíró használata előtt figyelmesen olvassa el az adott használati utasítást.

A hálózati adapter bekapcsolása előtt győződjön meg arról, hogy a villamoshálózat feszültsége megegyezik az adapteren feltüntetett feszültséggel.

Kapcsolja ki a gépet a használat közben szüneteken kívül ha nem használja.

Rendszeresen vizsgálja meg a hálózati adapter vezetékét. Ha a gép vagy a hálózati adapter sérült, forduljon márkaszervizhez.

Ne használja a hajnyírógépet, ha a fésű vagy a vágókések sérültek.

A gép bizonyos szervizelési munkálatokhoz szükséges szerszámok kellő kennisk, meg kell, hogy legyenek olajozva és nem szabad, hogy hajszál maradjon rajtuk. Minden használat után tisztítsa meg a pengeket a kefa segítségével.

A késszélekkel kisgyermekekről eszüne tárolja.

Ne merítse a készüléket vízbe és ne engedje, hogy nedvességi kerüljön rá. Ne kapcsolja be a készüléket, ha vizes vagy nedves. Ne dugjon be, ha nálunk vagy a dugaszolja ki a hálózati dugaszolja ki a hálózati dugaszolja ki a hálózati