

Quick Start Guide



ASUS VivoTab™ RT

Getting to know your tablet



Set up your device


Charging the battery

- 1 Connect one end of the USB cable connector to the charging port on the tablet.
- 2 Connect the other end of the cable to the USB port on the power adapter.
- 3 Connect the power adapter to an electrical outlet.



Installing a microSD™ card

- 1 Press in and release the protective cover on the microSD card slot.
- 2 Insert the microSD card (sold separately) into the slot. Ensure that the gold contacts are facing down.
- 3 Close the protective cover.



Power and lock

Press and hold the power button until the the tablet vibrates. When you start your device for the first time, the start up wizard guides you to configure your device.

- **Power off:** Swipe in from the right edge of the device to launch the charm bar. Tap **Settings** > **Power**, select **Shut down**.
- **Lock:** Tap the power button.
- **Unlock:** Tap the power button and swipe the screen up

Touchscreen and Navigation

Start screen

Windows® 8 comes with a tile-based user interface (UI) which allows you to organize and easily access Windows® apps from the Start Screen.

Gestures

Recent apps



Swipe from the left edge to scroll through running apps.

Search, settings & more



Swipe from the right edge to launch the charm bar.

All apps



On the Start screen, swipe down from the top edge.

In-app options



In an app, swipe down from the top edge.


Close an app



Swipe down from the top edge all the way to the bottom.

Connect to the AT&T Network

- 1 Swipe in from the right edge to launch the charm bar.
- 2 Tap **Settings** > **Network**.
- 3 In the Networks bar, tap **AT&T** > **Connect**.



Find more information

On the Web

- Interactive web tutorials are available at att.com/Tutorials. Select Manufacturer: **Asus** and Model: **VivoTab RT** from the drop down menus or click on the Device Help bookmark in the browser.
- Detailed support information including device specifications, troubleshooting, and user forums are available at att.com/DeviceSupport.
- For more about your wireless account, service plan, or network, visit att.com/Wireless.

On the Phone

- Call AT&T Customer Care at **1-800-331-0500** or dial **611** from any AT&T mobile phone.

Find Accessories


- Accessories for your tablet are at att.com/WirelessAccessories or visit your local AT&T store.

4G speeds delivered by LTE, or HSPA+ with enhanced backhaul, where available. Limited 4G LTE availability in select markets. Deployment ongoing. Compatible data plan required. LTE is a trademark of ETSI. Learn more at att.com/network.


Some features may require monthly access and/or per use charges. VivoTab™ is a trademark of ASUSTek Computer, Inc. Microsoft® and Exchange Active Sync are trademarks or registered trademarks of the Microsoft group of companies. © 2012 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies. All other marks contained herein are the property of their respective owners.

AT&T AllAccess

The AT&T AllAccess tile will give you the information you need to manage your data usage.



- Total amount of data used during the billing period
- Number of days remaining for the billing period
- Amount of data that has been used while roaming
- Number of unread notifications you've received
- Connection status



Tap the AT&T AllAccess tile to open the overview page to view data usage* details and more.

- 1 **Connection status** – technology, and signal strength.
- 2 **Current Plan and usage details**
- 3 **International data roaming**
- 4 **Notifications** - read and delete
- 5 **Customer Support**
- 6 **Device Information and wireless number**
- 7 **AT&T Wi-Fi** - view nearby AT&T free Wi-Fi hot spots

* Actual billed usage can be higher than estimated data usage displayed on the usage meter. For example, actual billed usage may be higher when: traveling internationally or outside AT&T's network; using the SIM card with another device; or, using a tethered handset. Unlimited Wi-Fi usage on the nationwide AT&T Wi-Fi network is included at no additional charge with a qualifying data plan. Access includes AT&T Wi-Fi Basic. Restrictions apply. See www.attwifi.com for details. The name "attwifi" will appear in the Wi-Fi network list when available.

Browse the web

Internet Explorer 10 (IE10)

To use IE10:

- 1 On the Start screen, tap **Internet Explorer**. From web address bar, type the web address and tap **Go**.

Adding and closing tabs


Your current open web pages will be displayed in thumbnails shown in tabs on the Menu Bar.

To add a new tab:

- 1 Swipe from the top or bottom edge of the IE10 page to show the Menu bar.
- 2 Tap **+**. You can also tap **+** to add a new InPrivate tab.

To close tab:

- 1 Swipe from the top or bottom edge of the IE10 page to show the Menu bar.
- 2 Tap **x**.



- Web address bar
- Goes back to previous page
- Refresh current web page
- Pin to Start
- Settings
- Next page

Personalize your device

App Tiles

To resize an app tile:

- 1 Swipe down the app tile to select and launch the settings bar.
- 2 Tap **+** to reduce or tap **-** to enlarge the app tile.

To pin apps to the Start screen:

- 1 From the Start screen, swipe down from the top edge.
- 2 In the settings bar, tap **All apps**.
- 3 Select an app and swipe down on it.
- 4 In the settings bar, tap **Pin** to pin the selected app to the Start screen.

To unpin an app:



- 1 Swipe down the app tile to select and launch the settings bar.
- 2 Tap **Unpin** to unpin an app.

Moving tiles

- 1 From the **start** screen, tap and hold a tile.
- 2 Move the tile and place it in a new location.

Settings


- 1 Swipe in from the right edge to launch the charm bar.
- 2 Tap **Settings** > **Change PC Settings** > **Personalize**.
- 3 Tap **Lock screen** to select the background screen.
- 4 Tap **Start** screen to select the background screen.
- 5 Tap **Account picture** to select the background screen.



Wi-Fi and Airplane Mode


Connecting to Wi-Fi

- 1 Swipe in from the right edge to launch the charm bar.
- 2 Tap **Settings** > **Change PC settings** > **Wireless**.
- 3 Tap Wi-Fi to enable.
- 4 From the **Start** screen, tap **Settings** > **Networks**.
- 5 Tap a network to select and tap **Connect**. If the network is secure, enter the passcode.



Turning the Airplane mode on or off

- 1 Launch the Charm bar.
- 2 Tap **Settings** > **Change PC settings** > **Wireless**.
 - Move the slider to the left to turn Airplane mode off.
 - Move the slider to the right to turn Airplane mode on.




Note: Contact your airline provider to learn about related inflight services that can be used and restrictions.

Microsoft® Store

Search and discover Metro style applications for your **VivoTab RT** device

- 1 From the **Start** screen, tap **Store**.
- 2 Microsoft Store windows displays. Select a desired app to install.
- 3 In the application window, tap **Install**.

Note: To download apps, you need to sign in with your Microsoft account.



Charm bar

The Charm bar allows you to search, share content through email or social networking, return to the Start panel, sync content via device or access settings.

To launch the Charm bar, swipe from the right edge of the screen.


- Search:** allows you to search for files, apps or settings.
- Share:** allows you to share applications via social networking sites or email.
- Start:** reverts the display back to the Start screen. From the Start screen, you can also use this to revert back to a recently opened app.
- Devices:** allows you to access and share files with the devices such as external displays or printers.
- Settings:** allows you to access the settings of your Tablet PC.



Email

Setting Up Mail

- 1 From the **Start** screen, tap Mail.
- 2 Enter the email address and password of the account you would like to set up and tap **Next**.
- 3 Tap **Sign up for a Microsoft account** to create a Microsoft account.
- 4 Enter the account and name as it will appear on outgoing messages and then tap **Done**.




Note: To use Mail, you need to sign in with your Microsoft account.

Using Mail

Mail supports multiple email accounts, printing from email, and multitasking functionality

From the Start screen, tap **Mail**.

- 1 To draft an email, tap **+**.
- 2 To sync your app to your account, tap **☺**.
- 3 To pin a specific folder to the **Start** menu, tap **📌**.



Map and Navigation

Find places, view real-time traffic and conditions, receive detailed directions to your destination.


Explore Maps

- 1 From the **Start** screen, tap **Maps**.
- 2 Swipe the bottom border of the tablet.
- 3 Tap **My Location** to show your current location.
- 4 Check out nearby places by panning and zooming in and out on the map.
- 5 Press and hold a location on the map to learn more about that location.



Get Directions

- 1 From the **Start** screen, tap **Maps**.
- 2 Swipe the bottom border of the tablet.
- 3 Tap **Directions**.
- 4 Use your current location as the starting point, or enter the start location you choose.
- 5 Enter your destination in the second text box.
- 6 Tap **Go**.
- 7 Tap an item in the **Directions** list to view it on the map.



Note: You must enable "Let apps use my location" under Privacy section in PC Settings.

Multitasking

Snap Feature

The Snap feature displays two apps side-by-side, allowing you to work or switch between apps.

Using Snap


IMPORTANT! Ensure that your **VivoTab RT** screen resolution is set to 1366 x 768 before using the Snap feature.

- 1 Launch the apps that you wish to snap.
- 2 Slowly swipe from the left edge of the tablet until the snap bar appears.
- 3 You can drag to move the snap bar to enlarge the desired app or drag the snap bar to the edge to close the snap view.



Microsoft Office

- 1 From the **Start** screen, tap a Microsoft Office application:
 - Word®
 - Excel®
 - PowerPoint®
 - OneNote®
- 2 You will be taken to the desktop mode where the Office application is running.




Social Networking

People supports multiple social networking accounts.

Your Microsoft account is used to log into Windows and sync settings.

- 1 From the **Start** screen, tap **People**.
- 2 In the **People** screen, tap **Connect to M**.
- 3 In **Accounts**, tap **your Microsoft account**.
- 4 Tap to setup, configure, or remove your account.





Camera

Take pictures and record videos with rear and front facing cameras, and then quickly and easily share them with friends and family.

Taking a Picture

- 1 From the **Start** screen, tap **Camera**.
- 2 Tap the screen to take a picture.




Recording a Video

- 1 From the **Start** screen, tap **Camera**.
- 2 Select **Video Mode**.
- 3 Tap the screen to start or stop recording.

Sharing a Picture

- 1 From the **Start** screen, tap **Photos**.
- 2 Swipe in from the right edge to launch the charm bar.
- 3 Tap **Share** and select the application or device to share the selected image.



Synchronizing Content

NFC Sharing

- 1 From the **Start** screen, swipe from the right edge of the screen to launch the Charm bar.
- 2 Tap **Devices** to list available devices.
- 3 Tap on a transfer method. For Tap and send, gently tap the **Asus VivoTab RT** against another NFC enabled device to send the selected content.



File Transfer

There are several options for your transfer files to your tablet:

- MicroSD card, support up to 64GB
- Insert the in-box USB adapter to the charging port, use thumb drive or portable hard drive to transfer file
- Home group feature – First setup homegroup from a Windows 7/8 laptop; then go to PC setting on the tablet to join the homegroup and access shared files/media. For more information, refer to the website below: <http://windows.microsoft.com/is-IS/windows7/products/features/homegroup>
- Skydrive or any other cloud storage solution

Your **Asus VivoTab RT** can now be synchronized with your PC.