



QT55748V01


Canon

PIXMA MP230


series

Model Number: K10379


1









2








2




3




4






4





5




6




7




8



9



5



6

