

7501GE

Diag.			English Description	Qty.
1	LSC08038	法兰螺栓M8*38	Flange hd hex. bolt	7
2	16002003	机油尺密封圈	Oil filler cap gasket	2
3	ZC6202	滚珠轴承	Ball bearing	2
4	XA0814	定位销	Sleeve	2
5	34002004	曲轴箱盖垫片	Case cover gasket	1
6	ZC6207	滚珠轴承6207	Ball bearing	1
7	YF355208	LT340/390 油封35*52*8	Oil seal	1
8	34002001	曲轴箱盖	Crankcase cover	1
10	24002002	带刻度机油尺	Oil filler cap	2
11	LSB06012	螺栓M6*12	Flange hd hex. bolt	2
12	34009003	调速弹簧	Governor spring	1
13	16009005	调速臂螺栓M6*21	Governor arm bolt	1
14	LMB6	螺母M6	Flange hd hex. Nut	1
15	34009004	调速臂	Regulating arm	1
16	34009001	调速拉杆	Governor rod	1
17	34009002	节气门复位拉簧	Throttle return spring	1
18			Flange hd hex. bolt	1
19	34009200	调速控制组件	Speed control ass'y	1
20	24001008	调速推盘	Governor	1
21	16001007	调速轴卡簧	Governor shaft cap	1
22	16001004	垫片6	Washer	2
23	24001006	调速轴	Governor shaft	1
24	34001101	调速齿轮组件	Governor weight	3
25	34001102		Governor weight pin	3
26	34001100	调速齿轮组件	Complete governor gear	1
27	ZC6202	滚珠轴承	Ball bearing	1
29	39001001	箱体	Crankcase	1
30	24001011	浸塑线夹	Wire retainer	2
31	LSB06010		Flange hd hex. bolt	1
32	LSB12015	放油螺塞	Drain plug bolt	2
33	24001005	放油螺塞垫片	Drain plug seal	1
34	YF355208	油封35*52*8	Oil seal	1
35	01010	曲轴箱过线套	Wire protector	1
36	ZC6207	滚珠轴承	Ball bearing	1
37	34001002	调速摆杆	Governor arm	1
38	24001003	调速摆杆锁夹	Lock clip	1
39		弹垫	Washer	1
39-2			Washer	2
39-3	YF081405	摆杆油封	Oil seal	1
40	16005204	摇臂轴调节螺母	Pivot adjusting nut	2
41	16005202	摇臂轴座销	Rocker pivot pin	2
42	24005201	气门摇臂	Valve rocker	2
44	24005009	排气门调节帽	Valve rotator	1
45	24005007	进气门弹簧座	Intake valve seat	1
46	24005006	气门弹簧	Valve spring	2
47	24005010	排气门弹簧下座	Spring retainer exhaust valve	1
48	34005004	进气阀	Intake valve	1
49	39005100	凸轮轴总成	Camshaft ass'y	1
50	24005001	气门挺柱	Tappet	2
51	34005002	推杆	Push rod	2
52	24005003	推杆导板	Push rod guide plate	1
53	16005203	摇臂轴螺栓	Pivot bolt	2
54	34005005	排气阀	Exhaust valve	1
55	24005008	排气门弹簧座	Exhaust valve seat	1
56	24004200	火花塞	Spark plug	1
57	LZA08032	单机双头螺柱AM8*32	Threaded stud	2
59	34004100	气缸盖组件	Cylinder head	1
60	24004104	气门导管夹	Valve guide clip	1
61	34004101	气缸头	Cylinder head	1

62	34004106	排气门座	Exhaust valve seat	1
63	34004105	进气门座	Intake valve seat	1
65	24004103	排气门导管	Exhaust valve guide	1
66	XA1220	定位销 12*20	Sleeve	2
67	39004001	气缸盖垫片	Cylinder head gasket	40
68	34004008	机组双头螺柱	Threaded Stud	2
69	34004005	下导风罩	Wind cover	1
70			Flange hd hex. bolt	1
71	24004003	呼吸管	Breather tube	1
72	24004006	气缸盖罩螺栓组件	Complete Head cover bolt	1
73	24004300	气缸盖罩总成	Head cover	1
74	24004002	气缸盖罩垫片	Head cover seal	1
75	24004004	气缸头螺栓	Flange hd hex. bolt	4
76	34004102	进气门导管	Intake valve guide	1
78	39007300	机组化油器接块	Connecting block	1
79	34007004	进气口垫片	Inlet gasket	1
80	24007400	机组单向阀组件	Complete Check valve	1
82	39007001	空滤器垫片	Air cleaner gasket	1
83	24007500	机组手动阻风门总成	Complete manual choke	1
84	39007200	机组化油器总成	Complete Carburetor	1
85	39007002	化油器垫片	Carburetor gasket	1
86	34003102	正时齿轮	Timing driving gear	1
87	34003101	曲轴V1	Crankshaft	1
88	34003103	调速齿轮	Drive gear	1
89	YJA0418	半圆键4*18	Woodruff key	1
90	34003008	平衡轴	Balance shaft	1
91	39003006	活塞销卡簧	Piston pin clip	2
92	34003005	活塞销	Piston pin	1
93	39003004	活塞	Piston	1
94	39003300	活塞环组件	Piston ring set	1
95	34003200	连杆总成	Complete connecting rod	1
96	LSB06028	法兰螺栓M6*28	Flange hd hex. bolt	2
98	34012001	冷却风扇	Cooling fan	1
99	34012002	起动机	Starter pulley	1
100	34012003	飞轮螺母	Flywheel nut	1
101	16012007	单向导通阀	Diode	1
103	34012004	一体化点火线圈	Ignition coil	1
104	LSB06014		Flange hd hex. bolt	2
105	24012005	机油油位传感器组件	Oil sensor	1
106	LMB10		Special nut	1
108	34012100E	飞轮组件（电启动）	Flywheel with ring gear	1
109	24012008	充电线圈	Charging coil	1
110	34012400	起动机组件	Starter	1
	34012401	起动机继电器	Solenoid	1
111	XA0810		Flange hd hex. bolt	2
	50001000	LT390V1E	Engine LT390V1E	1
112	24006001		Large harness clip	1
113	24006002		Small harness clip	2
114	34006100	导风罩	Fan hood	1
117	LSB06012	螺栓6*12	Flange hd hex. bolt	4
118	34006200	手拉盘外壳	Casing	1
118-1	34006201	手拉盘总成	Recoil assembly	1
119	LSB06010	螺栓6*10	Flange hd hex. bolt	3
120	34006209	拉绳	Rope	1
121	34006210	拉手	Pulling handle	1
122	38001001	排气口垫片	Exhaust gasket	1
123	LMB08		Hex. nut	2
124	LSB08033		Flange hd hex. nut	2
125	TD08		Spring washer	2
128	38001003	消声器垫片	Muffler gasket	1
127	38001102	消声器接管	Muffler joint pipe	1
129	38001101	机组消声器总成	Muffler complete	1

130	TD08		Spring washer	2
131	LSB08020		Flange hd hex. bolt	2
132	PD08		Washer	2
133	LSB08020		Flange hd hex. bolt	2
134	TD08		Spring washer	2
135	PD08		Washer	2
136	38001004	消声器支架A	Muffler support	1
137		汽油机组内置免维护黑色电瓶线	Battery cable (black)	1
138		汽油机组内置免维护红色电瓶线	Battery cable (red)	1
140	34008200	机组空滤器总成	Complete Air filter	1
141	24008201		Air filter housing	1
143	24008204		Air filter cover	1
142	24008202	空滤器滤芯	Air filter element	1
144	LMB06	法兰螺母06	Flange hd hex. nut	2
145		空开	Circuit breaker	1
146	65006012	电门锁带钥匙	Key Switch	1
147	65006010	电压表	Voltmeter	1
148		电源指示灯	Power Light Indicator	1
149		计时器	Time counter	1
150		保护性接地	Ground	1
151		过流开关	Flow switch	1
152		直流插座	DC socket	1
153		交流插座	AC socket	1
154		交流插座	AC socket	1
155		三相插座	Three phas socket	1
156		控制面板后罩	Rear Control Panel Cover	1
157	65006004	控制面板总成	Control Panel	1
158	LSB06012		Flange hd hex. bolt	4
159	PD06		Washer	4
160	38003001	消声器护罩	Rear cover for muffler	1
162	TDA08		Spring washer	4
164	38003200	减震垫	Shock absorber	4
165	PDA08		Washer	4
166	LMA08		Hex. nut	4
167	38003100		Frame	1
168			Washer	4
169			Flange hd hex. bolt	4
170		消声器侧盖板	Cover for muffler	1
171		垫片6	Washer	2
172			Flange hd hex. bolt	2
173			Front cover for muffler	1
174			Flange hd hex. bolt	1
175			Spring washer	1
176			Washer	1
177		小头法兰螺栓	Pan hd screw	4
178		电瓶压杆	Battery retaining bar	1
179		12AH免维护电瓶	Battery	1
180		12AH钩型螺栓	Hooked bolt	2
181			Wing nut	2
182	25004001	油箱盖	Fuel cap	1
183	25004002		Fuel cap seal	1
184	25004003		Fuel strainer	1
185	25004100	油箱总成	Fuel tank	1
186	25004200	油开关组件	Fuel valve	1
187	38004008	油管	Fuel hose	1
188	25004009	油管夹	Clips	2
189	LMA06		Hex. nut	1
190	25004007		Rubber grommets	4
191	25004006		Metal sleeve	4
192	PDB06		Washer	4
193	LSB06012	法兰螺栓	Flange hd hex. bolt	4

194	25004005	机组油位浮标组件（含螺丝）KCC	Fuel level indicator	1
	25004008	油标玻璃	Plastic cover	1
195	LDA05010		Countersunk hd screw	2
197	LSB06012		Flange hd hex. bolt	2
198	38002007	190后端罩	End cover	1
199	LZA10265	电机螺栓	Shoulder bolt	1
200	TDA10		Spring washer	1
200-2			Washer	1
201	PDC010	大平垫10	Washer	1
202	38002003	电机轴承	Ball bearing	1
203	65002100	120/240V,60HZ 转子总成	Rotor ass'y	1
204	38002002	风叶(塑料)	Alternator fan	1
205	LSB08032		Flange hd hex. bolt	4
205-2		弹簧垫片	Spring washer	4
205-3			Washer	4
206	LSB05012		Flange hd hex. bolt	4
207	38002001	190前端盖	Front cover	1
208	65002200	120/240V,60HZ 铜线定子总成	Stator	1
209	65002004		Protection for stator	1
210	38020005	190后端盖	Rear cover	1
211	38002400	接线板	Terminal block	1
212	LSB05012		Flange hd hex. bolt	2
213	25002006		Carbon brush	2
214			Flange hd hex. bolt	2
218	LSB05012		Flange hd hex. bolt	1
219	38002300	AVR	AVR	1
219-2	25002006	碳刷	Carbon brush	1
220	LSB05012		Hex. bolt	2
221	LSB06179	固定后端盖法兰螺栓	Hex. bolt	4
222			Washer	4
223			Spring washer	4
224			Flange hd hex. nut	6
225	34006208	压板轴位螺钉	Shoulder bolt	1
226	34006207	棘爪压板	Spring lid	1
227	34006206	摩擦弹簧	Small spring lid	1
228		压缩弹簧	Compression spring	1
229		弹簧垫片	Washer	2
230	34006205	起劲棘爪	Ratchet	2
231	34006204	棘爪弹簧	Ratchet spring	2
232	34006203	起劲拉盘	Rope Reel	1
233	34006202	蜗卷盘簧	Spiral spring	1
234			Spring washer	2
235			Washer	2
236			Spring washer	1
237			Flange hd hex. bolt	1
238			Flange hd hex. bolt	1
239			Self tapping screw	2
240			Spring washer	2
241			Flange hd hex. bolt	2
243			Flange hd hex. bolt	1
244			Spring washer	4
245			Hex. nut	4



