

5475 Набор для вплетения бисера в волосы

Перед вами –целая студия дизайна для волос с настоящим рабочим прибором! Всего за несколько минут вы можете создать ваш неповторимый дизайн из вплетённого в волосы бисера и стать законодателем моды!

В комплект входят:

Приспособление для нанизывания бисера на волосы, 100 больших бисеринок различных цветов, 100 маленьких бисеринок различных цветов, 30 цветных резинок, 1 расчёска.

Переключатель в разные направления, отсек для 2 батареек, стоппер, металлическая проволока для нанизывания бисера, крючок для разделения прядей, рычаг для продвижения бисеринок.

Инструкция.

1. Вставьте 2 батарейки типа АА (в комплект не входят) в отделение для батареек. Чтобы открыть отсек батареек, отодвиньте крышку. (см. рис. 1)
2. Как следует расчешите волосы.
3. Передвиньте переключатель так, чтобы рычаг для продвижения бисеринок оказался в самом нижнем положении, а стоппер находился ниже крючка для разделения прядей.
4. Нанижите бисеринки на проволоку для нанизывания: первыми нанижите маленькие бисеринки, затем продолжите бисеринкам и выбранных вами цветов и размеров. (см. рис 3)

Примечание: Если волосы короткие, не нанизывайте слишком много бисера.

5. Возьмите небольшую прядь из центра и положите её на крючок в конце проволоки для нанизывания.
6. Держите прядь волос прямо и передвигайте переключатель вверх, пока все бисеринки не нанижутся на волосы (см. рис. 5)






Примечание: Если волосы короткие, несколько бисеринок может остаться в приборе.

7. Пропустите прядь волос под самой нижней бисеринкой, придерживая её на месте. Аккуратно и осторожно потяните волосы, чтобы освободить их из машинки (см. рис. 6)
8. Затяните конец пряди резинкой.

Все права защищены – Creative Toys Ltd – с 2019 года.
Категорически запрещено любое использование
компонентов набора, включая данные
инструкции, без разрешения фирмы Creative Toys Ltd в
письменном виде.

7. Gently pull the tool away from the scalp, so that the now doubled over lock of hair will straighten out and be released from the tool. Quickly grasp the lock of hair, after the last bead, so that the beads will not slid off. See Figure 8.

8. Put a rubber band on the lock of hair to hold the beads in place (the rubber band should be situated in a location on the lock of hair, above which you want the row of beads). See Figure 9.



If at any time in the future you should need to dispose of this product please note that waste composed of electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice. (Waste Electrical and Electronic Equipment Directive).

You may not reproduce, copy, photograph, record, translate, store in a database, or transmit in any form or means, electronic, optic or mechanic or other, any part of the material in these instructions. Commercial use, of any type, of material contained in these instructions is strictly forbidden except for permission in writing given from CREATIVE TOYS LTD.

2014 Small World Toys®, 1451 W. Knox Street, Torrance, CA 90501
Small World® and Small World Toys® are trademarks of Small World Toys.
©2006 Creative Toys Ltd. All rights reserved.
Components manufactured in China. Printed and assembled in Israel.
Conforms to EN 71, CPSIA and ASTM Requirement.
Keep this information for future reference. Product colors and content may vary.



See you at
www.smallworldtoys.co