

MAIN

| V500 spare parts list | | | | |
|-----------------------|--------------|-------------------------------|-----|----|
| NO. | Chinese Name | English Name | QTY | 备注 |
| 1 | 旋耕刀焊接盘 | Blade jointing Set | 2 | |
| 2 | 内六角螺钉 M6x20 | Inner Hexangular Screw M6x20 | 9 | |
| 3 | 输出轴衬套 | Output Axis Bush | 2 | |
| 4 | 防尘罩 | dustproof Cover | 2 | |
| 5 | 变速箱壳体R | Transmission Case R | 1 | |
| 6 | 油封 FA25x40x7 | Close Oil FA25x40x7 | 2 | |
| 7 | 轴承 30204 | Bearing 30204 | 1 | |
| 8 | 轴用挡圈 25 | Snap Washer-Shaft 25 | 2 | |
| 9 | 蜗轮 | Worm Wheel | 1 | |
| 10 | 平键 A6 x28 | Key A6x28 | 1 | |
| 11 | 输出轴 | Output Axis | 1 | |
| 12 | 卡子2.5 | Clip 2.5 | 2 | |
| 13 | 输出轴铆钉 | Worm Wheel rivet | 2 | |
| 14 | 锁紧螺母 M8 | Locknut M8 | 8 | |
| 15 | 自攻螺钉 St6x12 | Sheet Metal Screw St6x12 | 8 | |
| 16 | U形弯管 | U Shape Syphon | 1 | |
| 17 | 前板 | Front Plant | 1 | |
| 18 | 旋耕刀R | Blade R | 12 | |
| 19 | 螺母 M10 | Nut M10 | 32 | |
| 20 | 旋耕刀L | Blade L | 4 | |
| 21 | 螺栓 M10x20 | Bolt M10x20 | 34 | |
| 22 | 螺栓 M8x12 | Bolt M8x12 | 2 | |
| 23 | 锁紧螺母 M6 | Locknut M6 | 11 | |
| 24 | 变速箱壳体L | Transmission Case L | 1 | |
| 25 | 多楔带 7PJ414 | Belt 7PJ414 | 1 | |
| 26 | 螺栓 M8x40 | Bolt M8x40 | 4 | |
| 27 | 大垫 8 | Big Washer 8 | 6 | |
| 28 | 机座 | Machine Seat | 1 | |
| 29 | 聚胺脂垫圈 9 | Plastic Washer 9 | 3 | |
| 30 | 汽油机 | Gasoline Engine | 1 | |
| 31 | 螺栓 M8x45 | Bolt M8x45 | 4 | |
| 32 | 锁紧螺母 M5 | Locknut M5 | 8 | |
| 33 | 护板 | Protective Shutter | 1 | |
| 34 | 螺钉 M5x12 | Screw M5x12 | 8 | |
| 35 | 油门拉线 | Accelerograph String | 1 | |
| 36 | 离合器拉线 | Clutch String | 1 | |
| 37 | L形右弯管 | L Shape Right Syphon | 1 | |
| 38 | 螺母 M8 | Nut M8 | 2 | |
| 39 | 旋柄 | Revolving Handle | 2 | |
| 40 | 平垫 8 | Washer 8 | 5 | |
| 41 | 卡套 | Clip Cover | 4 | |
| 42 | 卡座 | Clip Seat | 4 | |
| 43 | 线卡 | Line Clip | 3 | |
| 44 | 刹车手把组件 | Brake Armguard Hold Assembly | 1 | |
| 45 | 内六角螺钉 M6x40 | Inner Hexangular Screw M6x40 | 1 | |
| 46 | 止转螺栓 M6x60 | Stop Turn Bolt M6x60 | 1 | |
| 47 | 手把套 | Handle Cover | 2 | |
| 48 | 油门手把组件 | Accelerograph Handle Assembly | 1 | |
| 49 | V形弯管 | V Shape Syphon | 1 | |
| 50 | 螺栓 M8x100 | Bolt M8x100 | 2 | |
| 51 | 卡簧 | Clip Reed | 1 | |
| 52 | 定位手把 | Orientation Handle | 1 | |
| 53 | L形左弯管 | L Shape Right Syphon | 1 | |
| 54 | 脚轮调整手把 | Wheel Adjustive Handle | 1 | |

MAIN

| | | | | |
|----|---------------|---------------------------------|---|--|
| 55 | 拉簧 | Taut Reed | 1 | |
| 56 | 螺栓 M8x20 | Bolt M8x20 | 1 | |
| 57 | 后支架焊接件 | Back Bracket | 1 | |
| 58 | 脚轮 | Wheel | 2 | |
| 59 | 脚轮套管 | Wheel Cover Pipe | 2 | |
| 60 | 六角发兰面锁紧螺母 M10 | Hex Flang Locknut M10 | 2 | |
| 61 | 轮支架 | Wheel Bracket | 1 | |
| 62 | 脚轮调整压块 | Wheel Adjustive Block | 1 | |
| 63 | 旋耕刀外护板 | Blade Outer Protective Shutte | 2 | |
| 64 | 脚轮盖 | Wheel Cover | 2 | |
| 65 | 螺栓 M10x60 | Bolt M10x60 | 2 | |
| 66 | 平垫 10 | Washer 10 | 4 | |
| 67 | 外齿锁紧垫圈 10 | Outer Tooth Washer 10 | 2 | |
| 68 | 变速箱盖板 | Transmission Case Cover | 1 | |
| 69 | U形固定板左 | U Shape Left Fixed Plank | 1 | |
| 70 | U形固定板右 | U Shape Right Fixed Plank | 2 | |
| 71 | 六角螺栓 M8x260 | Bolt M8x260 | 2 | |
| 72 | 蜗杆 | Worm | 1 | |
| 73 | 销轴 10x60 | Pin 10x60 | 2 | |
| 74 | 滚动轴承 6005 | Bearing 6005 | 2 | |
| 75 | 隔套 | Isolated Cover | 2 | |
| 76 | 螺栓 M8x60 | Bolt M8x60 | 1 | |
| 77 | 螺栓帽 | Bolt Cap | 1 | |
| 78 | 六角法兰面锁紧螺母 M8 | Hex Flang Locknut M8 | 8 | |
| 79 | 螺栓 M8x50 | Bolt M8x50 | 1 | |
| 80 | 弹簧心轴 | Spring Axis | 1 | |
| 81 | 涨紧轮弹簧 | Pulley Tightener Spring | 1 | |
| 82 | T型板 | T Shape Plank | 1 | |
| 83 | 变速箱带轮 | Transmission Case Pulley | 1 | |
| 84 | 轴承 608-2Z | Bearing 608-2Z | 2 | |
| 85 | 螺钉 M5x8 | Screw M5x8 | 2 | |
| 86 | 滚动轴承 6004 | Bearing 6004 | 1 | |
| 87 | 平垫 5 | Washer 5 | 2 | |
| 88 | 弹性圆柱销 5x40 | Lock Pin 5X40 | 1 | |
| 89 | 皮带护板 | Strap Protective Shutte | 1 | |
| 90 | 紧定螺钉 M8x12 | Fixed Screw M8x12 | 2 | |
| 91 | 发动机带轮 | Engine Pully | 1 | |
| 92 | 涨紧轮隔套 | Pulley Tightener Isolated Cover | 1 | |
| 93 | CVD50涨紧轮 | CVD50 Pulley Tightener | 1 | |