

T425

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar

A T425 BRAKE ASSY




Page A T425 BRAKE ASSY				
Position	Article	Quantity	Description	Kit
1	505 05 04-01	1	BRAKE ASSY	
3	505 05 06-01	1	GUARD	1
4	505 05 07-01	1	SPRING	1
5	505 05 08-01	1	SCREW	1
6	505 05 09-01	1	SPACER	1
7	505 05 10-01	1	SPACER	1
8	505 05 11-01	1	WEIGHT	1
9	505 05 12-01	1	SPRING	1
10	505 05 13-01	1	SPRING	1
11	505 05 14-01	1	WASHER	1
12	505 05 15-01	1	NUT	1
13	505 05 16-01	1	LEVER C	1
14	505 05 17-01	1	ROLLER	1
15	505 05 18-01	1	ARM	1
16	505 05 19-01	1	BAND	1
17	505 05 20-01	1	ROLLER	1
18	505 05 21-01	1	SPRING	1
19	505 05 22-01	1	COVER. SPRING	1
20	505 05 23-01	4	SCREW	1
21	505 05 24-01	1	PLATE(B)	1
22	505 05 25-01	1	SCREW	1
23	505 05 26-01	1	NUT	1
24	505 05 27-01	1	GEAR	1
25	505 05 28-01	1	NUT	
26	505 05 90-01	1	DECAL. CLUTCH COVER	

B T425
CLUTCH ASSY
OIL PUMP ASSY




Page B T425 CLUTCH ASSY, OILPUMP ASSY				
Position	Article	Quantity	Description	Kit
1	505 04 46-01	1	PIPE COMP	
2	505 04 47-01	1	PIPE	1
3	505 04 48-01	1	JOINT	1
4	505 04 49-01	1	PIPE	1
5	505 04 50-01	1	CLIP	1
6	505 04 51-01	1	FILTER	1
7	505 04 52-01	1	RING	1
8	505 05 29-01	1	OIL PUMP ASSY	
10	505 05 31-01	1	WORM	8
11	505 04 16-01	2	SCREW	
12	505 05 33-01	1	WASHER	
13	505 05 35-01	1	PIPE	
14	505 05 36-01	1	COVER. PUMP	
15	505 04 70-01	2	SCREW	
16	525 61 52-01	1	CLUTCH DRUM 1/4" 8T	
16	525 61 53-01	1	CLUTCH DRUM 3/8 6T	
17	505 04 98-01	1	CLUTCH	
18	505 04 99-01	2	SHOE.CLUTCH	17
19	505 05 00-01	2	SPRING	17
21	505 05 02-01	1	PLATE	
22	505 05 03-01	1	BEARING	16
23	505 05 34-01	1	SEAL	

C T425
INTAKE




Page C T425 INTAKE				
Position	Article	Quantity	Description	Kit
1	505 06 04-01	1	PIPE SET	1
2	505 04 16-01	2	SCREW	2
3	505 05 84-01	1	ROD. CHOKE	1
4	505 05 85-01	1	GROMMET	1
5	505 05 50-01	1	CARBURETOR ASSY	1
6	505 05 81-01	1	SEAL	1
7	505 05 82-01	1	PLATE.BASE	1
8	505 05 86-01	1	PLATE	1
9	505 05 83-01	2	SCREW	2
10	505 05 87-01	1	CLEANER	1
11	505 05 88-01	1	ELEMENT	1
12	505 04 92-01	1	COVER COMP	1
13	505 04 93-01	1	KNOB. CLEANER	1
14	505 04 94-01	1	GROMMET	1

D T425
STARTER ASSY



Page D T425 STARTER ASSY				
Position	Article	Quantity	Description	Kit
1	505 05 38-01	1	STARTER ASSY	
2	505 05 39-01	1	STARTERCOVER COMP	1
3	505 15 18-01	1	STARTERCOVER	1, 2
4	537 28 32-01	1	REINFORCEMENT SLEEVE	1, 2
5	505 05 40-01	1	REEL	1
6	505 05 41-01	1	SPRING	1
7	505 05 42-01	1	ROPE	1
8	505 05 43-01	1	KNOB	1
9	505 05 44-01	1	WASHER	1
10	505 04 76-01	1	SCREW	1
11	505 05 46-01	1	COVER	1
12	505 05 47-01	1	PIPE	1
13	505 04 70-01	1	SCREW	1
14	505 15 19-01	1	GUIDE	1
15	505 15 20-01	1	SCREW	1
16	505 04 70-01	4	SCREW	
17	505 05 91-01	1	DECAL. STARTER	


E T425
ROTOR ASSY
MODULE ASSY



Page E T425 ROTOR ASSY, MODULE ASSY				
Position	Article	Quantity	Description	Kit
1	505 04 15-01	1	NUT	
2 *	525 73 84-01	1	FLYWHEEL ASSY	
3	505 04 22-01	2	PAWL	2
4	505 04 23-01	2	SPRING	2
5	505 04 24-01	2	SCREW	2
6	505 04 25-01	2	WASHER	2
7 *	525 73 81-01	1	MODULE ASSY	
10	525 61 55-01	1	CAP	7
12	505 04 33-01	1	GROMMET	7
13	505 04 34-01	2	SPACER	
14	505 04 35-01	2	BOLT	
15	503 23 51 08	1	Spark plug RCJ7Y	
16	505 04 37-01	1	CORD	
17	505 04 38-01	1	CORD	


* See Service Bulletin B0900015

F T425
MUFFLER ASSY




Page F T425 MUFFLER ASSY				
Position	Article	Quantity	Description	Kit
1	505 04 17-01	1	MUFFLER	
2	505 04 20-01	1	PLATE	
3	505 04 18-01	1	GASKET	
4	505 04 19-01	2	SCREW	


G T425
HANDLE ASSY



Page G T425 HANDLE ASSY				
Position	Article	Quantity	Description	Kit
1	505 04 73-01	1	HANDLE ASSY	
2	505 04 74-01	1	STOPPER	1
3	505 04 75-01	1	DAMPER	1
4	505 04 76-01	1	SCREW	1
5	505 04 76-01	2	SCREW	
6	505 04 95-01	1	BOLT	
7	505 04 96-01	1	CAP	




Page H T425 HANDLE COMP				
Position	Article	Quantity	Description	Kit
1	505 04 36-01	1	SWITCH	
2	505 04 85-01	1	ELBOW	
3	505 04 82-01	2	PIPE	
4	505 04 84-01	1	PIPE	
5	505 04 83-01	2	JOINT	
6	505 04 89-01	1	ROD. THROTTLE	
7	505 04 78-01	1	HANDLE COMP	
8	505 04 79-01	1	LEVER	7
9	505 04 80-01	1	SPRING	7
10	505 04 81-01	1	SPRING PIN	7
11	505 04 86-01	1	STOPPER	
12	505 04 88-01	1	ARM	
13	505 04 90-01	1	COVER	
14	505 04 70-01	1	SCREW	
15	505 04 87-01	1	DAMPER	
16	505 04 95-01	1	BOLT	
17	505 04 96-01	1	CAP	

J**T425
CASE COMP**


Page J T425 CASE COMP				
Position	Article	Quantity	Description	Kit
1	505 04 39-01	1	CASE COMP	
2	505 04 40-01	2	SCREW	1
3	505 04 68-01	4	SCREW	
4	505 04 57-01	1	COVER, FRONT	
5	505 04 70-01	2	SCREW	
6	505 04 41-01	1	PIPE ASSY	
7	505 04 42-01	1	PIPE	6
8	505 04 43-01	1	GROMMET	6
9	505 04 44-01	1	FILTER	6
10	505 04 45-01	1	COLLAR	6
11	505 04 53-01	1	BREATHER	
12	505 04 54-01	1	GROMMET	
13	505 04 58-01	1	PUMP	
14	505 04 59-01	1	PIPE	
15	505 04 60-01	1	FUELCAP ASSY	
16	505 04 61-01	2	GASKET	16, 35
17	505 04 69-01	1	COVER	
18	505 04 70-01	1	SCREW	
19	505 04 71-01	1	MAT	
20	505 05 89-01	1	DECAL. WARNING SIGNS	
21	505 04 66-01	1	CATCHER	
22	505 04 67-01	1	SCREW	
23	505 04 64-01	1	PLATE	
24	505 04 65-01	1	SEAL	23
25	505 04 55-01	1	VALVE	
26	505 04 56-01	1	SEAL	
27	505 04 75-01	1	DAMPER	
28	505 04 95-01	1	BOLT	
29	505 04 96-01	1	CAP	
30	505 04 72-01	1	SCREW	
31	505 05 92-01	1	EYELET	
32	505 04 70-01	2	SCREW	
33	505 15 21 01	1	EYELET	
34	505 05 23-01	1	SCREW	
35	505 04 62-01	1	OILCAP ASSY,	

K T425
CYLINDER COMP




Page K T425 CYLINDER COMP				
Position	Article	Quantity	Description	Kit
1	525 61 60-01	1	CYLINDER COMP	
2	505 04 00-01	1	ELBOW	1
3	525 61 59-01	1	PISTON COMP	1
4	505 04 06-01	1	RING.PISTON	1, 3
5	505 04 08-01	2	RING	1, 3
6	505 04 05-01	1	PISTON	1, 3
7	505 04 09-01	1	BEARING	1
8	505 04 02-01	1	CLIP	
9	505 04 01-01	1	PIPE	
10	505 04 03-01	1	CRANKCASE	
11	505 04 04-01	4	BOLT	




L T425
CRANK SHAFT



Page L T425 CRANK SHAFT				
Position	Article	Quantity	Description	Kit
1	525 61 61-01		CRANKSHAFT COMP	
2	505 04 12-01	2	BEARING	1
3	505 04 09-01	1	BEARING	1
4	505 04 10-01	2	WASHER	1
5	505 04 13-01	1	SEAL	
6	505 04 14-01	1	SEAL	
7	544 26 00-01	1	KEY	



Page M T425 CARBURETOR				
Position	Article	Quantity	Description	Kit
1	505 05 50-01	1	CARBURETOR ASSY	
2	505 05 51-01	1	SCREEN	1
3	505 05 52-01	1	COVER	1
4	505 05 53-01	1	SCREW	1
5	505 05 54-01	1	GASKET	1, 37
6	505 05 55-01	1	DIAPHRAGM	1, 37
7	505 05 56-01	1	VALVE.INLET	1
8	505 05 57-01	1	SPRING	1
9	505 05 58-01	1	PIN	1
10	505 05 59-01	1	SCREW	1
11	505 05 60-01	1	LEVER	1
12	505 05 61-01	1	COVER	1
13	505 05 62-01	1	PLUG	1
14	505 05 63-01	1	GASKET	1, 37
15	505 05 64-01	1	DIAPHRAGM	1, 37
16	505 05 65-01	1	RING	1
17	505 05 66-01	1	VALVE	1
18	505 05 67-01	3	SCREW	1
19	505 05 68-01	1	SPRING	1
20	505 05 69-01	1	SHAFT	1
21	505 05 70-01	1	SCREW	1
22	505 05 71-01	1	SPRING.IDLE	1
23	505 05 72-01	1	LEVER	1
24	505 05 73-01	1	SCREW	1
25	505 05 74-01	1	VALVE	1
26	505 05 75-01	1	SPRING	1
27	505 05 76-01	1	SHAFT	1
28	505 05 77-01	1	BUSHING	1
29	505 05 78-01	1	SCREW ASSY	1
30	505 13 42-01	1	NEEDLE	1
31	505 13 43-01	2	CAP	1
33	505 13 41-01	1	NEEDLE	1
34	505 05 79-01	1	SPRING	1
35	505 05 80-01	1	PISTON	1
36	506 12 30-01	1	STOP	1
37	505 06 01-01	1	GASKET KIT	



Page N T425 ACCESSORIES				
Position	Article	Quantity	Description	Kit
1	505 05 94-01	1	COMBI TOOL	
2	505 06 05-01	1	GUIDE BAR COVER	
3	505 06 02-01	1	SPIKE KIT	