

INVOLIGHT

**SM2000
POWER SNOW MACHINE**

USER MANUAL

Please read over this manual before operation the machine 

Thanks for using the Snow Machine. For assuring your safety and using the machines well, please read over this instruction carefully before operation.

Information:

Voltage: 220V, 50-60HZ

Power consumption: 1500W

Approx. Snow Flake Output: 100m3

High of Blow: upwards of 15m

Fluid consumption: approx. 350 ml/min.

Used Fluid: Snow fluid

Size: 62x58x97cm

Weight: 33kg

Continuous working

Operation:

1. Open the flight-case and put out the snow machine.
2. Put the machine to the best flatness position.
3. According to your needs, choosing the shooting angle of the machine.
4. Put the feeding fluid pipe into the bottle of snow liquid.
5. To work the machine, please turn on the power of fan first, and then press the switch of the snow.
6. To stop the machine, you must stop the snow swift, and then turn off the fan.

Attention :

1. The power must same as located.
2. Turn off the machine and disconnect from current if not used or nobody is with it. Moreover, the machine is designed for adult use only. Install away from children.
3. Please use the high quality Snow Liquid.

4. Don't spray the snow directly to people.
5. Power off before the snow liquid is used up.
6. A certain noise is within common range when the machine is working.
7. Keep clean.

Function

