

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Lincoln dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.

Lincoln Customer
Relationship Center

U.S. 1-800-521-4140
(TDD for the hearing
impaired 1-800-232-5952)
lincolnowner.com

Ford of Canada's Lincoln
Customer Relationship Centre

Canada 1-800-387-9333
lincolncanada.com



LEARN MORE ABOUT YOUR NEW LINCOLN MKT
lincolnowner.com (U.S.) / lincolncanada.com (Canada)

LEARN HOW TO SYNC YOUR RIDE: SYNC is a voice-activated technology personalized by you. It is a hands-free, voice recognition system used for entertainment, information and communication.

SyncMyRide.com (U.S.) / SyncMyRide.ca (Canada)

WARNING

Driving while distracted can result in loss of vehicle control, accident and injury. Ford Motor Company strongly recommends that drivers use extreme caution when using any device or feature that may take their focus off the road. Your primary responsibility is the safe operation of the vehicle. We recommend against the use of any hand-held device while driving, encourage the use of voice-operated systems when possible and that you become aware of applicable state and local laws that may affect the use of electronic devices while driving.



Lincoln MKT
August 2012
Second Printing
Quick Reference Guide
Litho in USA

DE9J 19G217 AA



2013 QUICK REFERENCE GUIDE



LINCOLN MKT

MKT COMMONLY USED VOICE COMMANDS

SYNC® ...Say the Word.

Touch the  button on the right-hand side of your steering wheel, and then say:



Basic Commands

- ▶ What can I say?
- ▶ List of commands
- ▶ Main menu
- ▶ Previous
- ▶ Next
- ▶ Go back
- ▶ Exit
- ▶ Help
- ▶ Vehicle health
- ▶ Pair my phone



Phone

- ▶ Phone list of commands
- ▶ Dial
- ▶ Call <name> on cell/at home/at work
- ▶ Call voicemail
- ▶ Do not disturb<On/Off>
- ▶ Listen to text messages (phone-dependent feature)



Climate

- ▶ Climate control list of commands
- ▶ Climate <On/Off>
- ▶ Climate my temperature
- ▶ Climate temperature <60-85> degrees



SYNC Services

Must say "Services" first, and then "What can I say?"

- ▶ Traffic
- ▶ Directions
- ▶ Business search
- ▶ Operator (for direction or business search)
- ▶ Favorites
- ▶ News, sports, weather, horoscopes, stock quotes, movies or travel
- ▶ Help



Entertainment

- ▶ Audio list of commands
 - You can also get detailed lists of commands for radio, USB, Bluetooth® audio, Sirius and SD Card
- ▶ Audio <On/Off>
- ▶ Radio
 - FM <87.7-107.9>
 - FM preset <#>
- ▶ CD
 - Play track <1-152>
 - Shuffle <On/Off>
- ▶ USB
 - Play song <name>
 - Play album <name>
- ▶ SiriusXM
 - <channel name>
 - Preset <#>



Navigation

Navigation list of commands (if equipped)"

- ▶ Destination street address <number, name, city>
 - ▶ Destination home
 - ▶ Navigation voice <On/Off>
 - ▶ Navigation volume <increase/decrease>
 - ▶ Repeat instruction
 - ▶ Show <map/north-up/heading-up/3D>
- Travel Link list of commands
- ▶ Traffic
 - ▶ Weather
 - ▶ Movie Listings
 - ▶ Fuel prices
 - ▶ Sports <headlines: scores/schedule>

TABLE OF CONTENTS



INSTRUMENT PANEL	4-5
SYNC WITH MYLINCOLN TOUCH	6-9
CONVENIENCE	10
COMFORT	11
ESSENTIAL INFORMATION	12-13
FUNCTION	14-15

SMARTER THAN
LUXURY

Some services may not be available in your area. For additional support, refer to your *Owner's Manual*, visit the website or call the toll-free number. **U.S. customers:** Visit SyncMyRide.com or call 1-800-392-3673 (select Option 1 or 2 for language, then press 3). **Canadian customers:** Visit SyncMyRide.ca or call 1-800-565-3673 (select Option 1 or 2 for language, then press 3).



INSTRUMENT PANEL

{ LINCOLN MKT

1 POWER TILT/TELESCOPE STEERING COLUMN:

Your power tilt steering column has a four-way rocker control which allows you to adjust the steering wheel to the desired position.

2 CRUISE CONTROL:

To set your cruise control speed:

1. Press the **ON** control up and release.
2. Accelerate to the desired speed.
3. Press the **SET** control up and release, then take your foot off the accelerator.

- ▶ After your speed has been set you can press **SET +/-** to adjust cruise speed up or down. To disable, press the **OFF** control down.

ADAPTIVE CRUISE CONTROL*:

Allows you to set a 'gap distance' between yourself and the vehicle in front of you during highway driving. When your cruise control is active, press **GAP** up or down to select the gap distance. Refer to the *Cruise Control* chapter of your *Owner's Manual* for more information.

Note: *Driving aids do not replace the need to watch where the vehicle is moving and brake where necessary. Refer to your Owner's Manual for safety information, more details and limitations.*

3 LEFT VEHICLE INFO DISPLAY:

Provides information about various systems on your vehicle. Use the left-hand 5-way controls located on the steering wheel to choose and confirm settings and messages. Refer to the *Information Displays* chapter in your *Owner's Manual* for more information.

4 SERVICE ENGINE SOON LIGHT:


illuminates briefly when the ignition is turned on. If it remains on or is blinking after the engine is started, the on-board diagnostics system (OBD-II) has detected a malfunction. Drive in a moderate fashion and contact your authorized dealer as soon as possible.


5 RIGHT VEHICLE INFO DISPLAY:

Displays information about Entertainment, Phone, Navigation and Climate. Use the right-hand 5-way controls located on your steering wheel to scroll through, highlight and make minor adjustments within a selected menu. Refer to the *MyLincoln Touch™* chapter in your *Owner's Manual* for more information.

6 STEERING WHEEL AUDIO CONTROLS:

Press **VOL +/-** to increase/decrease volume levels. Press **SEEK ▲ / ▼** to access the next/previous radio station preset, CD track or preset satellite radio channel*.

 : Press to access SYNC* phone features.

 : Press to access voice recognition.

7 PUSH BUTTON START:

Allows you to start your vehicle by pressing the **ENGINE START/STOP** button while fully pressing down on the brake pedal. Press the button again to turn the engine off.

Note: *Your intelligent access key* must be inside the vehicle for the ignition to start.*

8 HAZARD CONTROL

9 AUDIO VOLUME AND FAN SPEED SWIPE CONTROLS:

Simply swipe your finger to adjust audio volume or fan speed with the touch sensitive slide bars.

* if equipped

USING SYNC WITH MYLINCOLN TOUCH




SYNC is a hands-free, voice recognition system used for entertainment, information and communication.

Use the four-corner, four-color touch screen to explore and interact with your vehicle. The touch screen works the same way traditional controls, knobs and buttons do.

Simply press the various corners on your touch screen to personalize the many features and settings of your vehicle all in one place. The system provides easy interaction with your cellular phone, multimedia entertainment, climate controls and navigation system.


GENERAL TIPS

- ▶ Press the home  icon at any time to return to the home screen.
- ▶ For additional support, refer to your Owner's Manual, visit the website or call the toll-free number. See the inside front cover of this guide for more details.

BEFORE YOU GET STARTED:

- ▶ If you have the navigation SD card, make sure that it is inserted into the media port or your navigation will not work.
- ▶ The touch screen is sensitive, so make sure you press the desired icon accurately and firmly.

CREATE YOUR OWNER ACCOUNT:

1. Set up your owner account at SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada). Register by following the on-screen instructions. After registering, you can see what complimentary services you are eligible for.
2. SYNC uses a wireless connection called  Bluetooth® to communicate with your phone. Turn Bluetooth mode on in your phone's menu options. This lets your phone find SYNC. For more details on setting up your phone with SYNC, visit SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada), or your phone manufacturer's website.

WHY YOU NEED A SYNC OWNER ACCOUNT:

A SYNC owner account is required for Vehicle Health Report activation and the ability to view your reports online. You'll also be able to take advantage of all of SYNC's Services and personalization features, such as saving your Favorites and Points of Interest (POI). You'll receive the latest software updates that add new places, directions and information, and if you have questions, you'll get free customer support. Visit the website or call the toll-free number for more information. See the inside front cover of this guide for details.

PAIRING YOUR PHONE WITH SYNC:

1. Make sure that your vehicle is in (P) park and your radio and ignition are turned on.

2. Press the phone button. When the display indicates No Phone Found, press OK.
3. When Add Bluetooth Device? appears, press OK.
4. When Find SYNC appears in the display, press OK. When prompted, enter the PIN provided by SYNC into your phone.
5. The display will indicate when the pairing is successful.

Note: The system may prompt you to set your phone as the primary/favorite (the primary phone will receive messages and voice mails); download your phone book (this is required to use the full set of VOICE commands) and/or turn on 911 Assist®.

TIPS

- Make sure you accept SYNC's request to access your phone.
- To pair subsequent phones, please refer to Pairing Subsequent Phones in the SYNC chapter of your Owner's Manual.
- If you are experiencing pairing problems, try performing a clean pairing by deleting your services from SYNC, deleting the SYNC connection from your phone, and then repeating the Pairing Your Phone with SYNC process.

PHONE

Voice-control your phone to connect with many other features and SYNC services:

- ▶ Connect to SYNC Services for traffic, directions, business searches and information favorites.
- ▶ Connect to Operator Assist to help locate a listing or destination.
- ▶ Call for a Vehicle Health Report.
- ▶ Connects automatically with a 911 Operator in the event of an accident (feature must be on prior to an event).
- ▶ Transfer calls seamlessly from SYNC to phone as you get in or out of your vehicle.
- ▶ Refer to the SYNC chapter of your *Owner's Manual* for complete details.

USING MY PHONE WITH SYNC:

Note: Enter your phone book contacts with both first and last names to increase SYNC's ability to select the correct contact. Remember to say the contact name exactly as it's listed in your phone book.

Making a phone call: Use SYNC to make a phone call to anyone in your phone book by pressing the voice button. When prompted, give any of the following voice commands:

- Call <name>
- Call <name> at work
- Call <name> on mobile or cell
- Call <name> at home

For example, you could say "Call Jake Smith at home". SYNC repeats the command back to you and dials the number.

Note: You can also make phone calls by giving the voice command "Dial", then verbally saying the phone number.

Answering incoming calls: Whenever you have an incoming call, you will be able to see the name and number of the person calling in your display. Press ACCEPT on the touch screen or the phone button to answer an incoming call. You can hang up at any time by pressing and holding the phone button.

Ending the call: Press and hold the phone button.

Do not disturb mode: This feature blocks incoming calls and text messages, and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command "Do not disturb on" to enable and "Do not disturb off" to disable.

NAVIGATION*

Get started with your navigation system by pressing the upper-right, green corner. The available, voice-activated navigation system includes:

- ▶ SiriusXM Traffic
- ▶ SiriusXM Travel Link
- ▶ Global positioning satellite (GPS) technology
- ▶ 3-D mapping
- ▶ Turn-by-turn navigation

SET A DESTINATION

Set a destination on your touch screen by using a street address, city center, a place on the map or a Point Of Interest (POI). The easiest way, however, is by voice.

1. Press the voice button. When prompted say "Destination street address".
2. The system will ask you to say the full address and will display an example on-screen.

3. You can then speak the address naturally, such as: "One two three Main Street, Anytown".

You can also use the touch screen to enter a destination and narrow your choices by city or street as you type.

You can choose from up to three different types of routes:

- ▶ Fastest: Uses the fastest moving roads possible.
- ▶ Shortest: Uses the shortest distance possible.
- ▶ Eco (EcoRoute): Uses the most fuel efficient route.

TIPS

- ▶ Save your favorite locations by touching "Save to Favorites".
- ▶ Change your map views from Direction Headed, North Up or 3D.

CLIMATE

Control the temperature, airflow direction, fan speed and other climate features for you and your front passenger. Say "Climate temperature 72 degrees" and MyLincoln Touch will make the adjustment.

SET YOUR TEMPERATURE

- ▶ Touch the lower-right, blue Climate corner on the touch screen.
- ▶ Set your exact, desired temperature by using the + or - buttons.

ENTERTAINMENT

No matter how you store your music, SYNC makes it yours to enjoy when you're behind the wheel. Just press the lower-left, red corner of the touch screen. From here, you can easily go between AM/FM, Sirius and other media sources.

SET YOUR RADIO PRESETS

- ▶ Touch the Entertainment corner on the touch screen.
- ▶ Touch FM.
- ▶ Touch Direct Tune.
- ▶ Enter the desired station and touch Enter.
- ▶ Touch Presets and then touch and hold one of the memory preset buttons to save it. You'll hear a brief mute and the sound will return once the station is saved.

USING SYNC TO ACCESS DIGITAL MEDIA

SYNC has a media hub with multiple inputs, allowing you to access personal media from your digital devices. Plug in your USB media devices, such as phones and MP3 players, and use SYNC to play all of your favorite music.

Note: SYNC indexes your music; the more information that is stored on your USB device, the longer it takes SYNC to index.

USING VOICE COMMANDS TO PLAY MUSIC

1. Plug your media player into your USB port.
2. Press the voice button. When prompted say "USB", then follow up by saying one of the following voice commands:

- | |
|-------------------|
| Play all |
| Play next song |
| Play song <name> |
| Play album <name> |

3. You will hear the command repeated back to you and the selected item will play.

For more information, refer to the *MyLincoln Touch* chapter of your *Owner's Manual*. For support, visit the website or call the toll-free number. See the inside front cover of this guide for details.

CONVENIENCE


CONSOLE REFRIGERATOR/FREEZER*: Before using, flip the console lid forward and then remove the cover (make sure to reinstall the cover to help maintain the temperature). For the refrigerator, press the **COOL** control. In this mode, the system will cool to approximately 41°F (5°C). For the Freezer, press the **FREEZE** control. The system will cool to approximately 23°F (-5°C). Press the selected control again to turn the system off.


Note: Your ignition must be on for this system to operate.


MEMORY FUNCTION: Allows one touch recall of memory positions for the driver seat, power mirrors, steering column and power adjustable foot pedals. Use the memory controls located on the driver's door to program and then recall memory positions.


To Program position 1, press and hold the **1** button until you hear a chime. Use this same procedure to set positions **2** and **3** using the respective buttons. You can now use these controls to recall the set memory positions.


INTELLIGENT ACCESS (IA) REMOTE ENTRY ICONS:

Press  once to lock all doors. Press again within three seconds to confirm all doors are locked.

Press  once to unlock the driver's door. Press again within three seconds to unlock all doors.

Press  to activate the panic alarm. Press again or turn on the ignition to deactivate.

Press  twice within three seconds to open the liftgate.

Car finder: Press  twice within three seconds to locate your vehicle. The horn will chirp and the lamps will flash.

INTELLIGENT ACCESS (IA) KEY:




Note: Your intelligent access key must be within three feet of the vehicle for intelligent access to function properly.



To unlock and open the driver's door, pull the front exterior door handle. To lock the doors, touch the sensor button on the door handle. To unlock and open the liftgate,



press the exterior liftgate release button above the license plate.



The intelligent access key also contains a mechanical key blade, which can be used to unlock the driver door if necessary.

REMOTE START: Remote start allows you to start the engine from outside your vehicle using your transmitter. To start, press  and then press  twice within three seconds. Once inside, apply the brake while pressing the **ENGINE START/STOP** button. Shift into D (Drive) and go. If you have an integrated keyhead transmitter, simply insert the key into the ignition and turn the ignition on as you normally would before driving. To turn the engine off from outside the vehicle after using your remote start, press  once.

COMFORT



HEATED AND COOLED FRONT SEATS: To access, press the Climate corner on the touch screen. For heated front seats, press  repeatedly to cycle through the various heat modes and off. For cooled front seats, press  repeatedly to cycle through the various cooling modes and off.

SECOND-ROW HEATED AND COOLED SEATS*: These controls are located on the rear of the floor console. Press  continuously to cycle through the various heat modes and off. Press  repeatedly to cycle through the various cooling modes and off.



POWERFOLD® THIRD-ROW SEAT*: The third-row seat features a one-touch power operation that allows you to adjust the seats with the touch of a button. The buttons are located behind the third-row seats on the left-hand quarter trim panel. To use, press the **RH/BOTH/LH** button to select the right seat, the left seat or both seats you want to move. Then select the desired seat position:


- ▶ Press the **STOW** button to stow the seat into the tub floor.
- ▶ Press the **FOLD** button (the top portion of the



button) to fold the seat back down.




- ▶ Press the **NORMAL** button to return the seat to the normal seating position.

Note: The power folding seats work only when the vehicle is in P (Park) and the liftgate is open.

HEATED STEERING WHEEL*: Your vehicle may be equipped with a heated steering wheel. Press the  icon to turn this feature on and off.

Note: The wood trim will not heat between the 10 and 2 o'clock positions.



PANORAMIC VISTA ROOF® AND POWER SUNSHADES*: To open, press and release the overhead moonroof switch . The front and rear sunshades will open entirely, and the glass panel will open to the first position. Press  again to fully open. To close, pull the switch  down. The glass panel will stop at the first position. Pull again and hold to fully close the glass panel and the sunshades. To vent from a closed position, press the **TILT** button. To close from a venting position, pull the **TILT** button.

* if equipped



THX II® CERTIFIED AUDIO SYSTEM*:

Fourteen strategically positioned, high-performance speakers deliver a home theater sound right in your vehicle. The system will automatically make adjustments to volume and sound distribution, based on vehicle speed and external road noise.

TILTING HEAD RESTRAINTS: Your vehicle's front-row head restraints can be adjusted. Pull up to raise the head restraint. To lower, press the head restraint down while pressing and holding the guide sleeve adjust/release button. Tilt the head restraint forward for additional comfort by gently pulling the top of the head restraint. Once it is in the forward-most position, tilting it forward once more will release it to the upright position.

Note: Do not attempt to force the headrest backward after it has been tilted. Instead, continue tilting it forward until the headrest releases to the upright position.

FUEL-EFFICIENT TRANSMISSION:

Your vehicle has been designed to improve fuel economy by reducing fuel usage while coasting or decelerating. This may be perceived as a light to medium braking sensation when removing your foot from the accelerator pedal.

ROADSIDE ASSISTANCE:

Your new Lincoln MKT comes with the assurance and support of 24-hour emergency roadside assistance. To receive roadside assistance in the United States, call 1-(800)-241-3673. In Canada, call 1-(800)-665-2006.

FUEL TANK CAPACITY/ FUEL INFO:

Your vehicle has a 18.6 gallon (70.4L) fuel tank. Use only **UNLEADED** fuel or **UNLEADED** fuel blended with a maximum of 15% ethanol. Do not use fuel ethanol (E85), diesel, fuel-methanol, leaded fuel or any other fuel because it could damage or impair the emission control system.

EASY FUEL® SYSTEM:

With this system, you simply open the fuel door, insert the nozzle and begin fueling. It is self-sealing and therefore protected against dust, dirt, water, snow and ice. Wait 10 seconds from the time the refueling nozzle is shut-off until you remove the nozzle from the tank to allow residual fuel in the nozzle to drain into the tank. When using a portable fuel container, slowly insert the fuel funnel (located in the spare tire compartment), and pour the fuel into the funnel.



SOS POST-CRASH ALERT SYSTEM™:

Provides audible and visual alarms when a crash causes the deployment of airbags or the activation of the safety belt pretensioners. The turn signals will flash and the horn will sound. To deactivate, press the hazard flasher control or the panic button (⏏) on your remote transmitter.

COLLISION WARNING SYSTEM*:

This system is designed to alert the driver of certain collision risks. Radar sensors detect if vehicles ahead of you which

are moving in the same direction, may be a collision risk. The system will alert you with an audible chime and red warning light which will appear above the dash. If the risk of collision increases, the system will increase brake support to help reduce collision speed.

LOCATION OF SPARE TIRE AND TOOLS:

Your spare tire and tools are located beneath the third row seats under the floor panel (you will need to unseat the seats to access). The spare tire is designed for emergency use only and should be replaced as soon as possible. For complete details on changing your tire, refer to the **Changing a Road Wheel and Tires** section in the **Wheels and Tires** chapter of your **Owner's Manual**.

REAR WINDOW BUFFETING:




When one or both of your rear windows are open, you may hear a wind throb or buffeting noise. To alleviate this, simply lower a front window approximately 2-3 inches (5-8 centimeters).

TIRE PRESSURE MONITORING SYSTEM:

Your vehicle has a tire pressure monitoring system that illuminates a low tire pressure warning light (⚠) in your instrument cluster when one or more of your tires is significantly underinflated. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the **Inflating Your Tires** section in the **Wheels and Tires** chapter of your **Owner's Manual** for more information.



REAR VIEW CAMERA: This system provides a visual display of the area behind the vehicle. The display automatically appears in the touch screen when the vehicle is in R (Reverse) and uses green, yellow and red guides to alert you of your proximity to objects.

POWER LIFTGATE: Your liftgate has an automatic open and closing feature. To open remotely, press  twice on your remote control within three seconds. Press  twice again to close or reverse the movement. You can also operate the liftgate by pressing the  button on the instrument panel.



REVERSE SENSING SYSTEM: This system sounds a warning tone if there is an obstacle near the vehicle's rear bumper when the vehicle is in R (Reverse) and is traveling less than 3 mph (5 km/h). The warning tone will increase in frequency as the object gets closer.

*Note: Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your **Owner's Manual** for safety information, more details and system limitations.*



SELECTSHIFT AUTOMATIC TRANSMISSION: Gives you the ability to manually change gears, if you'd like. To use, move the gearshift lever from D (Drive) to S (Sport). Then, use the paddle shifter on your steering wheel to manually make shifts. Pull the right paddle (+) to upshift, pull the left paddle (-) to downshift.



BLIS® (BLIND SPOT INFORMATION SYSTEM) WITH CROSS TRAFFIC ALERT (CTA)*: BLIS uses radar sensors to help you determine if a vehicle may be in your blind spot zone. The CTA feature alerts you if a car is coming toward you when you are backing out of a parking space. BLIS and CTA will display a yellow indicator light in your exterior mirrors and the CTA will also sound tones and display messages to warn you which direction vehicles are approaching. Refer to the *Driving Aids* chapter in your **Owner's Manual** for more information.

*Note: Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your **Owner's Manual** for safety information, more details and system limitations.*

UNIVERSAL GARAGE DOOR OPENER: Your driver's side visor has a built-in wireless transmitter that replaces the common hand-held garage door opener. This system can also be programmed to security systems, entry gates and home or office lighting. Refer to the *Universal Garage Door Opener* chapter in your **Owner's Manual** for programming instructions.



LANE KEEPING SYSTEM*: This system works to alert drivers of unintentional lane departures by providing vibration feedback in the steering wheel and/or steering torque feedback. This alert helps drivers steer back into the appropriate lane. Adjust your system settings as desired by Mode, Sensitivity, and Intensity* from your information display screen. Turn the feature on and off by pressing the button on your center console, in front of the shifter.



SECURICODE™ KEYLESS ENTRY SYSTEM: Allows you to lock or unlock the doors, recall memory features and arm or disarm the anti-theft alarm. To get started, you will need your five digit factory code found on your owner's wallet card (located in the glove box). Entering this code unlocks the driver's door. To lock all doors, press and hold **7•8** and **9•0** at the same time. For complete information, refer to the *SecuriCode Keyless Entry Keypad* section in the *Locks* chapter of your **Owner's Manual**.

* if equipped