

WARNING

Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.



United States
Lincoln Customer Relationship Center
1-800-521-4140
(TDD for the hearing impaired 1-800-232-5952)
lincolnowner.com

Canada
Lincoln Customer Relationship Centre
1-800-387-9333
lincolncanada.com

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Lincoln dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.

Lincoln MKT
January 2014
Second Printing
Quick Reference Guide
Litho in U.S.A.
EE9J 19G217 AA



2014 MKT



Quick Reference Guide




THE LINCOLN MOTOR COMPANY

Commonly Used Voice Commands

SYNC® Say the Word.

Table of Contents

2014 MKT

Touch the voice  button on the right-hand side of your steering wheel and then say:



Basic Commands

- ▶ What can I say?
- ▶ List of commands
- ▶ Main menu
- ▶ Previous
- ▶ Next
- ▶ Go back
- ▶ Exit
- ▶ Help
- ▶ Vehicle health
- ▶ Pair my phone



Phone

- ▶ Phone list of commands
- ▶ Dial
- ▶ Call <name> on cell/
at home/at work
- ▶ Call voicemail
- ▶ Do not disturb<On/Off>
- ▶ Listen to text messages
(phone-dependent feature)



Climate

- ▶ Climate control list
of commands
- ▶ Climate <On/Off>
- ▶ Climate my temperature
- ▶ Climate temperature
<60-85> degrees



SYNC Services*

Must say "Services" first, and then

- ▶ What can I say?
- ▶ Traffic
- ▶ Directions
- ▶ Business search
- ▶ Operator (for direction or
business search)
- ▶ Favorites
- ▶ News, sports, weather,
horoscopes, stock quotes,
movies or travel
- ▶ Help



Entertainment

- ▶ Audio list of commands
 - You can also get detailed
lists of commands for radio,
USB, **Bluetooth**® audio,
SiriusXM and SD card
- ▶ Audio <On/Off>
- ▶ Radio
 - FM <87.9-107.9>
 - FM preset <#>
- ▶ CD
 - Play track <1-512>
 - Shuffle <On/Off>
- ▶ USB
 - Play song <name>
 - Play album <name>
- ▶ SiriusXM
 - <channel name>
 - Preset <#>



Navigation*

- Navigation list of commands
 - ▶ Destination street address
<number, name, city>
 - ▶ Destination home
 - ▶ Navigation voice <On/Off>
 - ▶ Navigation volume
<increase/decrease>
 - ▶ Repeat instruction
 - ▶ Show <map/north-up/
heading-up/3D>
- Travel Link list of commands
 - ▶ Traffic
 - ▶ Weather
 - ▶ Movie listings
 - ▶ Fuel prices
 - ▶ Sports <headlines/
scores/schedule>

*if equipped

Instrument Panel.....	4 – 5
SYNC with MyLincoln Touch.....	6 – 9
Convenience.....	10
Comfort.....	11
Essential Information.....	12 – 13
Function.....	14 – 15



lincolnowner.com



lincolncanada.com

LEARN MORE ABOUT YOUR NEW MKT

Scan the country-appropriate QR code with your smartphone (make sure you have a scanner app installed) and you can access even more information about your vehicle.

Some services may not be available in your area. For additional support, refer to your Owner's Manual, visit the website or call the toll-free number. **U.S. customers:** Visit SyncMyRide.com or call **1-800-392-3673** (select Option 1 or 2 for language, then press 3). **Canadian customers:** Visit SyncMyRide.ca or call **1-800-565-3673** (select Option 1 or 2 for language, then press 3).



Instrument Panel

2014 MKT

1 Cruise Control

To set your cruise control speed:

- Press the **ON** control up and release.
- Accelerate to the desired speed.
- Press the **SET** control up and release, then take your foot off the accelerator.
 - After your speed has been set, you can press **SET +/-** to adjust cruise speed up or down.
 - To disable, press the **OFF** control down.

Adaptive Cruise Control*

Allows you to set a 'gap distance' between your vehicle and the vehicle in front of you during highway driving. When your cruise control is active, press **GAP** up or down to select the gap distance. Refer to the **Cruise Control** chapter of your **Owner's Manual** for more information.

Note: Driving aids do not replace the need to watch where the vehicle is moving and brake where necessary. Refer to your **Owner's Manual** for safety information, more details and limitations.


2 Power Tilt/Telescope Steering Column

Use the 4-way rocker control to adjust the steering wheel to the desired position.

3 Left Information Display

Provides information about various systems on your vehicle. Use the left-hand, 5-way controls located on the steering wheel to choose and confirm settings and messages. Refer to the **Information Displays** chapter in your **Owner's Manual** for more information.

4 Service Engine Soon Light

 Lights briefly when the ignition is turned on. If it remains on or is blinking after you start the engine, the On-Board Diagnostics (OBD-II) system has detected a malfunction. Drive in a moderate fashion and contact your authorized dealer as soon as possible.


5 Right Information Display

Provides information about Entertainment, Phone and Navigation*. Use the right-hand, 5-way controls located on your steering wheel to scroll through, highlight and make minor adjustments within a selected menu. Refer to the **MyLincoln Touch™** chapter in your **Owner's Manual** for more information.

6 Steering Wheel Controls

Press **VOL +/-** to increase/decrease volume levels. Press **SEEK ▲ / ▼** to access

the next/previous radio station preset, CD track or preset satellite radio channel*.

Press  to access SYNC® phone features.

Press  to access voice recognition.

7 Keyless Starting

Allows you to start your vehicle by pressing the **ENGINE START/STOP** button while fully pressing down on the brake pedal. Press the button again to switch the engine off. If your vehicle has been idling for an extended period of time, it will show an alert in the information display, giving a driver time to override the feature. If the driver does nothing, the engine automatically shuts down.

Note: Your intelligent access transmitter must be inside the vehicle for the ignition to start.

8 Hazard Control

9 Audio Volume and Fan Speed Swipe Controls

Press or tap the right or left side of the slider, or slide your finger across the control to increase or decrease the audio volume or fan speed.




Using SYNC with MyLincoln Touch

SYNC is a hands-free, voice recognition system used for entertainment, information and communication.

Use the four-corner, four-color touchscreen to explore and interact with your vehicle. The touchscreen works the same way traditional controls, knobs and buttons do.

Press the various corners on your touchscreen to personalize the many features and settings of your vehicle all in one place. The system provides easy interaction with your cellular phone, multimedia entertainment, climate controls and navigation system*.

General Tips


- ▶ Press the home  icon at any time to return to the home screen.
- ▶ For additional support, refer to your **Owner's Manual**, visit the website or call the toll-free number. See the inside front cover of this guide for more details.

Before You Get Started

- ▶ If you have the navigation SD card, make sure that it is inserted into the media port or your navigation will not work.
- ▶ The touchscreen is sensitive, so make sure you press the desired icon accurately and firmly.

Create Your Owner Account

1. Set up your owner account at SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada). Register by following the on-screen instructions. After registering, you can see what complimentary services you are eligible for.

2. SYNC uses  **Bluetooth®**, a wireless connection, to communicate with your phone. Turn **Bluetooth** mode on in your phone's menu options. This lets your phone find SYNC.

For more details on setting up your phone with SYNC, visit SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada), or your phone manufacturer's website.

Why You Need a SYNC Owner Account

A SYNC owner account is required for Vehicle Health Report activation and the ability to view your reports online. You'll also be able to take advantage of all the SYNC Services* and personalization features, such as saving your favorites and points of interest (POI). You'll receive the latest software updates that add new places, directions and information, and if you have questions, you'll get free customer support. Visit the website or call the toll-free number for more information. See the inside front cover of this guide for details.

Pairing Your Phone with SYNC

1. Make sure that your vehicle is in park (P) and your radio and ignition are turned on.
2. Touch **Add Phone** in the upper left corner of the touchscreen. **Find SYNC** appears on the screen and instructs you to begin the pairing process from your device.
3. Make sure that **Bluetooth** is set to **ON** and that your cellular phone is in the proper mode. See your phone's manual, if necessary. Select **SYNC**, and a six-digit PIN appears on your device.

4. If you are prompted to enter a PIN on your device, it does not support Secure Simple Pairing. To pair, enter the PIN displayed on the touchscreen. Skip the next step.
5. When prompted on your phone's display, confirm that the PIN provided by SYNC matches the PIN displayed on your cellular phone.
6. The display will indicate when the pairing is successful.

Note: SYNC may prompt you with more phone options. For more information on the capability of your phone, see your phone's manual and visit the website.

Tips

- ▶ Make sure you accept the request from SYNC to access your phone.
- ▶ To pair subsequent phones, please refer to **Pairing Subsequent Phones** in the **MyLincoln Touch** chapter of your **Owner's Manual**.
- ▶ If you are experiencing pairing problems, try performing a clean pairing by deleting your phone from SYNC, deleting the SYNC connection from your phone, and then repeating the **Pairing Your Phone with SYNC** process.

Phone

Voice-control your phone to connect with many other features and SYNC Services:



- ▶ Connect to SYNC Services for traffic, directions, business searches and information.
- ▶ Connect to Operator Assist to help locate a listing or destination.
- ▶ Call for a Vehicle Health Report.
- ▶ Connects automatically with a 911 Operator in the event of an accident (feature must be on prior to an event).
- ▶ Transfer calls seamlessly from SYNC to phone as you get in or out of your vehicle.

Refer to the **MyLincoln Touch** chapter of your **Owner's Manual** for complete details.

Using Your Phone with SYNC

Note: Enter your phone book contacts with both first and last names to increase the ability of SYNC to select the correct contact. Remember to say the contact name exactly as it is listed in your phone book.

Making a Phone Call

Use SYNC to make a phone call to anyone in your phone book by pressing the voice button. When prompted, say a voice command.

For example, you could say **“Call Jake Smith at home”**. SYNC repeats the command back to you and dials the number.

Note: You can also make phone calls by giving the voice command **“Dial”**, then verbally saying the phone number.

Answering Incoming Calls

Whenever you have an incoming call, you will be able to see the name and number of the person calling in your display. Press **ACCEPT** on the touchscreen or the phone button to answer an incoming call.

Ending the Call

Press and hold the phone button.

Do Not Disturb Mode

This feature blocks incoming calls and text messages, and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command **“Do not disturb on”** to enable and **“Do not disturb off”** to disable.

Navigation*

Get started with your navigation system by pressing the upper-right, green corner. The available, voice activated navigation system includes:

- ▶ SiriusXM Traffic
- ▶ SiriusXM Travel Link
- ▶ GPS (Global Positioning System) technology
- ▶ 3-D mapping
- ▶ Turn-by-turn navigation

Set a Destination

Set a destination on your touchscreen by using a street address, city center, a place on the map or a Point Of Interest (POI). The easiest way, however, is by voice.



1. Press the voice button. When prompted, say **“Destination street address”**.
2. The system will ask you to say the full address and will display an example on-screen.

3. You can then speak the address naturally, such as: **“One two three Main Street, Anytown”**.

You can also use the touchscreen to enter a destination and narrow your choices by city or street as you type.

You can choose from up to three different types of routes:

- ▶ **Fastest:** Uses the fastest moving roads possible.
- ▶ **Shortest:** Uses the shortest distance possible.
- ▶ **Eco (EcoRoute):** Uses the most fuel efficient route.

Tips

- ▶ Save your favorite locations by touching **“Save to Favorites”**.
- ▶ Change your map views from Direction Headed, North Up or 3D.

*if equipped

Climate

Control the temperature, airflow direction, fan speed and other climate features for you and your front passenger. Say **“Climate temperature 72 degrees”** and MyLincoln Touch will make the adjustment.



Set Your Temperature

- ▶ Touch the lower-right, blue Climate corner on the touchscreen.
- ▶ Set your exact, desired temperature by using the + or – buttons.

Rear Climate Controls

- ▶ Touch **Rear** on the lower-right corner of the Climate screen to access the rear climate control.
- ▶ Touch **Rear Control** to allow the rear passengers to adjust their climate settings. Touch it again to control the settings from the touchscreen. See your **Owner's Manual** for complete details.

Entertainment

No matter how you store your music, SYNC makes it yours to enjoy when you're behind the wheel. Just press the lower-left, red corner of the touchscreen. From here, you can easily go between AM/FM, Sirius and other media sources.



Set Your Radio Presets

- ▶ Touch the Entertainment corner on the touchscreen.
- ▶ Touch **FM**.
- ▶ Touch **Direct Tune**.
- ▶ Enter the desired station and touch **Enter**.
- ▶ Touch **Presets** and then touch and hold one of the memory preset buttons to save it.

You'll hear a brief mute and the sound will return once the station is saved.

Using SYNC to Access Digital Media

SYNC has a media hub with multiple inputs, allowing you to access personal media from your digital devices. Plug in your USB media devices, such as phones and MP3 players, and use SYNC to play all of your favorite music.

Note: SYNC indexes your music; the more information that is stored on your USB device, the longer it takes SYNC to index.

Using Voice Commands to Play Music

1. Plug your media player into your USB port.
2. Press the voice button. When prompted, say **“USB”**, then follow up by saying a voice command.
3. You will hear the command repeated back to you and the selected item will play.

For more information, refer to the **MyLincoln Touch** chapter of your **Owner's Manual**. For support, visit the website or call the toll-free number. See the inside front cover of this guide for details.

Console Refrigerator/Freezer*



Before using, flip the console lid forward and then remove the cover (make sure to reinstall the cover to help maintain the temperature). For the refrigerator, press the **COOL** control. In this mode, the system will cool to approximately 41°F (5°C). For the Freezer, press the **FREEZE** control. The system will cool to approximately 23°F (-5°C). Press the selected control again to turn the system off.

Note: Ford recommends only using this feature when the engine is running to avoid draining your vehicle's battery.

Memory Function*

Allows one touch recall of memory positions for the driver seat, power mirrors, steering column and power adjustable foot pedals. Use the memory controls located on the driver's door to program and then recall memory positions. To program position **1**, press and hold the **1** button until you hear a tone. Use this same procedure to set positions **2** and **3** using the respective buttons. You can now use these controls to recall the set memory positions.

Remote Start

Allows you to start the engine from outside your vehicle using your transmitter. To start, press and then press twice within three seconds. Once inside, apply the brake while pressing the **ENGINE START/STOP** button. Shift into drive (D) and go. If you have an integrated keypad

transmitter, simply insert the key into the ignition and switch on the ignition as you normally would before driving. To switch off the engine from outside the vehicle after using your remote start, press once.

Intelligent Access Remote Entry Icons

Press once to lock all doors. Press again within three seconds to confirm all doors are locked.

Press once to unlock the driver's door. Press again within three seconds to unlock all doors.

Press to activate the panic alarm. Press again or turn on the ignition to deactivate.

Press twice within three seconds to open the liftgate.

Car finder: Press twice within three seconds to locate your vehicle. The horn will sound and the lamps will flash.

Intelligent Access Transmitter



Note: Your intelligent access transmitter must be within 3 feet (1 meter) of the vehicle for intelligent access to function properly.

To unlock and open the driver door, pull the front exterior door handle. To lock the doors, touch the sensor button on the door handle. To unlock and open the liftgate, press the exterior liftgate release button above the license plate.

The intelligent access transmitter also contains a mechanical key blade, which can be used to unlock the driver door, if necessary.

Heated and Cooled Front Seats



To access, press the Climate corner on the touchscreen. For heated front seats, press repeatedly to cycle through the various heat settings and off. For cooled front seats, press repeatedly to cycle through the various cooling settings and off.

Second-Row Heated and Cooled Seats*

These controls are located on the rear of the floor console.



Press continuously to cycle through the various heat settings and off. Press repeatedly to cycle through the various cooling settings and off.

PowerFold® Third-Row Seat*



The third-row seat features a power, one-touch operation that allows you to adjust the seats with the touch of a button. The buttons are located behind the third-row seats on the left-hand quarter trim panel. To use, press the **RH/BOTH/LH** button to select the right seat, the left seat or both seats you want to move. Then select the desired seat position.

- ▶ Press the **STOW** button to stow the seat into the tub floor.
- ▶ Press the **FOLD** button (the top portion of the button) to fold the seatback down.
- ▶ Press the **TAILGATE** button (the bottom portion of the button) to put the seat into the tailgate position.
- ▶ Press the **NORMAL** button to return the seat to the normal seating position.



Note: The power folding seats work only when the vehicle is in park (P) and the tailgate is open.

Panoramic Vista Roof® and Power Sunshades*



To open the sunshades, press and release the overhead moonroof switch . Press again to open the moonroof. The moonroof will stop short of the fully opened position. This position may help to reduce wind noise. Press and release the control again to fully open. To close, pull the switch down. The glass panel will stop at the first position. Pull again and hold to fully close the glass panel and the sunshades. To vent from a closed position, press the **TILT** button. To close from a venting position, pull the **TILT** button.



THX II® Certified Audio System*

Fourteen strategically positioned, high-performance speakers deliver a home theater sound right in your vehicle. The system will automatically make adjustments to volume and sound distribution, based on vehicle speed and external road noise.

Tilting Head Restraints*

Your vehicle's front-row head restraints can be adjusted. Pull up to raise the head restraint. To lower, press the head restraint down while pressing and holding the guide sleeve adjust/release button. Tilt the head restraint forward for additional comfort by gently pulling the top of the head restraint. Once it is in its forward-most position, tilting it forward once more will release it to the upright position.

Note: Do not attempt to force the head restraint backward after tilting it forward. Instead, continue tilting it forward until the head restraint releases to the upright position.

Adaptive Headlamps*

The headlamp beams move in the same direction as the steering wheel, providing more visibility when driving around curves. To use, turn the lighting control switch to the autolamp position. The system is only active at speeds above 3 mph (5 km/h). See the **Lighting** chapter in your **Owner's Manual** for more details.



Fuel Tank Capacity/Fuel Info

Your vehicle has a 18.6 gallon (70.4L) fuel tank. Use only **UNLEADED** fuel or **UNLEADED** fuel blended with a maximum of **15% ethanol**. Do not use fuel ethanol (E85), diesel, fuel-methanol, leaded fuel or any other fuel because it could damage or impair the emission control system. See your **Owner's Manual** for complete details.

Towing Your MKT

Towing your vehicle behind an RV or any other vehicle may be limited. Refer to the **Towing the Vehicle on Four Wheels** section in the **Towing** chapter of your **Owner's Manual** for more information.

Fuel-Efficient Transmission

Your vehicle has been designed to improve fuel economy by reducing fuel usage while coasting or decelerating. This may be perceived as a light to medium braking sensation when removing your foot from the accelerator pedal.

Lincoln Drive Control*

This suite of electronic vehicle systems lets you choose three different driving experiences through the information

display: Comfort, Normal and Sport. See the **Driving Aids** chapter of your **Owner's Manual** for complete details.



Collision Warning System*

This system is designed to alert the driver of certain collision risks. Radar

sensors detect if vehicles ahead of you which are moving in the same direction, may be a collision risk. The system will alert you with an audible tone and red warning light which will appear above the dash. If the risk of collision increases, the system will increase brake support to help reduce collision speed.

Location of Spare Tire and Tools

Your spare tire and tools are located beneath the third row seats under the floor panel (you will need to unstow the seats to access). The spare tire is designed for emergency use only and should be replaced as soon as possible. For complete details on changing your tire, refer to the **Changing a Road Wheel** section in the **Wheels and Tires** chapter of your **Owner's Manual**.

Rear Window Buffeting

When one or both of your rear windows are open, you may hear a pulsing noise. To alleviate this, lower a front window approximately 2-3 inches (5-8 centimeters).

Tire Pressure Monitoring System

Your vehicle has a tire pressure monitoring system that illuminates a low tire pressure warning light (⚠️) in your instrument cluster when one or more of your tires are significantly under-inflated. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the **Inflating Your Tires** section in the **Wheels and Tires** chapter of your **Owner's Manual** for more information.

Roadside Assistance




Your new Lincoln MKT comes with the assurance and support of 24-hour emergency roadside assistance. To receive roadside assistance in the United States, call **1-800-521-4140**. In Canada, call **1-800-665-2006**.



Rear View Camera

This system provides a visual display of the area behind the vehicle. The display automatically appears in the touchscreen when the vehicle is in reverse (R) and uses green, yellow and red guides to alert you of your proximity to objects.

Power Liftgate

Your liftgate has an automatic open and closing feature. To open remotely, press  twice on your remote control within three seconds. Press  twice again to close or reverse the movement. You can also operate the liftgate by pressing the  button on the instrument panel.



Active Park Assist*

The system detects an available parallel parking space and automatically steers the vehicle into the space (hands-free) while you control the accelerator, gearshift and brakes. The system visually and/or audibly instructs the driver to park the vehicle.

Reverse Sensing System

This system sounds a warning tone if there is an obstacle near the vehicle's rear bumper when the vehicle is in reverse (R) and is traveling less than 3 mph (5 km/h). The warning tone will increase in frequency as the object gets closer.

Note: Visibility aids, such as active park assist and reverse sensing system, do not replace the need to watch where the vehicle is moving. Refer to your **Owner's Manual** for safety information, more details and system limitations.

SelectShift Automatic® Transmission

Gives you the ability to manually change gears, if you'd like. To use, move the gearshift lever from drive (D) to sport (S). Then, use the paddle shifter on your steering wheel to manually make shifts. Pull the right paddle (+) to upshift, pull the left paddle (-) to downshift.



Lane Keeping System*



This system works to alert drivers of unintentional lane departures through the steering system and instrument cluster display, and helps drivers steer back into the appropriate lane.

Turn the feature on and off by pressing the button on your center console, in front of the shifter.

Note: The system is designed to aid the driver. It is not intended to replace the driver's attention and judgment. The driver is still responsible to drive with due care and attention.

SecuriCode™ Keyless Entry System



Allows you to lock or unlock the doors, recall memory features and arm or disarm the anti-theft alarm. To get started, you will need your factory-set, 5-digit entry code found on your owner's wallet card (located in the glove box). Entering this code unlocks the driver's door. To lock all doors, press and hold **7-8** and **9-0** at the same time. For complete information, refer to the **SecuriCode Keyless Entry Keypad** section in the **Locks** chapter of your **Owner's Manual**.

BLIS® (Blind Spot Information System) with Cross Traffic Alert (CTA)*



BLIS aids the driver in detecting vehicles that may have entered the blind spot zone. The CTA feature is designed to warn you of vehicles approaching from the sides when the transmission is in reverse (R). BLIS and CTA will display a yellow indicator light in your exterior mirrors and the CTA will also sound tones and display messages to warn you from which direction vehicles are approaching. Refer to the **Driving Aids** chapter in your **Owner's Manual** for more information.

Note: Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your **Owner's Manual** for safety information, more details and system limitations.

Universal Garage Door Opener

The driver-side visor has a built-in wireless transmitter that replaces the common hand-held garage door opener. This system can also be programmed to security systems, entry gates and home or office lighting. Refer to the **Universal Garage Door Opener** chapter in your **Owner's Manual** for programming instructions.