

WARNING

Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.




United States
Lincoln Customer Relationship Center
1-800-521-4140
(TDD for the hearing impaired 1-800-232-5952)
lincolnowner.com

Canada
Lincoln Customer Relationship Centre
1-800-387-9333
lincolncanada.com

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Lincoln dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.

Lincoln Navigator
March 2014
Second Printing
Quick Reference Guide
Litho in USA
EL7J 19G217 AA



2014 NAVIGATOR



Quick Reference Guide




THE LINCOLN MOTOR COMPANY

Commonly Used Voice Commands

SYNC® Say the Word.

Table of Contents

2014 NAVIGATOR

Touch the voice button  on the right-hand side of your steering wheel and then say:



Basic Commands

- ▶ What can I say?
- ▶ List of commands
- ▶ Main menu
- ▶ Previous
- ▶ Next
- ▶ Go back
- ▶ Exit
- ▶ Help
- ▶ Vehicle health*
- ▶ Pair my phone



Phone

- ▶ Phone list of commands
 - Dial
 - Call <name> on cell/at home/at work
 - Call voicemail
 - Do not disturb <On/Off>
 - Listen to text messages (phone-dependent feature)



Entertainment

- ▶ Audio list of commands: You can also get detailed lists of commands for radio, USB, **Bluetooth**® audio, SiriusXM and SD card
- ▶ Audio <On/Off>
- ▶ Radio
 - FM <87.9-107.9>
 - FM preset <#>
- ▶ CD
 - Play track <1-512>
 - Shuffle <On/Off>
- ▶ USB
 - Play song <name>
 - Play album <name>
- ▶ SiriusXM
 - <Channel name>
 - Preset <#>



SYNC Services*

- Must say "Services" first, and then
- ▶ What can I say?
 - ▶ Traffic
 - ▶ Directions
 - ▶ Business search
 - ▶ Operator (for direction or business search)
 - ▶ Favorites
 - ▶ News, sports, weather, horoscopes, stock quotes, movies or travel
 - ▶ Help

*if equipped

Some services may not be available in your area. For additional support, refer to your Owner's Manual, visit the website or call the toll-free number.

U.S. customers: Visit SyncMyRide.com or call **1-800-392-3673** (select Option 1 or 2 for language, then press 3). **Canadian customers:** Visit SyncMyRide.ca or call **1-800-565-3673** (select Option 1 or 2 for language, then press 3).

Instrument Panel	4 – 5
Vehicle Stability	6 – 7
SYNC	8 – 9
Convenience	10
Comfort	11
Essential Information	12 – 13
Function	14 – 15



lincolnowner.com



lincolncanada.com

LEARN MORE ABOUT YOUR NEW NAVIGATOR

Scan the country-appropriate QR code with your smartphone (make sure you have a scanner app installed), and you can access even more information about your vehicle.



Instrument Panel

2014 NAVIGATOR

1 Lighting Control

- Switches the headlamps on.
- Switches the headlamps off.
- Switches on the parking lamps.
- Autolamps: Automatically turns the exterior lamps on or off based on available daylight.
- Switches on fog lamps when you pull the control toward you. You can switch the fog lamps on when the ignition is on, the lighting control knob is in any position other than the off position and you do not switch the high beams on.

2 Parking Brake

3 Windshield Wipers and Washers

Rotate the end of the control lever away from you or toward you to increase or decrease the speed of the wipers.

To use the washer feature, push the end of the lever:

- ▶ Quickly for a single swipe without fluid.
- ▶ Hold briefly for three swipes with washer fluid.
- ▶ Hold for a longer wash cycle.

To operate your rear window wiper:

Rotate the rear wiper control to **1** (slower intermittent speed), **2** (faster intermittent speed) or **0** (off). For a rear wash cycle, rotate and hold the control to either the top or bottom position to activate the rear washer. The control will return to the **2** or **0** position when you release it.

Note: For optimal wiper performance, clean your blades and glass regularly. Refer to your **Owner's Manual** for more information.

4 Cruise Control

To set the speed:

- A. Press and release **ON**.
- B. Accelerate to the desired speed.
- C. Press **SET+** and take your foot off the accelerator.
 - ▶ To set a higher or lower speed, press and hold **SET+** or **SET-** until you reach the desired speed. Additionally, you can press and release either button to change your set speed in approximately 1 mph (2 km/h) increments.
 - ▶ To cancel a set speed, tap the brake pedal. The set speed will not be erased.

- ▶ To return to a previously set speed, press **RESUME**.
- ▶ To switch off, press **OFF** or switch off the ignition.

5 Information Display

Shows important vehicle information through a constant monitor of vehicle systems. The display will notify you of potential vehicle problems by showing system warnings followed by a long indicator tone. For more details about your information display functions, please see your **Owner's Manual**.

6 Service Engine Soon Light

Lights briefly when you switch the ignition on. If it remains on or blinks after you start the engine, the On-Board Diagnostics (OBD-II) system has detected a malfunction. Drive in a moderate fashion (avoid heavy acceleration and deceleration) and contact an authorized dealer as soon as possible.

7 Hazard Control

Overdrive Control with Tow/Haul Feature

The tow/haul feature improves transmission operation when towing a trailer or a heavy load. To activate tow/haul, press the button on the side of the gearshift lever. The **TOW HAUL** indicator light will illuminate in the instrument cluster. To deactivate, press the button again. Drive with the vehicle in overdrive (D) with tow/haul off for the best fuel economy. Refer to the **Transmission** chapter of your **Owner's Manual** for more information.



Control Trac® Four-Wheel-Drive (4WD) System*

4X2 (2WD): Delivers power to the rear wheels only. This is appropriate for normal, on-road driving on dry pavement.

4X4 AUTO: Provides electronic control four-wheel drive with power delivered to all four wheels, as required, for increased traction.

The information display will show **"4X4 AUTO"** when this position is selected. This mode is appropriate for all on-road driving conditions, such as dry road surfaces, wet pavement, snow or gravel.

4X4: Provides electronically locked four-wheel drive power to all four wheels. The information display will show **"4X4"** when you select this mode. 4x4 mode is not recommended for use on dry pavement. It is only intended for severe winter or off-road conditions, such as deep snow, ice or shallow sand. Refer to the **Using Four-Wheel Drive (4WD)** chapter in your **Owner's Manual** for more information including shifting instructions.

AdvanceTrac® with RSC® (Roll Stability Control™)

Helps you keep control of your vehicle when on a slippery surface. The electronic stability control portion of the system helps avoid skids and lateral slides, and roll stability control helps avoid a vehicle rollover. The traction control system helps avoid drive wheel spin and loss of traction. Refer to the **Stability Control** chapter in your **Owner's Manual** for safety information and more details.

Trailer Sway Control*

This feature applies your vehicle brakes at individual wheels and, if necessary, reduces engine power. If the trailer begins to sway, the stability control light flashes and the message **TRAILER SWAY REDUCE SPEED** appears in the information display. The first step to do is slow down your vehicle, then pull safely to the side of the road and check for proper tongue load and trailer load distribution. See the **Load Carrying** chapter in your **Owner's Manual** for specific loading information.



Getting Started with Your SYNC System

SYNC is a hands-free, voice recognition system used for entertainment, information and communication. SYNC. Say the Word.

General Tips

- ▶ Press **RETURN** to exit a menu.
- ▶ For additional support, refer to your **Owner's Manual**, visit the website or call the toll-free number. See the inside front cover of this guide for details.


Before You Get Started

1. Set up your owner account by visiting **SyncMyRide.com** (U.S.) or **SyncMyRide.ca** (Canada). Follow the on-screen instructions.

Note: Your account gives you even more SYNC capabilities, including personalization features and software updates.
2. **SYNC** uses a wireless connection called **Bluetooth®** to communicate with your phone. Turn **Bluetooth** mode on in your phone's menu options. This lets your phone find **SYNC**. For more details on setting up your phone with **SYNC**, visit **SyncMyRide.com** (U.S.), **SyncMyRide.ca** (Canada) or your phone manufacturer's website.

Pairing Your Phone with SYNC

First-time pairing lets you use the many features of SYNC.

1. Make sure that your vehicle is in park (P) and you switch your ignition and radio on.
2. Press the phone button  on your steering wheel or the **Phone** button on your audio controls. When the **No phone paired** message displays on the screen, press **Settings**, then press **Add** to add your cellular phone.
3. Make sure that you switch **Bluetooth** on and your cellular phone is in the proper mode. Refer to your phone's user guide, if necessary.
4. **Find SYNC** will appear on the touchscreen, indicating that it is trying to pair with your cellular phone. When the system finds your phone, your touchscreen will display a six-digit **PIN**.

5. When prompted on your cellular phone's display, enter the six-digit **PIN** provided by **SYNC** into your cellular phone.
6. The display indicates when the pairing is successful.

Note: The system may prompt you to:

- ▶ Set your phone as the **primary** or **favorite** (the primary phone will receive messages and voicemail).
- ▶ Download your phone book (a requirement to use the full set of voice commands).
- ▶ Switch on 911 Assist®.

Tips

- ▶ Make sure you accept the request from **SYNC** to access your phone.
- ▶ To pair subsequent phones or to learn more about your **SYNC** system, please refer to **Pairing Subsequent Phones** in the **SYNC** chapter of your **Owner's Manual**.


Using Your Phone with SYNC

Note: You must download your phone book to make phone calls with voice commands by name.



Making a Phone Call

Use **SYNC** to make a phone call to anyone in your phone book by pressing the voice button and when prompted, give a voice command.

For example, you could say "**Call Jake Smith at home**". When the system confirms the number, say "**Dial**" again to initiate the call.

Note: You can also make phone calls by pressing the voice button . When prompted, give the voice command "**Dial**", then verbally say the phone number.

Answering Incoming Calls

Whenever you have an incoming call, you will be able to see the name and number of the person calling in your display. Press the phone button  to answer an incoming call. You can hang up at any time by pressing and holding the phone button .


Do Not Disturb Mode

This feature blocks incoming calls and text messages, and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command "**Do not disturb on**" to enable and "**Do not disturb off**" to disable.

Using SYNC to Access Digital Media

SYNC has a media hub with multiple inputs allowing you to access personal media from your digital devices. Plug in your **USB** media devices such as phones and **MP3** players, and use **SYNC** to play all of your favorite music. **SYNC** indexes all of your music. The more music stored on your device, the longer it takes **SYNC** to index.

Using Voice Commands to Play Music

1. Plug your media player into your USB port.
2. Press the voice button . When prompted, say "**USB**", then follow-up saying one of the following voice commands.

SYNC AppLink™*

SYNC AppLink allows voice access to select mobile applications that you already have or can download to your Android™, BlackBerry® or iPhone®.

Current apps available include Pandora Internet Radio®, Stitcher Smart Radio™, Open Beak (BlackBerry exclusive), iHeartRadio, Slacker, NPR News and SYNC Destinations and more.

For more information on **SYNC**, visit the website or call the toll-free number. See the inside front cover of this guide for details.

Autowipers

If you switch on this feature, your wipers will automatically turn on when moisture is present on the windshield. The wiper speed will vary based on the amount of moisture detected on the windshield and the sensitivity setting. The wipers will continue to wipe as long as moisture is detected. To deactivate, turn your wiper controls off.


Note: Make sure you switch this feature off before entering a car wash.


MyKey®


MyKey allows you to program certain driving restrictions in order to promote good driving habits. You can set speed restrictions and limit volume levels. For complete information, refer to the **MyKey** chapter in your **Owner's Manual**.

Power Liftgate





Press  on the instrument panel to open or close the power liftgate. For added convenience, there are three more ways to activate your power liftgate's capabilities:

1. On your remote entry transmitter, press  twice within three seconds to open or close your power liftgate.
2. To open using the liftgate control button in the liftgate handle: Unlock the doors using either the remote entry transmitter or the power door unlock control, and press the control.

3. To close using the rear cargo area button: Press and release the  control located on the left rear quarter panel. This button is automatically disabled when the liftgate is latched.

Note: Keep clear of the liftgate when operating the rear switch. Your power liftgate is equipped with an obstacle detection feature which will either stop or revert to a full open position if it encounters a solid object. For complete information, see the **Liftgate** section within the **Locks** chapter of your **Owner's Manual**.

Power-Adjustable Foot Pedals

Located to the left of your steering column, your power-adjustable pedal control lets you move your brake and accelerator pedals closer. Press the  arrow to move the pedals closer to you or the  arrow to move

the pedals further away from you. The pedals should only be adjusted when the vehicle is stopped and in park (P).

SecuriCode™ Keyless Entry Keypad



Lock or unlock the doors or release the liftgate glass without using a key. The keypad can be operated with the factory-set, 5-digit entry code; this code is located on the owner's wallet card in the glove box. You can also create up to five of your own 5-digit personal entry codes. To lock all of the doors and liftgate, press and hold **7-8** and **9-0** at the same time. For complete information, refer to the **Locks** chapter of your **Owner's Manual**.

PowerFold® Third-Row Seat*



60/40 split-folding bench seat uses a power-activated seatback release. Fold one side or both down for more flexibility.

The controls are located on the right-hand rear quarter trim panel that is accessible from the liftgate area.

Note: Make sure you unfasten all safety belts before lowering seats.

To lower:



1. Make sure that the head restraints are folded down first.
2. Press "FOLD" on the button.

3. To return the seatback to its original position, press "UP" on the button.

Note: The power-folding seats will operate for 10 minutes after the ignition switch is turned off. The transmission must be in park (P) and the liftgate or liftgate glass must be open.

Front Climate Controlled Seats





Press the heated seat symbol  or the cooled seat symbol  to cycle through the various settings and off. More indicator lights show warmer or cooler settings.

Second-Row Heated Seats





The rear heated seat controls are on the rear of the center console.



- ▶ Press  for maximum heat or  for minimum heat.
- ▶ Press again to switch off.

Note: The heated seats reset at every ignition run cycle. They will turn off automatically when you switch off the engine.

Memory Seat Feature

The memory function will save and recall the positions of the driver seat, power mirrors, adjustable pedals and steering column. Use the control located on the side of the driver's seat

  to program and then recall saved memory positions.

To program position **1**, switch the ignition on. Move the memory features to your preferred position. Press and hold the **1** button  for about two seconds until you hear a tone. Use this same procedure to set the second position by using the **2** button . You can now use these controls to recall the set memory positions.

Auto-Leveling Suspension*

The system helps keep the rear of your vehicle at a constant level, thanks to a hydraulic pump inside of each rear shock. The feature helps improve ride, handling and general vehicle performance during certain road conditions, steering maneuvers, braking and acceleration, and towing. See the **Driving Aids** section of your **Owner's Manual** for details.



Easy Fuel® System

Easy Fuel system is self sealing and therefore protected against dust, dirt, water, snow and ice. This type of fuel system is capless. A locking plug, as shown, is available. To refill your fuel tank, open the fuel filler door by pulling the indent on the door, insert the nozzle

and start fueling. Wait 10 seconds from the time the refueling nozzle is shut off until you remove the nozzle from the vehicle to allow residual fuel in the nozzle to drain into the tank. If you need to fill your fuel tank with a portable fuel container, use the fuel funnel which is included with the tire changing tools. Slowly insert the funnel into the Easy Fuel system and fill the tank with fuel from the container. When done, clean the funnel or properly dispose of it. Extra funnels can be purchased from your authorized dealer. Do not use aftermarket funnels as they will not work with the Easy Fuel system and may cause damage.

Fuel-Efficient Transmission

Your vehicle has been designed to improve fuel economy by reducing fuel usage while coasting or decelerating. This may be perceived as a light to medium braking sensation when removing your foot from the accelerator pedal.



Fuel Type and Fuel Tank Capacity

Depending on your vehicle, your fuel tank has a capacity of either 28 gallons (106L) or 33.5 gallons (126.8L).

If your vehicle is a Flex Fuel vehicle, it will have a yellow ring around the top of the fuel filler inlet. It is designed to use only **E85 FUEL ETHANOL, UNLEADED FUEL** “Regular” unleaded gasoline or any mixture of the two fuels. It is best not to alternate repeatedly between gasoline and E85. If you do switch fuels, it is recommended that you add as much fuel as possible—at least half a tank. If you use E85 fuel exclusively, it is recommended to fill the fuel tank with regular unleaded gasoline at each scheduled oil change. See your **Owner's Manual** for more specific information and E85 details.

Tire Pressure Monitoring System

Your vehicle is equipped with a Tire Pressure Monitoring System (TPMS) that displays a low tire pressure warning light (⚠️) when one or more of your tires are significantly under-inflated. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the **Inflating Your**

Tires section in the **Wheels and Tires** chapter of your **Owner's Manual** for more information.

Location of Spare Tire and Tools

The temporary spare tire is located under the vehicle, just forward of the rear bumper. It is designed for emergency use only and should be replaced as soon as possible. The jack and tools are under the access panel in the floor compartment behind the rear seat. Make sure you switch the deployable running boards* off prior to jacking, hoisting or towing your vehicle.

For complete details on how to change your tire, refer to the **Roadside Emergencies** chapter in your **Owner's Manual**.

Roadside Assistance

Your new Lincoln Navigator comes with the assurance and support of 24-hour emergency roadside assistance. To receive roadside assistance in the United States, call **1-800-521-4140**. In Canada, call **1-800-387-9333**.

SOS Post-Crash Alert System™

The system flashes the direction indicator lamps and sounds the horn (intermittently) in the event of a serious impact that deploys an airbag.

The horn and lamps will turn off when:

- ▶ You press the hazard control button in your vehicle or the panic button* (Ⓜ️) on your keyless remote transmitter.
- ▶ Your vehicle runs out of power.





Rear View Camera*

The rear view camera system is on the liftgate and provides a video image of the area behind the vehicle. The display will automatically appear on the navigation system screen* or in the interior mirror whenever the vehicle is in reverse (R) and uses colored guidelines (green, yellow and red) to indicate distance. Objects in the red zone are the closest to your vehicle while objects in the green zone are further away.



Forward and Reverse Sensing Systems

The systems may warn you if there is an object in front of or behind the vehicle. The system will sound a warning tone that increases in frequency as the object gets closer and will sound continuously when the object is less than 10 inches (25 centimeters) away.

Note: Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your **Owner's Manual** for safety information, more details and limitations.



Moonroof*

The sliding shade can be manually opened or closed when the moonroof is closed. Pull the shade toward the front of the vehicle to close it. The moonroof control is located on the overhead console. To open, press and release the **SLIDE** control. The moonroof will stop short of the fully opened position. To fully open the moonroof, press and release the **SLIDE** control again. To close, pull and release the **SLIDE** control. Press and release the **TILT** control to vent the moonroof. Pull and hold the **TILT** control to close the moonroof.



Navigation System*

Set your destination by using your touchscreen or voice commands.

To Program a Destination Using the Touchscreen

1. Press the **DEST** button and "**Accept**" when the "**Terms of Use**" screen appears.
2. Select from the following:
 - a. **Quick:** Allows you to access emergency destinations (such as police stations or hospitals), save your favorite destinations to presets for quick access, find the nearest point of interest (POI), recall a previous destination or entry from your address book to set as a current destination, or cancel your route.

b. **Standard:** Allows you to set a destination using any of the following:

- i. Address Book
- ii. Previous Destination
- iii. Phone Number
- iv. Map
- v. Street Address
- vi. Point of Interest
- vii. Freeway Exit/Entrance
- viii. Intersection

c. **Edit Route:** Allows you to make any adjustments to the currently selected navigation route such as:

- i. Cancel Route
- ii. Detour
- iii. View Route
- iv. Edit Route Preferences
- v. Edit Traffic Preferences
- vi. Edit Destination/Way Points
- vii. Edit Turn List

Note: Periodic map updates are available at an additional cost. Call **1-800-NAVMAPS** (in Mexico, call **01-800-557-5539**) or visit www.navigation.com/ford.