

Personal Audio System


Startup Guide / Guide de démarrage / Anleitung für die Inbetriebnahme / Guía de inicio rápido
 / Guida all'avvio / Snelstartgids / Guia de Inicio Rápido / Käynnistysopas / Uppstartguide /
 Instrukcja uruchamiania / Használatba vételi útmutató / Příručka spouštění /
 Příručka spustenia / Руководство по началу работы / Посібник із налаштування



<http://www.sony.net/>


©2012 Sony Corporation Printed in China

ZS-S10CP





1




**Bottom / Partie inférieure / Unterseite /
 Parte inferior / Parte inferiore / Onderkant /
 Parte inferior / Pohja/ Nedtill / Spód / Alul /
 Spodní část / Spodná časť / Нижняя часть /
 Нижня частина**



2



RADIO



CD

