

ViewSonic®

VNB107 ViewBook



ViewSonic®

- User Guide
- Guía del usuario
- Guia do usuário
- Руководство пользователя
- 使用手冊 (繁中)
- 使用手冊 (簡中)
- 사용자 안내서
- دليل المستخدم

Model No. : VS13323

Compliance Information

CE Conformity for European Countries

CE The device complies with the EMC Directive 2004/108/EC and Low Voltage Directive 2006/95/EC.

Following information is only for EU-member states:

The mark shown to the right is in compliance with the Waste Electrical and Electronic Equipment Directive 2002/96/EC (WEEE).

The mark indicates the requirement NOT to dispose the equipment as unsorted municipal waste, but use the return and collection systems according to local law.

If the batteries, accumulators and button cells included with this equipment, display the chemical symbol Hg, Cd, or Pb, then it means that the battery has a heavy metal content of more than 0.0005% Mercury, or more than 0.002% Cadmium, or more than 0.004% Lead.



R&TTE Compliance Statement **CE**

This wireless module device complies with the Essential Requirements of the R&TTE Directive of the European Union (1999/5/EC). This equipment meets the following conformance standards:

ETSI EN 300 328

EN 301 489-01

EN 301 489-17

EN 62209-2

Notified Countries: Germany, UK, Netherlands, Belgium, Sweden, Denmark, Finland, France, Italy, Spain, Austria, Ireland, Portugal, Greece, Luxembourg, Estonia, Latvia, Lithuania, Czech Republic, Slovakia, Slovenia, Hungary, Poland and Malta.

Important Safety Instructions

1. DO NOT press or touch the LCD Screen. DO NOT place notebook PC with small items, they may scratch LCD Screen or penetrate the vents of notebook PC.
2. DO NOT expose notebook PC to dirty or dusty environment. Keep the environment clean and dry.
3. DO NOT place notebook PC on uneven or unstable work surface.
4. DO NOT place or drop objects on the top of notebook PC. DO NOT shove any foreign objects into notebook PC. DO NOT close with force the LCD Screen lid.
5. DO NOT expose notebook PC to strong magnetic or electrical fields; DO NOT place floppy disks near or on notebook PC as this may cause the loss of data on the floppy disks.
6. DO NOT leave notebook PC facing the sun as it can damage the LCD Screen, especially when in a car.
7. SAFE TEMPERATURE: This notebook PC should only be used in environments with ambient temperatures between 5°C (41°F) and 35°C(95°F).
8. DO NOT expose notebook PC to or use near liquids, rain, or moisture.
9. Caution: there is a risk of explosion if the battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
10. DO NOT throw notebook PC in municipal waste. Check local regulations for disposal of electronic products. Please recycle the Battery Pack, and check with your Local Authority or retailer for an advice on recycling.
11. Notebook PC and its power adapter may produce some heat during operation or charging of its internal battery. DO NOT leave notebook PC on your lap or any part of your body in order to prevent discomfort or injury from heat exposure.
12. INPUT RATING: Refer to the rating label on notebook PC and make sure that the Power Adapter complies with that rating. Only use accessories recommended by ViewSonic.
13. Check the connections between the main unit and attached devices before turning on your notebook PC.
14. DO NOT use notebook PC during eating to avoid dirtying your notebook PC.
15. DO NOT insert anything into notebook PC that may result in short circuit or can damage the electronic circuits.
16. Power off your notebook PC, if you want to install or remove some external devices, which do not support hot-plugging-in.
17. Disconnect your notebook PC from the electrical outlet and remove any installed batteries before cleaning the notebook PC. Keep your notebook PC away from children.
18. DO NOT disassemble notebook PC. Only a certified service technician should perform repairs on your computer.
19. Use only the Battery Packs approved by ViewSonic.
20. Notebook PC has vents to disperse heat. DO NOT place notebook PC on soft objects (e.g.: bed, sofa, your lap) as this can block the air flow from those vents and cause system halt due to overheating.

Declaration of RoHS Compliance

This product has been designed and manufactured in compliance with Directive 2002/95/EC of the European Parliament and the Council on restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS Directive) and is deemed to comply with the maximum concentration values issued by the European Technical Adaptation Committee (TAC) as shown below:

Substance	Proposed Maximum Concentration	Actual Concentration
Lead (Pb)	0,1%	< 0,1%
Mercury (Hg)	0,1%	< 0,1%
Cadmium (Cd)	0,01%	< 0,01%
Hexavalent Chromium (Cr6+)	0,1%	< 0,1%
Polybrominated biphenyls (PBB)	0,1%	< 0,1%
Polybrominated diphenyl ethers (PBDE)	0,1%	< 0,1%

Certain components of products as stated above are exempted under the Annex of the RoHS Directives as noted below:

Examples of exempted components are:

1. Mercury in compact fluorescent lamps not exceeding 5 mg per lamp and in other lamps not specifically mentioned in the Annex of RoHS Directive.
2. Lead in glass of cathode ray tubes, electronic components, fluorescent tubes, and electronic ceramic parts (e.g. piezoelectronic devices).
3. Lead in high temperature type solders (i.e. lead-based alloys containing 85% by weight or more lead).
4. Lead as an alloying element in steel containing up to 0.35% lead by weight, aluminium containing up to 0.4% lead by weight and as a copper alloy containing up to 4% lead by weight.

Copyright Information

Copyright © ViewSonic® Corporation, 2010. All rights reserved.

Microsoft®, Windows®, Windows NT®, and the Windows® logo are registered trademarks of Microsoft® Corporation in the United States and other countries.

ViewSonic®, the three birds logo, OnView®, ViewMatch™, and ViewMeter® are registered trademarks of ViewSonic® Corporation.

Intel®, Pentium®, and Atom™ are registered trademarks of Intel Corporation.

Disclaimer: ViewSonic® Corporation shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from furnishing this material, or the performance or use of this product.

In the interest of continuing product improvement, ViewSonic® Corporation reserves the right to change product specifications without notice. Information in this document may change without notice.

No part of this document may be copied, reproduced, or transmitted by any means, for any purpose without prior written permission from ViewSonic® Corporation.

Product Registration

To meet your future needs, and to receive any additional product information as it becomes available, please register your product on the Internet at: www.viewsonic.com. The ViewSonic® Wizard CD-ROM also provides an opportunity for you to print the registration form, which you may mail or fax to ViewSonic®.

For Your Records

Product Name:	VNB107 ViewSonic ViewBook
Model Number:	VS13323
Document Number:	VNB107-1_UG_ENG Rev. 1C 03-18-10
Serial Number:	_____
Purchase Date:	_____

Product disposal at end of product life

ViewSonic® is concerned about the preservation of our environment. Please dispose of this product properly at the end of its useful life. For the recycling information, please refer to our website:

1. USA: www.viewsonic.com/company/green/recycle-program/
2. Europe: www.viewsoniceurope.com/uk/support/recycling-information/
3. Taiwan: recycle.epa.gov.tw

Contents

Chapter 1: Preparing the netbook for use	
Package contents	1
Insert the battery	1
Connect the power adapter	1
Chapter 2: Turning on the VNB107	
Top View with the lid open	2
Turn on the VNB107	2
The function keys.....	3
Chapter 3: Configuring BIOS, installing an operating system and drivers	
Installing an operating system	4
Other settings of the Setup CMOS Utility	5
Installing the drivers.....	8
Chapter 4: Devices and interfaces	
Expand the interface devices.....	9
Chapter 5: Control Center Functions	
Using the Control Center	10

User's Guide

Dear customer!

Thank you for choosing ViewSonic's VNB107 netbook.

Your VNB107 has powerful information processing capabilities and mobile characteristics. Whether you are in the office, at home, or travelling, VNB107 is your effective assistant that accompanies you all the time.


This manual will help you master the methods and techniques of using VNB107 to the best.

Chapter 1 Preparing the netbook for use


NO.1.1 Package contents

First of all, please open the VNB107 box and carefully remove the contents; check if anything is missing or damaged.

NO.1.2 Insert the battery



Inserting the battery



Removing the battery

NO.1.3 Connect the power adapter



Chapter 2

Turning on the VNB107

NO.2.1 Top View with the lid open


Open the lid of your VNB107. Please be careful when opening or closing the lid; do not do it with excessive force as you can damage the netbook.



**VNB107
appearance**



NO.2.2 Turn on the VNB107

Make sure both the battery and the power adapter are connected to the netbook and to wall AC power outlet. Press the Power button for one second to turn on the netbook.



1	3G indicator: when the 3G LED is flashing in blue, VNB107 is connected to the 3G network. If the LED is off, either the 3G module is disabled or there is no connection for the 3G network.
2	The battery and charging status indicator: the LED glowing in amber means the battery is being charged; once the battery is fully charged the LED changes its color to blue.
3	HDD indicator: flashing in blue, this LED shows the HDD activity.
4	Wi-Fi indicator: when the netbook is connected to the wireless AP, the LED is flashing in blue. When the Wi-Fi module is disabled, the LED is not lit.
5	CapsLock: glowing in blue, this LED shows that all the input characters will appear in upper case.

NO.2.3 The function keys

Key	Description
Fn+Esc	Enter suspend state
Fn+F1	Enable or disable the touchpad
Fn+F2	Enable or disable the 3G module
Fn+F3	Enable or disable the Wi-Fi module
Fn+F4	Toggle the sound ON and OFF
Fn+F5	Decrease the brightness of the LCD
Fn+F6	Increase the brightness of the LCD
Fn+F7	Turn ON of OFF the video-out signal for externally connected LCD or projector
Fn+F8	Turn ON or OFF the internal display
Fn+F9	Customizable; the default setting is to open a web browser
Fn+F10	Customizable; the default setting is to open an email client
Fn+F11	Customizable; the default setting is to open a media player
Fn+F12	Customizable; the default setting is to open the Bluetooth application (optional)
Fn+ 	Increase the sound volume
Fn+ 	Decrease the sound volume
Fn+ ↑	Page up
Fn+ ↓	Page down
Fn+ ←	Home
Fn+ →	End

Chapter 3

Configuring BIOS, installing an operating system and drivers

NO.3.1 Installing an operating system


Before installing OS, you will need to set up BIOS to allow boot from USB-CD/DVD drive. To do that, turn on VNB107, and press F2 when prompted to run BIOS setup.



After you enter BIOS setup application, use the [→] and [←] keys to choose BOOT section of the main menu, select your USB-CD/DVD drive in the Boot priority list and use the [+] and [-] buttons to set the order in which drives and devices will be checked for a useable OS to boot at the time of startup.


NO.3.2 Other settings of the Setup CMOS Utility

Main Menu: Here you can set the system's date and time, as well as check system information like BIOS version, embedded controller firmware version, motherboard version, and the amount of the system memory and extended memory.




- **Sata Port:** the settings specific to SATA devices can be done here. The specific operation can be found in the System promoted screens.

Advanced Menu: you can make the following settings.



- Legacy USB: set if a USB device can be used under DOS.
- Summary Screen: set if you would like to see system configuration information each time you boot your VNB107.
- Boot-time Diagnostic Screen: choose between the image wallpaper mode and text information mode during the POST process.
- PXE OPROM: Set up if your VNB107 can be booted from LAN.
- Sata Controller Mode Option: setup the working mode of your HDD. If you are using Windows XP, you need to have AHCI disabled.
- AHCI Enable: enables or disables the Advanced Host Controller Interface for SATA devices.

Security Menu: security settings to enter the system.



- Supervisor Password: defines if a supervisor password is asked when entering the BIOS Setup Utility.
- User Password: defines if a user password is asked when entering the BIOS Setup Utility.
- Set User Password: used to define the User Password.
- Set Supervisor Password: used to define the Supervisor Password, which authority is higher than that of the User Password.
- Password on Boot: defines if a password is required to startup the VNB107.
- Set Harddisk Password: specifies the password for getting access to the HDD.

[Warning]: Please write down the passwords if you set any, as to avoid any inconvenience in the future.

Exit Menu: options for exiting the BIOS Setup Utility after you have made changes to the settings.



- Exit Saving Changes: to store the values and exit.
- Exit Discarding Changes: to exit without storing the values.
- Load Setup Defaults: to restore the settings to their factory values.
- Discard Changes: to abandon all the settings done during current session, yet to remain in the BIOS Setup Utility.
- Save Changes: to save the settings.

NO.3.3 Installing the drivers


Use the CD bundled with your VNB107 to install drivers and additional applications.

Choose the driver you need to install, and follow the on-screen instructions. After a driver is installed you may be requested to restart your system.

Chapter 4

Devices and interfaces

NO.4 Expand the interface devices



NO.	Item	Description
1	DC-in jack	Power jack for AC-DC adapter
2	VGA port	To connect to an external monitor or projector
3	USB port	To connect USB devices, such as pen drives, printers, etc.
4	Security Lock Slot	To connect a key-type security lock
5	Ventilation slot	The ventilation slot should not be obstructed while VNB107 is running
6	3G switch	Toggles the 3G module ON and OFF (optional)
7	Card reader	Can accommodate SD/MMC/MS/MS PRO cards
8	Headphone-out Jack	Used to connect headphones or external speakers
9	Microphone-in jack	Used to connect an external microphone
10	RJ-45 LAN Jack	Used to connect the Ethernet network cable
11	SIM card Slot	Please refer to the drawing next to the slot for a correct way to insert your SIM card

[Attention]: Your VNB107 may not have all the interfaces listed above.

Chapter 5

Control Center Functions

NO.5 Using the Control Center

You can search for all kinds of system information through the Control Center, conduct the system settings and view the help information.




[Note]: To enjoy the functionality of the Control Center, please install it from the Driver disc bundled with the VNB107.

The Control Center can have some modifications and thus be different from the description herein.


System Information

Click on the System Info icon on the home-page of the Control Center to see the VNB107 basic system information.




[Note]: Click on the drop-down menu in the lower right corner of the window for more information.


Click on the Battery icon on the home-page of the Control Center to view the system power supply information and change the auto-warning settings.



Click on the Cooling Control icon on the home-page of the control center to view the relevant CPU and fan information.



Click on the Display icon on the home-page of the Control Center to do the display settings and adjust the brightness of the LCD back light.



To adjust the settings of the externally connected monitor, click on the external monitor icon first to select it, then click on the Switch button.

[Note]: The Control Center would maximum show two display devices simultaneously.


Click on the Shortcuts icon on the home-page of the Control Center to select the applications you want to be run when you press function key combinations. You can also restore the settings to their factory defaults.



Click on the Profile icon on the home-page of the Control Center to set up different power profiles.




Windows XP operating system



Windows Vista operating system

Click on the Device Control icon on the home-page of the Control Center to enable/disable certain modules of your VNB107.



[Note]: The picture you would see here may be different due to hardware differences across models.

Customer Support

For technical support or product service, see the table below or contact your reseller.

NOTE: You will need the product serial number.

Country/Region	Website	T = Telephone F = FAX	Email
Australia/New Zealand	www.viewsonic.com.au	AUS= 1800 880 818 NZ= 0800 008 822	service@au.viewsonic.com
Canada	www.viewsonic.com	T (Toll-Free)= 1-866-463-4775 T (Toll)= 1-424-233-2533 F= 1-909-468-3757	service.ca@viewsonic.com
Europe	www.viewsoniceurope.com	www.viewsoniceurope.com/uk/Support/Calldesk.htm	
Hong Kong	www.hk.viewsonic.com	T= 852 3102 2900	service@hk.viewsonic.com
India	www.in.viewsonic.com	T= 1800 11 9999	service@in.viewsonic.com
Ireland (Eire)	www.viewsoniceurope.com/uk/	www.viewsoniceurope.com/uk/ support/call-desk/	service_ie@viewsoniceurope.com
Korea	www.kr.viewsonic.com	T= 080 333 2131	service@kr.viewsonic.com
Latin America (Argentina)	www.viewsonic.com/la/	T= 0800-4441185	soporte@viewsonic.com
Latin America (Chile)	www.viewsonic.com/la/	T= 1230-020-7975	soporte@viewsonic.com
Latin America (Columbia)	www.viewsonic.com/la/	T= 01800-9-157235	soporte@viewsonic.com
Latin America (Mexico)	www.viewsonic.com/la/	T= 001-8882328722	soporte@viewsonic.com
Renta y Datos, 29 SUR 721, COL. LA PAZ, 72160 PUEBLA, PUE. Tel: 01.222.891.55.77 CON 10 LINEAS Electroser, Av Reforma No. 403Gx39 y 41, 97000 Mérida, Yucatán. Tel: 01.999.925.19.16 Other places please refer to http://www.viewsonic.com/la/soporte/index.htm#Mexico			
Latin America (Peru)	www.viewsonic.com/la/	T= 0800-545656	soporte@viewsonic.com
Macau	www.hk.viewsonic.com	T= 853 2870 0303	service@hk.viewsonic.com
Middle East	ap.viewsonic.com/me/	Contact your reseller	service@ap.viewsonic.com
Puerto Rico & Virgin Islands	www.viewsonic.com	T= 1-800-688-6688 (English) T= 1-866-379-1304 (Spanish) F= 1-909-468-3757	service.us@viewsonic.com soporte@viewsonic.com
Singapore/Malaysia/ Thailand	www.ap.viewsonic.com	T= 65 6461 6044	service@sg.viewsonic.com
South Africa	ap.viewsonic.com/za/	Contact your reseller	service@ap.viewsonic.com
United Kingdom	www.viewsoniceurope.com/uk/	www.viewsoniceurope.com/uk/ support/call-desk/	service_gb@viewsoniceurope.com
United States	www.viewsonic.com	T (Toll-Free)= 1-800-688-6688 T (Toll)= 1-424-233-2530 F= 1-909-468-3757	service.us@viewsonic.com

Limited Warranty

VIEWSONIC® NETBOOK

What the warranty covers:

ViewSonic warrants its products to be free from defects in material and workmanship during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, ViewSonic will, at its sole option, repair or replace the product with a similar product. Replacement Product or parts may include remanufactured or refurbished parts or components. The replacement unit will be covered by the balance of the time remaining on the customer's original limited warranty. ViewSonic provides no warranty for the third-party software included with the product or installed by the customer.

How long the warranty is effective:

ViewSonic Netbook products are warranted for (1) year from the first consumer purchase for parts and labor.

User is responsible for the back up of any data before returning the unit for service.

ViewSonic is not responsible for any data lost.

Who the warranty protects:

This warranty is valid only for the first consumer purchaser.

What the warranty does not cover:

1. Any product on which the serial number has been defaced, modified or removed.
2. Damage, deterioration or malfunction resulting from:
 - a. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
 - b. Any damage of the product due to shipment.
 - c. Removal or installation of the product.
 - d. Causes external to the product, such as electrical power fluctuations or failure.
 - e. Use of supplies or parts not meeting ViewSonic's specifications.
 - f. Normal wear and tear.
 - g. Any other cause which does not relate to a product defect.
3. Any product exhibiting a condition commonly known as "image burn-in" which results when a static image is displayed on the product for an extended period of time.
4. Removal, installation, one way transportation, insurance, and set-up service charges.

How to get service:

1. For information about receiving service under warranty, contact ViewSonic Customer Support (Please refer to Customer Support page). You will need to provide your product's serial number.
2. To obtain warranty service, you will be required to provide (a) the original dated sales slip, (b) your name, (c) your address, (d) a description of the problem, and (e) the serial number of the product.
3. Take or ship the product freight prepaid in the original container to an authorized ViewSonic service center or ViewSonic.
4. For additional information or the name of the nearest ViewSonic service center, contact ViewSonic.

Limitation of implied warranties:

There are no warranties, express or implied, which extend beyond the description contained herein including the implied warranty of merchantability and fitness for a particular purpose.

Exclusion of damages:

ViewSonic's liability is limited to the cost of repair or replacement of the product. ViewSonic shall not be liable for:

1. Damage to other property caused by any defects in the product, damages based upon inconvenience, loss of use of the product, loss of time, loss of profits, loss of business opportunity, loss of goodwill, interference with business relationships, or other commercial loss, even if advised of the possibility of such damages.
2. Any other damages, whether incidental, consequential or otherwise.
3. Any claim against the customer by any other party.
4. Repair or attempted repair by anyone not authorized by ViewSonic.

Effect of state law:

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow limitations on implied warranties and/or do not allow the exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

Sales outside the U.S.A. and Canada:

For warranty information and service on ViewSonic products sold outside of the U.S.A. and Canada, contact ViewSonic or your local ViewSonic dealer.

The warranty period for this product in mainland China (Hong Kong, Macao and Taiwan Excluded) is subject to the terms and conditions of the Maintenance Guarantee Card.

For users in Europe and Russia, full details of warranty provided can be found in www.viewsoniceurope.com under Support/Warranty Information.



ViewSonic