

ZyWALL Turbo Card

Extension Card

User's Guide

08/2005
Version 1.00



Copyright

Copyright © 2005 by ZyXEL Communications Corporation.

The contents of this publication may not be reproduced in any part or as a whole, transcribed, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, electronic, mechanical, magnetic, optical, chemical, photocopying, manual, or otherwise, without the prior written permission of ZyXEL Communications Corporation.

Published by ZyXEL Communications Corporation. All rights reserved.

Disclaimer

ZyXEL does not assume any liability arising out of the application or use of any products, or software described herein. Neither does it convey any license under its patent rights nor the patent rights of others. ZyXEL further reserves the right to make changes in any products described herein without notice. This publication is subject to change without notice.

Trademarks

ZyNOS (ZyXEL Network Operating System) is a registered trademark of ZyXEL Communications, Inc. Other trademarks mentioned in this publication are used for identification purposes only and may be properties of their respective owners.

ZyXEL Limited Warranty

ZyXEL warrants to the original end user (purchaser) that this product is free from any defects in materials or workmanship for a period of up to two (2) years from the date of purchase. During the warranty period, and upon proof of purchase, should the product have indications of failure due to faulty workmanship and/or materials, ZyXEL will, at its discretion, repair or replace the defective products or components without charge for either parts or labor, and to whatever extent it shall deem necessary to restore the product or components to proper operating condition. Any replacement will consist of a new or re-manufactured functionally equivalent product of equal value, and will be solely at the discretion of ZyXEL. This warranty shall not apply if the product is modified, misused, tampered with, damaged by an act of God, or subjected to abnormal working conditions.

Note

Repair or replacement, as provided under this warranty, is the exclusive remedy of the purchaser. This warranty is in lieu of all other warranties, express or implied, including any implied warranty of merchantability or fitness for a particular use or purpose. ZyXEL shall in no event be held liable for indirect or consequential damages of any kind of character to the purchaser.

To obtain the services of this warranty, contact ZyXEL's Service Center for your Return Material Authorization number (RMA). Products must be returned Postage Prepaid. It is recommended that the unit be insured when shipped. Any returned products without proof of purchase or those with an out-dated warranty will be repaired or replaced (at the discretion of ZyXEL) and the customer will be billed for parts and labor. All repaired or replaced products will be shipped by ZyXEL to the corresponding return address, Postage Paid. This warranty gives you specific legal rights, and you may also have other rights that vary from country to country.

Customer Support

METHOD	SUPPORT E-MAIL	TELEPHONE ^A	WEB SITE
LOCATION	SALES E-MAIL	FAX	FTP SITE
CORPORATE HEADQUARTERS (WORLDWIDE)	support@zyxel.com.tw	+886-3-578-3942	www.zyxel.com www.europe.zyxel.com
	sales@zyxel.com.tw	+886-3-578-2439	ftp.zyxel.com ftp.europe.zyxel.com
CZECH REPUBLIC	info@cz.zyxel.com	+420 241 091 350	www.zyxel.cz
	info@cz.zyxel.com	+420 241 091 359	
DENMARK	support@zyxel.dk	+45 39 55 07 00	www.zyxel.dk
	sales@zyxel.dk	+45 39 55 07 07	
FINLAND	support@zyxel.fi	+358-9-4780-8411	www.zyxel.fi
	sales@zyxel.fi	+358-9-4780 8448	
FRANCE	info@zyxel.fr	+33 (0)4 72 52 97 97	www.zyxel.fr
		+33 (0)4 72 52 19 20	
GERMANY	support@zyxel.de	+49-2405-6909-0	www.zyxel.de
	sales@zyxel.de	+49-2405-6909-99	
NORTH AMERICA	support@zyxel.com	+1-800-255-4101 +1-714-632-0882	www.us.zyxel.com
	sales@zyxel.com	+1-714-632-0858	ftp.us.zyxel.com
NORWAY	support@zyxel.no	+47 22 80 61 80	www.zyxel.no
	sales@zyxel.no	+47 22 80 61 81	

METHOD	SUPPORT E-MAIL	TELEPHONE^A	WEB SITE
LOCATION	SALES E-MAIL	FAX	FTP SITE
SPAIN	support@zyxel.es	+34 902 195 420	www.zyxel.es
	sales@zyxel.es	+34 913 005 345	
SWEDEN	support@zyxel.se	+46 31 744 7700	www.zyxel.se
	sales@zyxel.se	+46 31 744 7701	
UNITED KINGDOM	support@zyxel.co.uk	+44 (0) 1344 303044 08707 555779 (UK only)	www.zyxel.co.uk
	sales@zyxel.co.uk	+44 (0) 1344 303034	ftp.zyxel.co.uk

a. "+" is the (prefix) number you enter to make an international telephone call.

Table of Contents

Introduction	5
Installation	6
Activating IDP and AV	8
Removing Turbo	13
Product Specifications	14

1 Introduction

ZyWALL Turbo Card is a co-processor accelerator that is used in conjunction with a ZyWALL 5, ZyWALL 35 or ZyWALL 70 for fast, efficient IDP (Intrusion Detection and Prevention) and AV (Anti Virus) traffic inspection.

We refer to ZyWALL Turbo Card as “Turbo” and to ZyWALL 5, ZyWALL 35 or ZyWALL 70 as “ZyWALL” in this guide.

Figure 1 ZyWALL Turbo Card



Note: Turbo does not have a MAC address.

2 Installation


- 1 Turn off the ZyWALL.

Note: Do not insert Turbo while the ZyWALL is turned on.

- 2 Carefully insert Turbo into the rear panel slot of the ZyWALL. If the slot already contains a wireless card, remove it.

Note: The ZyWALL has no wireless capability when Turbo is in place.

Figure 2 Inserting Turbo



3 Turn on the ZyWALL.

2.1 Turbo LEDs

Figure 3 Turbo LEDs



LED	DESCRIPTION
PWR	The PWR LED turns on when the Turbo card is inserted into the ZyWALL and the ZyWALL is turned on.
ACT	The ACT LED blinks when Turbo is performing IDP and/or AV traffic inspection.

3 Activating IDP and AV

- 1 Access the ZyWALL web configurator (192.168.1.1 is the default IP address).

Note: See your ZyWALL User's Guide for detailed information on the web configurator.

- 2 You must register for AV and IDP services before using these services. Click **REGISTRATION** in the navigation panel. You can create a myZyXEL.com account and activate a trial usage of IDP and AV here.

Figure 4 Service Registration

REGISTRATION

Registration **Service**

Device Registration

☒ New myZyXEL.com account ☐ Existing myZyXEL.com account

User Name: ZyWALL Check

Password: ***** (Type username and password from 6 to 20 characters.)

Confirm Password: *****

E-Mail Address: test@zyxel.com

Country: Taiwan

Service Activation

☒ Content Filtering 1-month Trial

☒ Anti Spam 3-month Trial

☒ IDP/AV 3-month Trial

Note: For more device services management, please go to myZyXEL.com

Apply Reset

- 3 Click the **Service** tab. After you are satisfied with the IDP and AV services, you should purchase an iCard and activate standard service in the service screen by entering the license key.

Figure 5 Activate Standard Services.

REGISTRATION

Registration

Service

Service Management

Service	Status	Registration Type	Expiration Day
Content Filter Service	Inactive	-	-
Anti-Spam Service	Inactive	-	-
IDP/Anti-Virus Service	Inactive	-	-

License Upgrade

License Key

Update

Service License Refresh

(Sync with myZyXEL.com to download license Info.)

- Click **SECURITY, AV**. Enable AV and select the services and interfaces for AV traffic inspection in this screen.

Figure 6 Activate AV

ANTI-VIRUS

General Update

General Setup

☒ Enable Anti-Virus

Available Service

Service	Active	Log	Alert	Protected Interface	Send Windows Message	Destroy File
FTP (TCP 20/21)	☒	☒	☐	☒ LAN ☒ WAN_1 ☒ WAN_2 ☒ DMZ	☐	☐
HTTP (TCP 80, 8080, 3128)	☒	☒	☐	☒ LAN ☒ WAN_1 ☒ WAN_2 ☒ DMZ	☐	☐
POP3 (TCP/UDP 110)	☒	☒	☐	☒ LAN ☒ WAN_1 ☒ WAN_2 ☒ DMZ	☐	☐
SMTP (TCP/UDP 25)	☒	☒	☐	☒ LAN ☒ WAN_1 ☒ WAN_2 ☒ DMZ	☐	☐

Apply Reset

- 5** Click **SECURITY, IDP**. Enable IDP on the selected ZyWALL interfaces in this screen. Traffic going out from the ZyWALL through the selected interface(s) is inspected for malicious packets.

Figure 7 Activate IDP

INTRUSION DETECTION AND PREVENTION

General Signature Update Backup & Restore

General Setup

☒ Enable Intrusion Detection and Prevention

Protected Interface	Active
WAN1	☒
WAN2	☒
LAN	☒
DMZ	☒

Apply Reset

- 6** Use either the **AV** or **IDP Update** screen to regularly update AV and IDP signatures. Regular updates are important as new network threats evolve.

Figure 8 Update Services

The screenshot displays the 'INTRUSION DETECTION AND PREVENTION' section of the ZyWALL Turbo Card web interface. It features four tabs: 'General', 'Signature', 'Update', and 'Backup & Restore'. The 'Update' tab is active, showing 'Signature Information' and 'Signature Update' sections.

Signature Information

- Current Pattern Version: v001.002
- Release Date: 09:02:04 06/01/2005
- Last Update: N/A
- Current IDP Signatures: 1723

Signature Update

Service Status: **License Inactive**

Synchronize the IDP and Anti-Virus Signature to the latest version with the online update server.

Update Server: myupdate.zywall.zyxel.com

☒ Auto Update

- ☐ Hourly
- ☐ Daily (0'clock)
- ☐ Weekly (0'clock)


4 Removing Turbo

- 1 Turn off the ZyWALL.

Note: Do not remove Turbo while the ZyWALL is turned on.

- 2 Press the eject button to pop Turbo out from the slot.

Figure 9 Removing Turbo



- 3 Replace the cover on the slot to prevent dust etc. from entering the ZyWALL

5 Product Specifications

FEATURE	DESCRIPTION
Operating Environment	Temperature: 0°C to 40° C Humidity: 5 to 90% (non-condensing)
Dimensions	(W) 115mm × (D) 55mm × (H) 9mm
Weight	41 (g)